9050B Excavator

P.I.N. EAC0501122 and After

Operators Manual

Bur 9-29291

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 9050B Excavator Operator's Manual | Publication 9-29291

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
RIGHT, LEFT, FRONT, AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 3
MACHINE COMPONENTS 4, 5

SAFETY / DECALS / HAND SIGNALS 7
SAFETY RULES 7
BEFORE OPERATION 8
MACHINE OPERATION 10
PARKING THE MACHINE 12
BURN PREVENTION 12
FIRE OR EXPLOSION PREVENTION 13
MAINTENANCE 14
SAFETY DECALS 16
HAND SIGNALS 25, 26

INSTRUMENTS AND CONTROLS 27
LOCATION OF COMPONENTS 27
HAND AND FOOT CONTROLS 28
STANDARD CONTROLS 29
OPTIONAL CONTROLS 30
RIGHT FRONT CONTROL PANEL 32
LEFT FRONT CONTROL PANEL 36
SYSTEMS DISPLAY PANEL 38
RIGHT REAR CONTROL PANEL 44
LEFT REAR CONTROL PANEL 45
OPERATION OF HEATING AND AIR CONDITIONING (If Equipped) 46
AM / FM RADIO 48
OPERATOR'S SEAT 49
SEAT BELT 50
CAB WINDOW AND DOOR CONTROLS 51
ANTI-VANDAL GUARD 54

OPERATING INSTRUCTIONS 55
RUN-IN PERIOD OF A NEW MACHINE 55
ENGINE OPERATION 55
ENGINE STARTING AID 60
MACHINE OPERATION 62
DRIVING THE MACHINE 63
AUXILIARY ATTACHMENT OPERATION 69
DISABLED MACHINE 79
TRANSPORTING THE MACHINE ON A TRAILER 79
OPERATING IN HOT WEATHER 82
OPERATING IN COLD WEATHER 82
MACHINE STORAGE 84

TRIM THIS EDGE

MidWestTech | Case 9050B Excavator Operator's Manual | Publication 9-29291 Order the manual at mid-west-tech.com >

LUBRICATION/FILTERS/FLUIDS 87
GENERAL SAFETY BEFORE YOU SERVICE 87
ENVIRONMENT 87
9050B LUBRICATION CHART 89
FLUIDS AND LUBRICATANTS 91
SERVICE SCHEDULE 92
HYDRAULIC FLUID CHART 94
ENGINE OIL RECOMMENDATIONS 95
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 96
GREASE FITTINGS 97
ENGINE LUBRICATION SYSTEM (CUMMINS M11-C265 ENGINE) 100
AIR FILTER SYSTEM 102
ENGINE COOLING SYSTEM (CUMMINS M11-C265 ENGINE) 105
DIESEL FUEL SYSTEM (CUMMINS M11-C265 ENGINE) 110
HYDRAULIC SYSTEM 112
SWING GEARBOX 121
FINAL DRIVE GEARBOXES 122

MAINTENANCE AND ADJUSTMENTS 123
DRIVE BELTS 123
AIR PRESSURE RESERVOIR 127
WINDSHIELD WASHER RESERVOIR 127
TESTING THE ACCUMULATOR 128
TRACKS 130
TRACK SHOE BOLTS 133
BUCKET INSTALLATION 134
WELDING ON THE MACHINE 134
FIRE EXTINGUISHER 135
SEAT BELT 136
PLASTIC AND RESIN PARTS 136
CAB AIR FILTER 137

ELECTRICAL SYSTEM 139
BATTERIES 139
FUSES 142

SPECIFICATIONS 143
CUMMINS ENGINE (M11-C265) DATA 143
DIMENSIONS 144
OPERATING DATA 146
WEIGHTS 147
LIFTING CAPACITIES 149
2.63 m (8 ft 8 in) SHORT ARM S (STANDARD), H (HEAVY), or L (LIGHT) MODE 150
2.63 M (8 ft 8 in) SHORT ARM F (FINE) MODE 151

TRIM THIS EDGE

MidWestTech | Case 9050B Excavator Operator's Manual | Publication 9-29291 Order the manual at mid-west-tech.com >

SPECIFICATIONS (CONT.)
3.23 m (10 ft 7 in) STANDARD ARM S (STANDARD), H (HEAVY), or L (LIGHT) MODE 152
3.23 m (10 ft 7 in) STANDARD ARM F (FINE) MODE 153
4.03 m (13 ft 3 in) LONG ARM S (STANDARD), H (HEAVY), or L (LIGHT) MODE 154
4.03 m (13 ft 3 in) LONG ARM F (FINE) MODE 155
BUCKETS 156
BOLT TORQUES 158

AFTER DELIVERY CHECK 161, 163

ALPHABETICAL INDEX 165

TRIM THIS EDGE

MidWestTech | Case 9050B Excavator Operator's Manual | Publication 9-29291 Order the manual at mid-west-tech.com >