9060B Excavator

P.I.N. EAC0601026 and After

Operators Manual

Bur 9-29381
Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 9060B Excavator Operator's Manual | Publication 9-29381

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER 1
RIGHT, LEFT, FRONT, AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 3
MACHINE COMPONENTS 4

SAFETY / DECALS / HAND SIGNALS 7
SAFETY RULES 7
BEFORE OPERATION 8
MACHINE OPERATION 10
PARKING THE MACHINE 12
BURN PREVENTION 12
FIRE OR EXPLOSION PREVENTION 13
MAINTENANCE 14
SAFETY DECALS 17
HAND SIGNALS 26, 27

INSTRUMENTS AND CONTROLS 29
LOCATION OF COMPONENTS 29
HAND AND FOOT CONTROLS 30
STANDARD CONTROLS 31
OPTIONAL CONTROLS 32
RIGHT fRONT CONTROL PANEL 34
LEFT FRONT CONTROL PANEL 38
SYSTEMS DISPLAY PANEL 40
RIGHT REAR CONTROL PANEL 46
LEFT REAR CONTROL PANEL 47
OPERATION OF HEATING AND AIR CONDITIONING 48
AM / FM RADIO 50
OPERATOR'S SEAT 51
SEAT BELT 52
CAB WINDOWS AND DOOR CONTROLS 53
ANTI-VANDAL GUARD 56

OPERATING INSTRUCTIONS 57
RUN-IN PERIOD OF A NEW MACHINE 57
ENGINE OPERATION 57
ENGINE STARTING AID 62
MACHINE OPERATION 64
DRIVING THE MACHINE 65
AUXILIARY ATTACHMENT OPERATION 71
DISABLED MACHINE 81
TRANSPORTING THE MACHINE ON A TRAILER 81
REAR COUNTERWEIGHT REMOVAL AND INSTALLATION 84
OPERATING IN HOT WEATHER 90
OPERATING IN COLD WEATHER 90, 91
MACHINE STORAGE 92

TRIM THIS EDGE

MidWestTech | Case 9060B Excavator Operator's Manual | Publication 9-29381 Order the manual at mid-west-tech.com >

LUBRICATION/FILTERS/FLUIDS 95
GENERAL SAFETY BEFORE YOU SERVICE 95
ENVIRONMENT 95
9060B LUBRICATION CHART 97
SERVICE SCHEDULE 100
HYDRAULIC FLUID CHART 102
ENGINE OIL RECOMMENDATIONS 103
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 104
GREASE FITTINGS 105
ENGINE LUBRICATION SYSTEM (CUMMINS ENGINE M11-C320) 108
AIR FILTER SYSTEM 110
ENGINE COOLING SYSTEM (CUMMINS ENGINE M11-C320) 113, 114
DIESEL FUEL SYSTEM (CUMMINS ENGINE M11-C320) 118
HYDRAULIC SYSTEM 120
SWING GEARBOX 129
FINAL DRIVE GEARBOXES 130

MAINTENANCE AND ADJUSTMENTS 131
DRIVE BELTS 131
AIR PRESSURE RESERVOIR 135
WINDSHIELD WASHER RESERVOIR 135
TESTING THE ACCUMULATOR 136
SETTING THE AUXILIARY COOLING FAN SPEED 138
TRACKS 140
TRACK SHOE BOLTS 143
BUCKET INSTALLATION 144
WELDING ON THE MACHINE 144
FIRE EXTINGUISHER 145
SEAT BELT 146
PLASTIC AND RESIN PARTS 146
CAB AIR FILTER 147

ELECTRICAL SYSTEM 149
BATTERIES 149
FUSES 152

SPECIFICATIONS 153
CUMMINS ENGINE (M 11-C320) DATA 153
DIMENSIONS 154
OPERATING DATA 156
WEIGHTS 158
LIFTING CAPACITIES 159
2.5 m (8 ft 3 in) SUPER SHORT ARM S (STANDARD), H (HEAVY), or L (LIGHT) MODE 160
3.4 m (11 ft 1 in) SHORT ARMS (STANDARD), H (HEAVY), or L (LIGHT) MODE 161
4.0 m (13 ft 1 in) STANDARD ARMS (STANDARD), H (HEAVY), or L (LIGHT) MODE 162

TRIM THIS EDGE

MidWestTech | Case 9060B Excavator Operator's Manual | Publication 9-29381 Order the manual at mid-west-tech.com >

SPECIFICATIONS (CONTINUED)
5.4 m (17 ft 8 in) LONG ARMS (STANDARD), H (HEAVY), or L (LIGHT) MODE 163
2.5 m (8 ft 3 in) SUPER SHORT ARMF (FINE) MODE 164
3.4 m (11 ft 1 in) SHORT ARMF (FINE) MODE 165
4.0 m (13 ft 1 in) STANDARD ARMF (FINE) MODE 166
5.4 m (17 ft 8 in) LONG ARMF (FINE) MODE 167
BUCKETS 168
BOLT TORQUES 169

AFTER DELIVERY CHECK 171, 173

ALPHABETICAL INDEX 175

TRIM THIS EDGE

MidWestTech | Case 9060B Excavator Operator's Manual | Publication 9-29381 Order the manual at mid-west-tech.com >