W24B Loader

Operator's Manual

9-3121

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W24B Loader Operator's Manual | Publication 9-3121

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Safety 2
Safety Rules 2
Rollover Protective Structure 7
Spark Arresting Muffler 9
Introduction 10
To the Case Owner 10
Serial Number Location 11
Specifications 12
Engine 12
Electrical System 12
Hydraulic System 12
Steering System 12
Travel Speeds 13
Tire Pressure 13
Operating Data 14
Dimensions 15
Buckets 15
Operating Instructions 16
Instruments and Controls 16
Loader Controls 23
Return-To-Dig 25
Bucket Height Control 25
Bucket Level Indicator 26
Engine Operation 27
Run-In 27
Starting 27
Idling 28
Stopping 28
Starting Aids 28
Manifold Preheater 29
Ether Injection 29
Coolant Heater 30
Booster Batteries 31
Machine Operation 31
Driving 31
Starting 31
Range Selection 31
Changing Directions 32
Steering 32
Engine Braking 32
Stopping 33
Towing 33
Cold Weather Operation 33
Hot Weather Operation 34
Loader Operating Tips 35
Job Layout 35
Filling the Bucket 36
Transporting 37
Dumping the Bucket 37
Truck Loading 38
Return-To-Dig Operation 38
Bucket Height Control 38
Fuels and Lubricants 39
Diesel Fuel 39
Fuel Specifications 39
Fuel Storage 41
Lubricants 41
Frame Pivot Safety Link 42
Fuel, Fluids and Lubricants Chart 43
Maintenance/Lubrication 44
Introduction 44
Maintenance Chart 45
Lubrication Points 47
Engine Lubrication System 49
Oil Level 49
Oil Change 49
Filter Change 50
Air Cleaning System 51
Auto Dust Unloader 51
Restriction Indicator 52
Air Cleaner Servicing 53
Cleaning the Element 54
Cooling System 56
Radiator 56
Coolant 56
Antifreeze 57
Cleaning the System 57
Thermostat 59
Fan Belts 59
Fuel System 61
Cleaning the System 62
Fuel Tank 63
Servicing Fuel Filters 64
Electric Fuel Pump Filter 64
Transfer Pump Filter 64
Bleeding the System 65
Electrical System 66
Lights 66
Starter Motor 67
Alternator 68
Battery 69
Booster Batteries 71
Hydraulic System 72
Oil Level 72
Oil and Filter Change 72
Braking System 74
Transmission 76
Oil Level 76
Oil and Filter Change 77
Front and Rear Axles 79
Oil Level 79
Oil Change 80
Axles, Wheels and Tires 81
Storage 81
Removal From Storage 83
Replacing Bucket Teeth 84
Spark Arresting Muffler 85
After Delivery Checkup 87

MidWestTech | Case W24B Loader Operator's Manual | Publication 9-3121 Order the manual at mid-west-tech.com >