W14
Articulated Loader
S/N 9119395 to 9119672
Operators Manual

9-3212

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case W14 Articulated Loader Operator's Manual | Publication 9-3212

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Safety Rules 2
Spark Arresting Muffler 10
Roll-Over Protection Structure 11
Introduction 13
To The Owner 13
Serial Number Location 14
Specifications 15
Operating Instructions 20
Instruments and Controls 20
L.H. Instrument Cluster 20
R.H. Instrument Panel 22
Operator's Compartment 24
Loader 28
Engine Operation 32
Run-In 32
Starting 32
Idling 33
Stopping 33
Starting Aids 33
Jump Starting Machine 36
Machine Operation 36
Driving 36
Cold Weather Operation 38
Hot Weather Operation 39
Loader Operation 40
Job Layout 41
Filling the Bucket 41
Transporting 43
Dumping the Bucket 43
Truck Loading 43
Return-To-Dig Operation 44
Fuels and Lubricants 45
Diesel Fuel 45
Fuel Specifications 45
Fuel Storage 45
Lubricants 47
Fuel, Fluids and Lubricants 48
Maintenance/Lubrication 49
Safety Link 49
Run-In Maintenance Chart 50
Scheduled Maintenance Chart 50
Lubrication Points 52
Engine Lubrication System 54
Oil Level 54
Oil Filter 55
Air Cleaning System 56
Restriction Indicator 58
Safety Filter 58
Air Cleaning Servicing 59
Cooling System 61
Radiator Cap 61
Coolant 61
Thermostat 62
Cleaning the System 64
Drive Belts 65
Fuel System 67
Draining Water From System . . . 67
Bleeding the System 69
Servicing Fuel Filters 69
Electrical System 71
Lights 71
Alternator 72
Battery Care 73
Specific Gravity Check 75
Hydraulic System 77
Oil Level 77
Oil and Filter Change 77
Braking System 79
Air Compressor 79
Air Reservoir 79
Master Cylinders 80
Alcohol Evaporator 80
Transmission/Converter Hydraulic System 82
Oil Level 82
Oil Change 83
Front and Rear Axles 86
Wheels and Tires 86
Return-To-Dig 88
Bucket Height Control 89
Bucket Teeth 90
Machine Storage 90
Reactivating Machine 92
Spark Arresting Muffler 93
After Delivery Checkup 95

MidWestTech | Case W14 Articulated Loader Operator's Manual | Publication 9-3212 Order the manual at mid-west-tech.com >