W14
Articulated Loader

S/N 9119672 And After

Operators Manual

9-3324

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case W14 Articulated Loader Operator's Manual | Publication 9-3324

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
Delivery of New Machine 3
Safety 4
Safety Rules 4
Spark Arrester 19
Roll-Over Protective Structure 20
Location of Product Identification Number 24
Location of Serial Numbers 25
Specifications 26
Operating Instructions 30
Instruments and Controls 30
Left Instrument Cluster 30
Right Instrument Panel 32
Operators Compartment 34
ROPS Cab Controls 36
Air Conditioning Operating Tips 39
Operators Seat 40
Seat Belts 42
Loader Controls 45
4-In-1 Bucket Controls 46
Bucket Level Indicator 48
Bucket Height Control 48
Return-To-Dig 49
Engine Operation 50
First Period of Operation with a New Engine 50
Service and Checks Before You Start 51
Starting the Engine 52
Stopping the Engine 54
Starting Aids 55
Operating the Machine 58
Operating in Cold Temperatures 61
Operating in Hot Temperatures .62
Loader Operations 63
Fuels and Lubricants 68
Diesel Fuel 68
Fuel Storage 68
Fuel, Fluids and Lubricants Chart 69
Maintenance and Lubrication ... 70
Introduction 70
Run-In Maintenance Chart 71
Scheduled Maintenance Chart 71
Safety Before You do Service 74
Grease Fittings 77
Engine Lubrication System ... 79
Engine Air Cleaning System .. 82
Engine Cooling System 87
Drive Belts 89
Fuel System 93
Electrical System 98
Battery Service 102
Hydraulic System (Before P.I.N. 9141518) 104
Hydraulic System (P.I.N. 9141518 and After) 106
Brake System 111
Transmission Hydraulic System 114
Front and Rear Axles 118
Cold Starting Aid 120
ROPS Cab and Air Conditioner 123
Cab Air Filters 124
Seat Belts 126
Wheels and Tires 131
Loader Service 133
Return-To-Dig Adjustment .133
Bucket Height Control 134
Bucket Teeth 135
Machine Storage 136
Removal from Storage 138
Spark Arrester Muffler 139
After Delivery Check 141

MidWestTech | Case W14 Articulated Loader Operator's Manual | Publication 9-3324 Order the manual at mid-west-tech.com >