W20
Articulated Loader

S/N 912340 and After

Operators Manual

9-3341

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case W20 Articulated Loader Operator's Manual | Publication 9-3341

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Safety 2
Safety Rules 2
Spark Arresting Muffler 11
Roll-Over Protection Structure 12
Introduction 15
To The Owner 15
Serial Number Location 16
Specifications 17
Engine 17
Electrical System 17
Hydraulic System 17
Travel Speeds 18
Tires 18
Operating Data and Dimensions 18
Steering System 20
Cooling System 20
Buckets 20
Capacities 20
Operating Instructions 21
Instruments and Controls 21
Loader Controls 33
4-In-1 Bucket Controls 34
Bucket Level Indicator 36
Bucket Height Control 36
Return-To-Dig 37
Engine Operation 38
Run-In 38
Starting 38
Idling 41
Shutting Off the Engine 41
Starting Aids 42
Jumper Batteries 43
Machine Operation 43
Shifting to High and Low Ranges 44
Shifting to Forward and Reverse 44
Converter Overheating 44
Steering 45
Auxiliary Steering 45
Engine Braking 45
Stopping 46
Cold Weather Operation 46
Hot Weather Operation 48
Loader Operation 49
Safety Rules 49
Job Rules 53
Filling the Bucket 54
Transporting 54
Dumping the Bucket 56
Truck Loading 56
Return-To-Dig Operation 56
Bucket Height Control 57
Clutch Cutout 58
Fuels and Lubricants 59
Diesel Fuel 59
Fuel Specifications 59
Fuel Storage 59
Fuel, Fluids and Lubricants Chart 60
Maintenance/Lubrication 61
Safety Link 61
Maintenance Chart 62
Lubrication Points 64
Engine Lubrication System 66
Oil Level 66
Oil Change 66
Oil Filter 68
Engine Air Cleaning System 68
Restriction Indicator 69
Safety Filter 70
Air Cleaner Servicing 71
Servicing the Elements 71
Spark Arresting Muffler 73
Engine Cooling System 73
Radiator Cap 73
Coolant 73
Cleaning the System 75
Thermostates 76
Drive Belts 78
Fan Belts 78
Brake System Compressor Belt 79
Air Conditioner Compressor Belt 80
Fuel System 81
Cleaning the System 82
Bleeding the System 84
Servicing the Fuel Filters 85
Electrical System 87
Lights 87
Do's and Do Not's for an Alternator Charging System 90
Battery Care and Maintenance 91
Hydraulic System 95
Oil Level 95
Oil and Filter Change 95
Braking System 97
Air Compressor 97
Air Reservoir 97
Master Cylinders 98
Alcohol Evaporator 98
Brake Adjustment 99
Transmission 100
Oil Level 100
Oil Change and Filter Service 101
Front and Rear Axles 103
Oil Level 103
Oil Change 103
Axles, Wheels and Tires 104
Loader 105
Return-To-Dig 105
Bucket Height Control 105
Replacing Bucket Teeth 107
Cold Start Aid 108
ROPS Pod Cab and Air Conditioning 109
General Maintenance 109
Cab Air Filters 110
Seat Belts 112
Operators Seat and Trim 113
Checking Refrigerant Level 115
Machine Storage 117
Removal from Storage 118
After Delivery Checkup 121

MidWestTech | Case W20 Articulated Loader Operator's Manual | Publication 9-3341 Order the manual at mid-west-tech.com >

SAFETY

SAFETY RULES

Your safety and the safety of those around you is highly dependent upon the care and good judgment you exercise in the use of this equipment. Know the positions and functions of all controls before attempting to operate. BE SURE TO CHECK ALL CONTROLS IN A SAFE OPEN AREA BEFORE STARTING YOUR WORK.

READ THIS MANUAL THOROUGHLY and make sure you understand, for example, the speed, braking, steering, stability and load characteristics of this machine before starting to operate.

The safety information presented in this manual is not intended to replace safety codes, insurance requirements, federal, state and local laws, rules and regulations. Know the regulations and laws that apply to your area and be sure that your machine is properly equipped to meet such laws and regulations.

It is recommended that the following safety rules be posted on the job site.

Pre-Starting

CAUTION: Clean or replace all safety decals if they can't be read. 25-6

CAUTION: Visually check out the machine for leaks and broken, missing or malfunctioning parts. Be sure all caps, dip sticks, battery covers, etc. are secure before starting. A part failure during operation could cause injury. 25-10



CAUTION: Wear the proper safety equipment - - avoid loose clothing. Obtain additional safety equipment when your safety may be in doubt. Hard hat, safety shoes, ear protectors, reflective clothing, safety goggles and heavy gloves may be required. 1-3

MidWestTech | Case W20 Articulated Loader Operator's Manual | Publication 9-3341 Order the manual at mid-west-tech.com >

CAUTION: Check that all lights (if so equipped) are functioning properly before operating at night. 25-7

WARNING: Be sure the operator's area, steps and grab handles are free of oil, loose objects or ice. Remove or secure all maintenance or personal items. Failure to keep these areas clean could cause a serious accident. 25-8



CAUTION: Know and understand the traffic flow patterns of your job. Understand and obey the flagman, road signs or signals. 1-8

CAUTION: Carry and maintain a fire extinguisher and first aid kit at all times. Know how to use them both. 25-9



WARNING: Do not smoke when using starting fluid or spray fluid near an open fire. Do not puncture or throw starting fluid can into an incinerator. Use this starting aid sparingly and do not store in a hot area. 1-10

WARNING: BE PARTICULARLY CAREFUL IF THIS IS NOT THE MACHINE YOU WOULD NORMALLY OPERATE. 2-2

MidWestTech | Case W20 Articulated Loader Operator's Manual | Publication 9-3341 Order the manual at mid-west-tech.com >