W36
Articulated Loader

Operators Manual

9-3502

CASE
CONSTRUCTION

MidWestTech | Case W36 Articulated Loader Operator's Manual | Publication 9-3502

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
Safety 4
Serial Number Location 23
Specifications 24
Operating Instructions 29
Instruments and Controls 29
Right-Hand Instrument Cluster 29
Left-Hand Instrument Panel 30
Transmission Controls 32
Foot Controls 33
Indicators Behind Operator's Area 34
ROPS Cab Controls 35
Air Conditioning Operating Tips 37
Operator's Seats 38
Loader Controls 41
Auxiliary Attachment Control 42
Control Lever Notes 42
Bucket Height Control 43
Return-To-Dig 44
Alcohol Evaporator 44
Engine Operation 45
Engine Run-In 45
Walk-Around Checks Before Starting 46
Starting the Engine 46
Idling the Engine 47
Stopping the Engine 48
Starting Aids 49
Cold Start (Ether Injection) 49
Aerosol Starting Fluid 51
24 Volt External Power Source 52
Machine Operation 53
Driving the Machine 53
Transmission Range Selection 54
Transmission Directional Shifts 54
Converter Overheating 55
Steering 55
Auxiliary Steering 55
Engine Braking 56
Stopping 56
Machine Braking System 57
Towing 58
Transporting the Machine 60
Cold Weather Operation 63
Hot Weather Operation 63
Operating Tips 64
Engine Speed and Transmission Range 64
Job Layout 65
Filling the Bucket 65
Transporting a Load 66
Dumping the Bucket 67
Truck Loading 67
Return-To-Dig 67
Bucket Height Control 68
Left Brake Pedal 68
Slow Moving Vehicle Emblem 68
Backup Alarm 68
Fuels and Lubricants 69
Maintenance/Lubrication 71
Introduction 71
Run-In Maintenance Chart 72
Scheduled Maintenance Chart 72
Transport/Service Link 74
Warning Tag 74
Engine Lubrication System 78
Oil Level 78
Oil Change 79
Filter Change 79
Air Cleaning System 80
Restriction Indicator 80
Automatic Dust Unloader 81
Element Service 82
Washing the Element 83
Cleaning the Element with Air 84
Inspecting Element 84
Engine Cooling System 85
Antifreeze 85
Cleaning the System 86
Drive Belts 87
Fan Belts 87
Brake System Compressor Belt 88
Air Conditioner Compressor Belt 89
Fuel System 90
Daily Inspection 90
Sediment Bowl 91
Fuel Tank 91
Replacing Filters 92
Removing Air from the System 93
Electrical System 94
Safety Tips 94
Battery Care and Maintenance 94
Replacing Lights 98
Equipment and Steering Hydraulic System 103
Oil Level 103
Filter Change 103
Oil Change 105
Brake System 106
Air Compressor 106
Auxiliary Air Reservoir 106
Main Air Reservoir 107
Remote Brake Fluid Reservoir 107
Brake Warning Light 107
Alcohol Evaporator 108
Transmission 109
Oil Level 109
Filter Change 110
Oil Change, Suction Screen and Breather Service 111
Front and Rear Axles 112
Oil Level 112
Oil Change 113
Wheels and Tires 114
Wheel Nut Torque 114
Tire Pressure Chart 114
Installing Tires 114
Loader Return-To-Dig Adjustment 115
Bucket Teeth 116
Tire Inflation Kit 117
ROPS Cab and Air Conditioner 118
Seat Belt 121
Machine Storage 126
Removal from Storage 128
After Delivery Check-Up 129

MidWestTech | Case W36 Articulated Loader Operator's Manual | Publication 9-3502 Order the manual at mid-west-tech.com >