580F Construction King Loader Backhoe

Operator's Manual

9-3611

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 580F Construction King Loader Backhoe Operator's Manual | Publicat... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Safety 2
Safety Rules 2
Before you Start the Machine 2
Operation 4
Service 11
Introduction 15
Serial Number Location 16
Specifications 17
Engine 17
Cooling System 17
Electrical System 17
Hydraulic System 17
Capacities 18
Travel Speeds 18
Tires 19
Operating Weights 19
Loader 20
Sideshift Backhoe 21
Axial Backhoe 23
Buckets 24
Instruments and Controls 26
Instrument Cluster 26
Machine Controls 28
Power Shuttle Models 30
Mechanical Shuttle Models 31
Seat, Parking Brake and Differential Lock Controls 33
Cab Controls 35
Engine Operation 35
The First Period of Operation 35
Starting Procedure 36
To Warm the Engine 37
The 'Idle Speed' 37
Stopping 37
Starting Aids 38
Cold Start Wing Nut 38
Thermostart 38
Booster Batteries 40
Battery Heater 40
To Operate the Machine 40
Operator's Seat 40
Gear Selection 41
To Drive the Machine 44
To Put the Machine on a Trailer 46
To Operate in Hot Temperature 47
To Operate in Cold Temperature 47
Operating Instructions 49
Operating Instructions for Loader 49
To Lift and Lower the Bucket 49
To 'Roll-Back' or Dump the Bucket 49
To Open or Close the Bucket Clam 50
Return-To-Dig 50
50
Bucket Level Indicator 50
Indicator for 4-in-1 Bucket Position 50
Indicator for 4-in-1 Bucket Clam 51
Instructions to Operate the Backhoe 54
Sideshift Backhoe with Foot Swing 54
Sideshift Backhoe with Dual Levers 55
Axial Backhoe with Foot Swing 56
Axial Backhoe with Dual Levers 57
Sideshift Backhoe with Extendahoe and Foot Swing 58
Sideshift Backhoe with Extendahoe and Dual Levers 59
Axial Backhoe with Extendahoe and Foot Swing 59
Axial Backhoe with Extendahoe and Dual Levers 60
Boom Lockout System 60
Sideshift Locking Valve 61
'Transport' Position for Backhoe 62
To Move the Backhoe to the Right Hand or Left Hand Side 66
To Remove the Backhoe 67
To Install the Backhoe on the Machine 70
Operating Tips 71
Information for Operating Loader 71
Instructions for Operation of the Backhoe 76
Fuels and Lubricants 84
Fuel, Fluids and Lubricants Chart 87
Maintenance and Lubrication 88
Introduction 88
Maintenance Chart for the First Time Period of Operation 89
Scheduled Maintenance Chart 89
Grease Fittings 91
Engine Oil and Filter 99
Air Cleaning System 101
'Engine Cooling System' 104
Fuel System 107
'Electric System' 112
Lights 112
Alternator 112
Battery 114
Booster Batteries 118
Hydraulic System 119
Transmission for the 'Power Shuttle' 122
Transaxle 123
Final Drives 125
Power Steering System 126
Wheels and Tires 128
Brakes 129
To Adjust the Fan Belt 130
Loader Adjustment 130
Return-To-Dig 130
Anti-Rollback Adjustment 131
Bucket Teeth 132
Storage of Machine 133
To Put the Machine into Service Again 135

MidWestTech | Case 580F Construction King Loader Backhoe Operator's Manual | Publicat... Order the manual at mid-west-tech.com >