580F
Loader Backhoe

Operators Manual

9-3614

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 580F Loader Backhoe Operator's Manual | Publication 9-3614

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Safety 2
Safety rules 3
Before you start the machine 3
Operation 5
Service 13
Introduction 20
Serial number location 21
Specifications 22
Engine 22
Cooling system 22
Electrical system 22
Hydraulic system 22
Capacities 23
Travel speeds 23
Tyres 24
Operating weights 24
Loader 25
Sideshift backhoe 26
Sideshift extendahoe 28
Axial backhoe 29
Axial extendahoe 30
Boom lift capacity (without boom lock) 31
Extendahoe lifting capacity (without boom lock) 35
Buckets 42
Instruments and controls 43
Instrument cluster 43
Machine controls 45
Power shuttle models (TC only) . . 47
Mechanical shuttle models (DC only) 49
Seat and differential lock controls . . 51
Cab controls 53
Engine operation 53
The first period of operation : New engines 53
Starting procedure 54
Engine warm-up 55
Idling 55
Stopping 55
Starting aids 56
Cold start wing nut 56
Thermostart 56
Booster Batteries 58
Battery heater 58
To operate the machine 58
Operator's seat 58
Gear selection 59
To drive the machine 62
To put the machine on a trailer . . 64
To operate in hot temperature . . 65
To operate in cold temperature . . 65
Operating instruction 67
Operating instructions for loader . . . 67
To lift and lower the bucket . . . 67
To «roll-back» or dump the bucket 67
To open or close the bucket clam 68
«Return-to-dig» 68
Bucket level indicator 68
Indicator for 4-in-1 bucket position 68
Indicator for 4-in-1 bucket clam . 69
Instructions to operate the backhoe 72
Sideshift backhoe with foot swing 72
Sideshift backhoe with dual levers 73
Axial backhoe controls with foot swing 74
Axial backhoe with dual controls 75
Sideshift backhoe with «Extendahoe» and foot swing 76
Sideshift backhoe with extendahoe and dual levers (controls not shown) 76
Axial backhoe with extendahoe and foot swing 77
Axial backhoe with extendahoe and dual levers (controls not shown). 77
Boom lockout system 78
Sideshift locking valve 79
«Transport» position for backhoe 80
To move the backhoe to the right hand or left hand side 84
To remove the backhoe 85
To install the backhoe on the machine 88
Operating tips 89
Loader operating tips 89
Instructions for operation of the backhoe 94
Fuels and lubricants 106
Diesel fuel 106
Fuel fluids and lubricants for the machine 108
Maintenance / Lubrication 109
Introduction 109
Maintenance chart for the first time period of operation (0-20 hours) . . 110
Scheduled maintenance chart 110
Grease fittings 112
Front wheel bearings 117
Engine oil and filter oil 121
The air cleaning system 123
The engine cooling system 125
The fuel system 128
The electrical system 133
To replace the lights 133
Alternator 133
Battery maintenance 135
Booster batteries 139
The hydraulic system 140
Power shuttle transmission 143
The «Transaxle» 145
The «Final drives» 147
The «Power steering system» 148
Wheels and tyres 150
The brakes 151
Clutch adjustment 154
To adjust the fan belt 154
Loader adjustments 155
Return-to-dig 155
«Anti-rollback» adjustment . . . 156
Bucket teeth 156
Storage of machine 157
Reactivating machine 160

MidWestTech | Case 580F Loader Backhoe Operator's Manual | Publication 9-3614 Order the manual at mid-west-tech.com >