W24B
Articulated Loader

Operators Manual

9-4083

CASE
CONSTRUCTION

MidWestTech | Case W24B Articulated Loader Operator's Manual | Publication 9-4083

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE CASE OWNER 1
SAFETY RULES 2
INTRODUCTION 4
SERIAL NUMBER LOCATION 5
SPECIFICATIONS 6
OPERATING INSTRUCTIONS 10
- Indicators And Controls 10
- Loader Controls 16
- Engine Operation 20
- Machine Operation 24
- Loader Operating Tips 28

FUELS AND LUBRICANTS 32
- Diesel 32
- Lubricants 34
- Fuel, Fluids And Lubricants Chart 36

MAINTENANCE/LUBRICATION 37
- General Information 37
- Scheduled Maintenance Chart 38
- Lubrication Points 40
- Engine Lubrication System 42
- Air Cleaning System 44
- Cooling System 49
- Thermostat 52
- Fan Belts 52
- Compressor Belt 53
- Fuel System 54
- Electrical System 59
- Equipment And Steering Hydraulic System 65
- Braking System 67
- Transmission 69
- Front And Rear Axles 72
- Wheels And Tires 74
- Storage 74
- Removal From Storage 76

ROLLOVER PROTECTIVE STRUCTURE 78

MidWestTech | Case W24B Articulated Loader Operator's Manual | Publication 9-4083 Order the manual at mid-west-tech.com >