W14
Articulated Loader

Operators Manual

9-4195

CASE
CONSTRUCTION

MidWestTech | Case W14 Articulated Loader Operator's Manual | Publication 9-4195

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Safety Rules 2
To The Case Owner 5
Serial Number Location 7
Specifications 9
Operating Instructions 15
Indicators and Controls 15
Engine Operation 27
Tractor Operation 31
Loader Operating Tips 35
ROPS 39
Fuel and Lubricants 41
Diesel Fuel 41
Lubrication 43
Fuel, Fluids and Lubricants Chart 45
Maintenance 46
Maintenance Schedule Chart 46
Lubrication Points 49
Engine Lubrication System 52
Air Cleaning System 54
Cooling System 59
Drive Belts 63
Fuel System 65
Electrical System 69
Equipment and Steering Hydraulic System 74
Braking System 77
Transmission-Converter Hydraulic System 80
Front and Rear Axles 84
Wheels and Tires 86
Loader 86
Bucket Teeth 88
Tractor Storage 88
Index 92
After Delivery Checkup 97

MidWestTech | Case W14 Articulated Loader Operator's Manual | Publication 9-4195 Order the manual at mid-west-tech.com >