W18 Loader

SN 9115403 & After

Operators Manual

9-4852

CASE CONSTRUCTION

MidWestTech | Case W18 Loader Operator's Manual | Publication 9-4852

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Safety Precautions 2
Spark Arresting Muffler 4
ROPS 4
Seat Belts 4
Accidental Upset 5
Maintenance and Inspection 5
Safety Precautions 5
Introduction 7
To the Owner 7
Serial Number Location 8
Specifications 9
Operating Instructions 15
Instruments and Controls 15
Operator's Compartment 15
Air Horn Button 15
Left and Right Brake Pedals . . . 15
Foot Throttle 15
Bucket and Lift Arm Controls . . 15
Range Selector Lever 16
Converter Oil Temp. Gauge . . . 17
Air Pressure Gauge 17
Fuel Gauge 17
Clutch Pressure Warning Light 17
Engine Oil Pressure Warning Light 17
Alternator Warning Light 17
Brake Warning Light 17
Water Temperature Gauge 18
Light Switch 18
Parking Brake Control 18
Key Switch 19
Fuel Shutoff Lever 19
Tachometer 20
Electric Hourmeter 20
Air Cleaner Restric. Indicator . . 20
Turn Signal Lever 21
Safety Flasher Lever 21
Operator's Seat 21
Height Adjustment 21
Tilt Adjustment 21
Horizontal Adjustment 21
Seat Belt 21
Loader Controls 22
Return-To-Dig 22
Bucket Height Control 22
Engine Operation 24
Run-In 24
Starting 25
Idling 26
Stopping 26
Starting Aids 26
Machine Operation 28
Driving 28
Cold Weather Operation 30
Hot Weather Operation 31
Loader Operation 32
Job Layout 33
Filling the Bucket 33
Transporting 35
Dumping the Bucket 35
Truck Loading 35
Return-To-Dig Operations 36
Fuels and Lubricants 37
Diesel Fuel 37
Fuel Specifications 37
Fuel Storage 37
Lubricants 38
Maintenance 40
Safety Link 40
Maintenance Schedule 41
Fuels, Fluids and Lubricants Chart. . 43
Lubrication Points 44
Engine Lubrication System 47
Oil Level 47
Oil Change 47
Oil Filter 48
Air Cleaning System 49
Restriction Indicator 51
Air Cleaner Servicing 51
Cooling System 53
Radiator Cap 53
Coolant 54
Thermostats 54
Cleaning the System 56
Drive Belts 58
Fuel System 59
Cleaning the System 60
Bleeding the System 63
Servicing Fuel Filters 64
Electrical System 65
Lights 65
Starter Motor 67
Alternator 68
Battery Care 68
Specific Gravity Table 70
Hydraulic System 71
Oil Level 71
Oil and Filter Change 71
Braking System 73
Air Compressor 73
Air Reservoir 73
Master Cylinders 74
Alcohol Evaporator 74
Trans. Torque Conv. Hydraulic Sys. . 76
Oil Level 76
Oil Change 77
Axles 79
Oil Level 79
Oil Change 80
Wheels and Tires 81
Wheel Nut Torque 81
Tire Pressure 81
Return-To-Dig Adjustment 83
Bucket Height Control Adjustment . . 83
Bucket Teeth 84
Machine Storage 84
After Delivery Check-up 89

MidWestTech | Case W18 Loader Operator's Manual | Publication 9-4852 Order the manual at mid-west-tech.com >