# 1845&1845S
# UNI-LOADER

## OPERATORS MANUAL

9-4915

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 1845, 1845S Uni-Loader Operator's Manual | Publication 9-4915

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


**Introduction** ..... 2
- Safety ..... 4
- Roll-Over Protective Structure ..18
- Location of PIN Number and Serial Numbers ..... 21

**Specifications** ..... 22

**Instructions for Operation of the Machine** ..... 27
- Instruments and Controls ..... 27
- Warning Light Panel ..... 29
- Instrument Panel ..... 30
- Controls ..... 31
- Controls for Steering ..... 34
- Control for Loader Arm ..... 36
- Control for Loader Bucket/Forks ..... 37
- Bucket/Attachment Level Indicator ..... 38
- Tool-Tach ..... 39
- Control for Auxiliary Hydraulics ..... 40
- Control for Hydraulic Grapple and Scarifier ..... 40
- Operator's Seat Belt ..... 41

**Engine Operation** ..... 43
- Cold Weather Operation ..... 50
- Hot Weather Operation ..... 50

**Driving the Uni-Loader** ..... 51

**Operating Tips** ..... 53

**Fuels and Lubricants** ..... 56
- Diesel Fuel ..... 56
- Gasoline Fuel ..... 56
- Fuel, Fluids and Lubricants Chart ..... 57

**Maintenance and Lubrication** ..... 58
- Introduction ..... 58
- Run-In Maintenance Chart ..... 59
- Scheduled Maintance Chart ..... 59
- Do Not Operate Tag ..... 17, 62
- Grease Fittings ..... 62
- Engine Lubrication System ..... 63
- Air Cleaner System ..... 65

Fuel System ..... 68
- Engine Cooling System ..... 74
- Gear Reducer ..... 77
- Electrical System ..... 78
- Fan Belt ..... 89
- Drive Chains ..... 90
- Drive Chain Compartment Oil ..93
- Cleaning the Machine ..... 94
- Spark Arresting Muffler ..... 94
- Safety Decals ..... 94
- Scarifier ..... 95
- Storage ..... 95
- Servicing the 1845S ..... 98
- After Delivery Check ..... 105




MidWestTech | Case 1845, 1845S Uni-Loader Operator's Manual | Publication 9-4915 Order the manual at mid-west-tech.com >