1410
Tractor

Operators Manual

9-5418

CASE IH AGRICULTURE

MidWestTech | Case 1410 Tractor Operator's Manual | Publication 9-5418

Order the manual at mid-west-tech.com >

CONTENTS

Use of Manual and Photograph of Tractor i
Safety Messages and Cartoons ii
ROPS Safety Messages xvi
Warning Signs xix
Hand Signals xx
Tractor Identification 1
Specifications 2
Operating Instruments and Controls 16
Operating Levers and Pedals 20
Starting the Engine 28
Stopping the Engine 29
Powershift Transmission 30
Synchromesh Transmission 31
Power Take Off (PTO) 32
Front Wheel Tread Positions 2WD 33
Front Wheel Tread Positions 4WD 34
Rear Wheel Tread Positions PAVT Wheels 34
Rear Wheel Tread Positions 35
Ballast 36
Measuring Wheel Slip 37
Three Point Linkage 38
Stabilizer Bars 39
Telescopic Link Ends 40
Mechanical Flotation 40
Top Link 4WD Tractors 41
Drawbar 42
Position of Levers for Depth Control 43
Operating with Depth Control 44
Position of Levers for Height Control 44
Operating with Height Control 44
Position of Levers with TCU 45
Operating with TCU 46
Double Acting Live Take off Valves 47
Single Acting Equipment 48
Pipes and Couplers 48
Remote Cylinders (Collar Type) 49
Remote Cylinders (Clamp Type) 50
Remote Cylinders (Mechanical Stop) 51
Preventive Maintenance Introduction 52
Service Chart 53
Lubricants and Fuel Storage 54
Lubrication Chart 55
Front Axle Lubrication Chart 4WD 56
Daily Inspection 57

MidWestTech | Case 1410 Tractor Operator's Manual | Publication 9-5418 Order the manual at mid-west-tech.com >

50 Hour Service 58
100 Hour Service 61
200/250 Hour Service 63
500 Hour Service 64
1000 Hour Service 73
Removing the Hood 74
Removing the Grille 74
Cylinder Head Tightening 75
Fuses 75
Alternator 76
Battery 76
SAE Seven Point Connector Plug 77
Wiring Diagrams 78

MidWestTech | Case 1410 Tractor Operator's Manual | Publication 9-5418 Order the manual at mid-west-tech.com >