# W20B Articulated Loader

## Operators Manual

**9-6002**

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W20B Articulated Loader Operator's Manual | Publication 9-6002

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


**Introduction** ..... 2
- Safety ..... 4
- Spark Arresting System ..... 17
- Roll-Over Protective Structure . 18
- Location of PIN Number and Serial Numbers ..... 22

**Specifications** ..... 23

**Operating Instructions** ..... 28
- Instruments and Controls ..... 28
- Loader Controls ..... 40
- Engine Operation ..... 45
  - Walk-Around Checks Before Starting ..... 46
  - Starting the Engine ..... 47, 48
  - Stopping the Engine ..... 49
- Machine Operation ..... 53
- Transmission Controls ..... 53
- Auxiliary Steering ..... 54
- Stopping ..... 55
- Towing ..... 55
- Transporting the Machine ..... 56
- Cold Weather Operation ..... 59
- Hot Weather Operation ..... 60
- Loader Operation ..... 61
  - Loading and Dumping the Bucket ..... 62
  - Return-To-Dig ..... 63
  - Bucket Height Control ..... 64
  - Clutch Cutout ..... 64

**Fuels and Lubricants** ..... 66
- Diesel Fuel ..... 66
- Fuel, Fluids and Lubricants Chart ..... 67

**Maintenance/Lubrication** ..... 68
- Introduction ..... 68
- Run-In Maintenance Chart ..... 69
- Scheduled Maintenance Chart . 69
- Safety Before You Do Service . 72
- Transport/Service Link ..... 73
- Grease Fittings ..... 74
- Engine Lubrication System ..... 76
- Engine Air Cleaning System ... 79
- Engine Cooling System ..... 84
- Drive Belts ..... 86
- Fuel System ..... 89
- Electrical System ..... 95
- Equipment and Steering Hydraulic System ..... 104
- Braking System ..... 106
- Transmission Hydraulic System ..... 109
- Axles ..... 112
- Wheels and Tires ..... 114
- Loader Service ..... 116
  - Return-To-Dig Adjustment . 116
  - Bucket Height Control Adjustment ..... 116
  - Bucket Teeth ..... 118
- Cold Start Aid ..... 119
- ROPS Cab and Air Conditioner ..... 120
- Seat Belts ..... 123
- Machine Storage ..... 128
- Removal From Storage ..... 129
- Spark Arrester Muffler ..... 131
- After Delivery Check ..... 133




MidWestTech | Case W20B Articulated Loader Operator's Manual | Publication 9-6002 Order the manual at mid-west-tech.com >