W24C Loader

Operators Manual

9-6123

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W24C Loader Operator's Manual | Publication 9-6123

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To The Owner 2
After Delivery Check 3
Safety 4
Before You Start the Engine 4
Machine Operation 8
Stopping the Machine 12
Service 13
ROPS Safety Precautions 18
Spark Arrester 19
Slow Moving Vehicle Emblem 19
Operating Instructions 20
Instruments and Controls 20
Optional Gauges 27
Cab Controls 28
Operators Seat 30
Standard Seat 30
Optional Suspension Seat 30
Lift Arm and Bucket Controls 31
Bucket Control Lever 31
Bucket Level Indicator 31
Lift Arm Control Lever 31
Bucket Height Control 31
Return-To-Dig 32
Clam Control Lever 32
4-In-1 Bucket 32
Engine Operation 33
Service and Check Before Starting Engine 33
Run-In Period for a New Engine 34
Starting the Engine 34
Stopping the Engine 35
Starting Aids 36
Machine Operation 39
Transmission Speeds 39
Operating the Machine 40
Stopping the Machine 40
Loader Operation 41
Clutch Cutout 41
Bucket Height Control 41
Return-To-Dig 41
Towing the Machine 43
Procedure to Transport the Machine 44
Maintenance and Lubrication 45
Safety Before You Service the Machine . . . 45
Safety Decals on the Machine 46
Do Not Operate Tag 46
Transport/Service Link 46
Systemgard Service 46
Fluids and Lubricants Chart 47
Run-In Maintenance Chart 48
Regular Maintenance Chart 48
Grease Fittings 51
Air Cleaner System 52
Restriction Indicator 52
Air Cleaner Service 52
Primary Filter Element 52
Secondary Filter Element 53
Engine Lubrication System 54
Oil Level 54
Oil Change 54
Oil Filter 55
Engine Cooling System 56
Coolant Level 56
Coolant 56
Cleaning the Cooling System 56
Fuel System 58
Checking for Water or Sediment 58
Replacing Fuel Filters 58
Electric Fuel Pump Filter 59
Fuel Filler Screen 60
Removing Air From the Fuel System 60
Hydraulic System 62
All Machines Before PIN 9143772 62
Oil Level 62
Filter and Oil Change 62
Machines with PIN 9143772 and After . . . 63
Oil Level 63
Adding Oil to the Reservoir 64
Oil Filters 64
Checking Oil Filters 65
Replacing Oil Filters 65
Oil Change 66
Transmission 67
Oil Level 67
Oil Filter 68
Oil Change 69
Drive Belts 70
Checking Belt Tension 70
Adjusting Belt Tension 70
Brake System 72
Air Reservoir 72
Air Compressor 72
Brake Fluid Level 72
Disc Brakes 72
Axles 73,74
Oil Level 73,74
Oil Change 73,74
Electrical System 75
Before You Service the Electrical System 75
Fluid Level of the Batteries 75
Cleaning the Batteries 76
Rotating Beacon 76,77
Lamps 77
Cab and Canopy 78
General Maintenance 78
Air Conditioner 79
Loader Service 80
Return-To-Dig Adjustment 80
Bucket Height Control Adjustment 81
Wheels and Tires 82
Wheel Nut Torque 82
Adding Air to the Tires 82
Tire or Rim Service/Inflating the Tire 83
Installing Tires 83
Alcohol Evaporator 84
Spark Arrester Muffler 85
Machine Storage 85
Removal From Storage 86
Roll-Over Protection Structure (ROPS) 87
Possible Damage to the ROPS 88
Maintenance and Inspection of the ROPS 88
Torque Specifications 89
ROPS Cab and ROPS Canopy 89
Seats and Seat Belts 90
Specifications 91
Engine 91
Capacities 91
Operating Weight 91
Electrical System 92
Travel Speeds 92
Tire Air Pressures 92
Loader Buckets 93
Loader Operating Data and Dimensions . . . 93
Diesel Fuel 94
Fuel Storage 94
Location of Product Identification Number (PIN) and Serial Numbers 95
Product Identification Number 95
Serial Numbers and Part Number 96
After Delivery Check 97

MidWestTech | Case W24C Loader Operator's Manual | Publication 9-6123 Order the manual at mid-west-tech.com >