680G Loader Backhoe

Operators Manual

9-6532

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 680G Loader Backhoe Operator's Manual | Publication 9-6532

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
Delivery of the New Machine 3
After Delivery Check 3
Safety 4
Safety Rules 4
Spark Arrester 24
Rollover Protective Structure 24
Location of (PIN) and Serial Numbers 29
Specifications 30
Instructions for Operation of the Machine 42
Instruments and Controls 42
Left Instrument Panel 43
Right Instrument Panel 46
Transmission Controls and Foot Pedals 48
Seat for the Operator 49
Cab Controls 50
Turn Signal and Flasher Control 53
Clutch Cutout 53
Cold Start Button 54
Engine Warning Light and Hand Throttle 54
Loader 56
Control Levers 56
Bucket Level Indicator 57
Return-To-Dig 57
Control Lever for Auxiliary Attachment 58
Position Indicator for 4-In-1 Bucket 58
Clam Indicator for 4-In-1 Bucket 58
Backhoe Controls 61, 62
Extendahoe Controls 63, 64
Engine Operation 65
First Period of Operation With a New Engine 65
Service and Checks Before You Start 66
Procedure to Start the Engine 67
Engine Speed 68
Procedure to Stop the Engine 68
Assistance When You Start the Engine 69
Machine Operation 74
Procedure to Operate the Machine 74
Procedure to Move a Disabled Machine 77
Procedure to Transport the Machine 80
When You Operate During Cold Temperatures 83
When You Operate During Hot Temperatures 83
Loader Operation 84
Safety When You Work 84
Engine Speed and Transmission Speed Control 85
Clutch Cutout 85
Preparation for the Job 86
Loose Material 86
Flat Ground 88
Return-To-Dig 89
Backhoe Operation 90
Safety When You Work 90
General 91
Stabilizer Pads 91
Digging Positions for the Backhoe Bucket 92
Procedure to Position Machine Before You Dig 92
Procedure to Put Backhoe in the Operating Position 93
Procedure to Dig With the Backhoe 94
Procedure to Move Machine Forward - Level Ground 96
Procedure to Move Machine Forward - On a Hill 97
Extendahoe 98
Procedure to Dig Next to a Fence or Building 98
Frost Tooth 99
Procedure to Put Backhoe Into the Transport Position 100
Fuels and Lubricants 103
Diesel Fuel 103
Fuel Specifications 103
Fuel Storage 103
Fuel, Fluids and Lubricants Chart 104
Maintenance and Lubrication 105
Introduction 105
Maintenance Chart for the First Period of Operation With a New Machine 106
Maintenance Chart for Regular Intervals 106
Safety Before Servicing 108
Safety Decals on the Machine 109
Grease Fittings 110
Engine Lubrication System 113
Oil Level 113
Oil Change 113
Engine Oil Filter 114
Air Cleaner System 115
Restriction Indicator 115
Dust Valve 115
Filter Service 117
Engine Cooling System 120
Coolant Level 120
Ethylene Glycol Coolant 120
Water Coolant 121
Procedure to Clean the System 121
Fuel System 123
Fuel Tank 123
Sediment Bowl for the Transfer Pump 125
Fuel Filters 126
Procedure to Remove Air from the Fuel System 127
Electrical System 129
Lights 129
Alternator 131
Battery 132
Auxiliary Batteries 136
Hydraulic System 137
Oil Level 137
Oil Change, Filter and Screen Service 138
Brake System 140
Air Compressor 140
Air Reservoir 140
Alcohol Evaporator 141
Power Shuttle Transmission 142
Oil Level 142
Oil Change 143
Four Speed Transmission 144
Oil Level 144
Oil Change 145
Rear Axle 146
Oil Level 146
Oil Change 147
Wheels and Tires 148
Front Wheel Bearings 150
Drive Belts 152
Loader Service 157
Backhoe Service 159
ROPS Cab Service 161
Seat Belts 161
Spark Arrester Muffler 162
Procedure to Store the Machine 163
Procedure to Put Machine in Operation Again 165
After Delivery Check 166

MidWestTech | Case 680G Loader Backhoe Operator's Manual | Publication 9-6532 Order the manual at mid-west-tech.com >