W3
Wheel Tractor

Service Manual

9-70451

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

SECTION I

SPLITTING TRACTOR

AND

TRACTOR SPECIFICATIONS & LUBRICATION

TABLE OF CONTENTS

	PAGE
GROUP A — TRACTOR SPECIFICATIONS	I-3
1. SPECIFICATIONS	I-3
2. TRACTOR SERIAL NUMBER LOCATION	I-4
3. ENGINE LUBRICATION	I-4
4. TRACTOR LUBRICATION	I-8
5. FUEL SPECIFICATIONS (GASOLINE)	I-15
6. FUEL SPECIFICATIONS (DIESEL)	I-15
GROUP B — SPLITTING TRACTOR	I-20
1. REMOVING BACKHOE	I-20
2. REMOVING LOADER	I-22
3. TOOLS FOR SPLITTING TRACTOR	I-24
4. TRACTOR SHROUD, HOOD, ETC.	I-28
5. SPLITTING TRACTOR AT FRONT OF TRANSMISSION	I-29
6. SPLITTING TRACTOR AT REAR OF ENGINE	I-32
7. SPLITTING TRACTOR AT FRONT OF ENGINE	I-36
8. FUEL TANK	I-41
9. REAR FENDERS AND STEP PLATES	I-43

MidWestTech | Case W3 WheelTractor Service Manual | Publication 9-70451 Order the manual at mid-west-tech.com >