Service Manual

JS 210 LC

110026 On

PUBLISHED BY THE
PRODUCT SUPPORT DEPARTMENT
OF JCB SERVICE :
23/7, MATHURA ROAD,
BALLABHGARH, FARIDABAD
TEL. : 0129-4299000
Part No. : 9803/6510

General Information 1
Care & Safety 2
Routine Maintenance 3
Attachments A
Body & Framework B
Electrics C
Hydraulics E
Transmission F
Brakes G
Track & Running Gear J
Engine K

MidWestTech | JCB JS 210 LC Hydraulic Excavator Service Manual | Publication 9803-651... Order the manual at mid-west-tech.com >

CONTENTS	PAGE NO.
Machine Identification Plate	1 - 1
Typical Vehicle Identification Number (VIN)	1 - 1
Typical Engine Identification Number	1 - 1
Torque Settings	2 - 1
Service Tools	
- Body and Frame	4 - 1
- Electrics	4 - 3
- Hydraulics	4 - 6
- Transmission	4 - 14
Sealing and Retaining Compounds	5 - 1

MidWestTech | JCB JS 210 LC Hydraulic Excavator Service Manual | Publication 9803... Order the manual at mid-west-tech.com >

CONTENTS	PAGE NO.
Safety Notices	1 - 1
General Safety	1 - 1
Operating Safety	1 - 3
Maintenance Safety	1 - 5
Safety Decals	1 - 7

MidWestTech | JCB JS 210 LC Hydraulic Excavator Service Manual | Publication 9803... Order the manual at mid-west-tech.com >

i i

Contents **Page No.**

Identification of Machine Components 1 - 1

Lubricants - Health and Safety
- Hygiene 2 - 1
- Storage 2 - 1
- Handling 2 - 1
- First Aid - Oil 2 - 1
- Spillage 2 - 1
- Fires 2 - 1

Service Capacities and Lubricants 3 - 1

Service Schedules 3 - 2

Checking for Damage 4 - 1

Cleaning the Machine 4 - 1

Daily Checks 5 - 1

Greasing 6 - 1


Fuel System
- Types of fuels 7 - 1
- Filling Tank and Check Fuel Level 7 - 1
- Changing Fuel Filter Element 7 - 2
- * Cleaning Lift Pump Strainer 7 - 2
- Draing Fuel Tank Impurites 7 - 3
- Draining Sediment Bowl 7 - 3
- Bleeding the Fuel System 7 - 4

Engine
- Changing the Oil and Filter 8 - 1
- Checking Oil Level 8 - 1
- Changing the Air Filter 8 - 2
- Adjustment/Changing Fan Belt 8 - 4
- Checking Coolant Level 8 - 6
- Cleaning the Radiator and Oil Cooler 8 - 6
- Changing Coolant 8 - 7

Hydraulic System
- Checking the Hydraulic Fluid Level 9 - 1
- Releasing Tank Pressure 9 - 2
- Topping-up Fluid Level 9 - 2
- Changing the Hydraulic Fluid 9 - 3
- Draining Water and Sediement from the Hydraulic Tank 9 - 4
- Cleaning/Changing Suction Strainer 9 - 4
- Changing the Return Filter 9 - 5
- Changing the Plexus Filter 9 - 5
- Changing the Air Breather Element 9 - 6
- Changing the Servo Oil Filter (Pilot) 9 - 7
- Changing the Breaker In-line Filter 9 - 7
- Changing the Drain Line Filter 9 - 8
- Air Bleeding from Hydraulic Pump
- Air Bleeding from Rams 9 - 9
- Air Bleeding from Slew Motor 9 - 9

MidWestTech | JCB JS 210 LC Hydraulic Excavator Service Manual | Publication 9803... Order the manual at mid-west-tech.com >

Changing the Drain Line Filter



1 **Prepare the Machine**
Position the machine on level ground. Stop the engine. Remove the starter key.

2 **Release Tank Pressure**
(see **Releasing Tank Pressure).**

3 **Locate the Filter**

4 **Remove the Oil Filter**
Unscrew and remove filter A from head B.


5 **Fit the New Filter**
Coat the seal of the new filter with clean hydraulic fluid. Screw the new filter into head B and tighten. Check and top up the hydraulic fluid level.

Air Bleeding Procedures

After replacing the hydraulic oil or repairing or replacing hydraulic components or removing hydraulic pipes, bleed air from the hydraulic circuit.

Bleeding Air from the Hydraulic Pump

If the air is not completely bled, damage could occur within the pump.



1 **Prepare the Machine**
Position the machine on level ground. Stop the engine. Remove the starter key.

2 **Locate the Hydraulic Pump**

3 Temporarily loosen the air bleeding plug **C** to check that oil does not come out of the plug.


4 If oil comes out re-tighten the plug, if it does not come out remove the air bleeding plug C and pour hydraulic oil into the pump case through the air bleeding port until the pump body is full. Retighten the bleed plug.

5 Run the machine at idle for five minutes.

MidWestTech | JCB JS 210 LC Hydraulic Excavator Service Manual | Publication 9803... Order the manual at mid-west-tech.com >

Dig Depth Chart

Long reach(LR)



Working Dimensions

Machine fitted with 15 m long reach boom and dipper.

A	Maximum reach (ground level)	15.49 m (50 ft 10 in)
B	Maximum reach (@ 4 m depth)	14.4 m (47 ft 3 in)

MidWestTech | JCB JS 210 LC Hydraulic Excavator Service Manual | Publication 9803... Order the manual at mid-west-tech.com >

Contents **Page No.**

Basic System Operation cont'd
Service Required Warning 5 - 81
EMS Set Menu. 5 - 83
EMS Set + Mode (5 Sec) Menu. 5 - 84
EMS Set+Mode (20 sec) Menu. 5 - 86

Fault Finding
JCB Service Master Diagnostic Tool
JCB Service Master 9 - 1
Using Service Master 9 - 1
Selecting Sevice Tool Applications 9 - 1
System Menus 9 - 2
HP Setup Overview 9 - 3
Using HP Setup 9 - 3
Connecting the Data Link Adatptor 9 - 4
Starting HPSetup 9 - 4
Data Link Adaptor 9 - 9
HP Data Logs 9 - 10
Flash Programming Aplication 9 - 20
Introduction to the Diagnostics Tool 10 - 1
Connecting to the Vehicle 10 - 2
Starting Diagnostic Mode 10 - 2
Circuit Diagrams 10 - 3
Indicator Lights (LEDs) 10 - 3
Stopping Diagnostic Mode 10 - 4
Language Setting 10 - 4
List of Text Messages Displayed on the EMS 10 - 5
Fault Finding Without using the JCB Service Master
-Diagnostic Tool 10 - 8

Service Procedures
Electrical Testing Methods 19 - 1
Using a Multimeter 19 - 1
- Measuring DC Voltage 19 - 3
- Measuring Resistance 19 -3
- Measuring Continuty 19 -3
- Testing a Diode 19-3
Testing of ECU (Electronic Control Unit) 20 - 1
-Inputs and Outputs 20 - 2
Wiring Harness
Repair Procedure 23 - 1
Battery 24 - 1

Harness Data
Harness Location and Interconnection 150 - 1
Main Harness Connector Location 150 - 2
Main Harness: Key to Connectors 150 - 3
Main Harness Drawings 150 - 4
Main Harness Data 150 - 8
Facia Link Harness Connector Location 150 - 10
Facia Link Harness: Key to Connectors 150 - 10
Facia Link Harness Drawings 150 - 12
Facia Link Harness Data 150 - 14
Cab Harness Connector Location 150 - 15

MidWestTech | JCB JS 210 LC Hydraulic Excavator Service Manual | Publication 9803... Order the manual at mid-west-tech.com >