Service Manual

FASTRAC 1115, 1115S, 1125 & 1135

PUBLISHED BY THE
TECHNICAL PUBLICATIONS DEPARTMENT
OF JCB SERVICE: ©
ROCESTER, STAFFORDSHIRE, ST14 5LS,
ENGLAND
Tel. ROCESTER (01889) 590312
PRINTED IN ENGLAND

Publication No. 9803/8010

General Information 1
Care & Safety 2
Routine Maintenance 3
Optional Equipment A
Body & Framework B
Electrics C
Controls D
Hydraulics E
Transmission F
Brakes G
Steering H
Suspension S
Engine T

MidWestTech | JCB Fastrac 1115, 1115S, 1125, 1135 Tractor Service Manual | Publication... Order the manual at mid-west-tech.com >

Contents

	Page No.
Serial Number Plate	1 - 1
Typical Vehicle Identification Number (VIN)	1 - 1
Typical Engine Identification Number	1 - 1
Unit Identification	1 - 1
Torque Settings	2 - 1
Sealing and Retaining Compounds	3 - 1
Service Tools Numerical List	4 - 1
Service Tools	
Body and Framework	5 - 1
Electrics	6 - 1
Hydraulics	7 - 1
Transmission	8 - 1
* Brakes	8 - 4
Steering	8 - 5
Suspension	8 - 5
Engine	8 - 5
Moving a Disabled Machine	10 - 1
Preparation for Towing	10 - 1
Transporting the Machine	10 - 2

MidWestTech | JCB Fastrac 1115, 1115S, 1125, 1135 Tractor Service Manual | Publica... Order the manual at mid-west-tech.com >

Sectional Diagrams Component Key

1 Battery
2 Ignition Switch
3 Starter Motor
4 Alternator
5 Trailer ABS Socket
6 Auxiliary Socket
7 Inhibit Start Relay 1
8 Inhibit Start Relay 2
9 Starter Solenoid
10 Clutch Start Microswitch
11 Front PTO Switch
12 Rear PTO Switch
13 Right Hand Brake Light
14 Left Hand Brake Light
15 Trailer Socket, Brake Light
16 Brake Light Switch
17 Front Brakes Hydraulic Pressure Switch (Machines to No. 737000)
18 Rear Brakes Hydraulic Pressure Switch (Machines to No. 737000)
19 Rear Washer Motor
20 Rear Wiper Motor
21 Rear Wash/Wipe Switch
22 Air Conditioning Relay
23 Rear Wiper Intermittent Relay
24 Front Washer Motor
25 Front Washer Switch
26 Horn Push
27 Horn
28 Front Wiper Motor
29 Front Wiper Intermittent Relay
30 Front Wiper Switch
31 Engine Shut Off Solenoid (ESOS)
32 Powersplit Relay 1 (High)
33 Powersplit Relay 2 (Low)
34 Powersplit 'H' (High) Light
35 Powersplit 'L' (Low) Light
36 Diode Connector
37 Neutral Dump Relay (H1)
38 Powersplit High Button
39 Powersplit Low Button
40 Powersplit High Solenoid
41 Powersplit Neutral Solenoid
42 Neutral Dump Relay Base
43 4WD Engaged Light Relay
44 4WD Indicator Light
45 Diode
46 2-Wheel Drive/Differential Lock Switch
47 2-Wheel Drive Solenoid
48 Differential Lock Solenoid
49 Rear PTO Brake Solenoid
50 Front PTO Brake Solenoid
51 Rear PTO Drive Solenoid
52 Front PTO Drive Solenoid
53 2-Wheel Drive Dump Relay
54 Tachograph
55 Beacon Switch
56 Radio (Optional)
57 Interior Light RH
58 Interior Light LH
59 Digital Clock
60 Beacon Socket
61 Left Hand Door Switch
62 Hazard Switch
63 Single Trailer Turn Relay
64 Second Trailer Direction Indicator Warning Light
65 Direction Indicator Switch
66 Trailer Socket, LH Indicator
67 Trailer Socket, RH Indicator
68 Trailer Socket, Battery Negative
69 LH Direction Indicator, Rear
70 RH Direction Indicator, Rear
71 Second Trailer Turn Relay
72 RH Direction Indicator, Front
73 LH Direction Indicator, Front
74 Front Work Light Switch
75 Front Work Light Relay
76 RH Front Work Light, Outer
77 RH Front Work Light, Inner
78 LH Front Work Light, Inner
79 LH Front Work Light, Outer
80 Rear Work Light Switch
81 Rear Work Light Relay
82 Rear Work Light 1
83 Rear Work Light 2
84 Rear Work Light 3
85 Rear Work Light 4
86 Road Lights Switch
87 Fog Light Switch
88 Head Light Flasher
89 Dip Switch
90 Instrument Cluster
91 Main Beam Warning Light
92 Left Hand Headlamp
93 Right Hand Headlamp
94 Trailer Socket, Fog Light
95 LH Rear Fog Light
96 RH Rear Fog Light
97 Auxiliary Head Light Connector
98 Cigar Lighter Illumination
99 Speedometer Illumination
100 Air Tank Gauge Illumination
101 Trailer Socket, LH Side Light
102 Rear Left Hand Side Light
103 LH Side Light
104 Trailer Socket, RH Side Light
105 Rear Right Hand Side Light
106 LH Number Plate Light
107 RH Side Light
108 Auxiliary Head Light Switch
108A Auxiliary Headlights - Main Beam Relay
108B Auxiliary Headlights - Dipped Beam Relay
109 Auxiliary Head Light Connectors LH
110 Auxiliary Head Light Connectors RH
111 Left Hand Speaker (Optional)
112 Right Hand Speaker (Optional)
113 Clutch Relay - Air Conditioning Compressor
114 Compressor
115 Low Pressure Switch
116 High Pressure Switch
117 Clutch - Air Conditioning Compressor
118 Blower Switch - Air Conditioning/Heater
119 Air Conditioning Switch
120 Left Hand Reversing Light
121 Right Hand Reversing Light
122 Reversing Light Switch
122A Reversing Lights Relay
123 Thermostart
124 Speedometer
125 Speedometer Transducer
126 Lights Switch Illumination
127 Cigar Lighter
128 Transmission Warning Light
129 Buzzer (Service Malfunction)
130 Time Delay Relay (for item 128)
131 Transmission Oil Pressure Switch
132 Test Button
133 Hourmeter
134 Panel Light 1
135 Panel Light 2
136 Water Temperature Sender
137 Low Air Tank Switch
138 Fuel Level Sender
139 Blocked Air Filter Switch
140 Transmission Oil Filter Switch
141 Engine Oil Pressure Switch
142 Tachometer
143 Handbrake Switch
144 Selectronic - Reverse Selected Indicator
145 Selectronic - Low Selected Indicator
146 Selectronic - Medium Selected Indicator
147 Selectronic - High Selected Indicator
148 Selectronic - Bypass for unused Clutch Switch
149 Selectronic - Speedometer Output Signals (>3 kph, >1 kph)
150 Selectronic - Neutral Solenoids Connector
151 Selectronic - Range Select Solenoids Connector
152 Selectronic Column Switch
153 Selectronic - Range Select Relays (R, L, M, H,)
154 Selectronic - Speed Inhibit Relay
155 Selectronic Cylinder, Reverse/Low (shown in neutral)
156 Selectronic Cylinder, High/Medium (shown in neutral)
157 Selectronic - Buzzer/Timer Latching Relay (PR5)
158 Selectronic - Buzzer Earth Relay (PR15)
159 Selectronic - Neutral Dump Latch Relay (H3)
160 Selectronic - Buzzer/Timer Unit
161 Selectronic - Neutral Select Relay (PR18)
162 Selectronic - Anti-surge Relay (PR16)
163 Trailer Socket IGN & Battery Feeds
164 Area Cut-out
165 Area Cut-out Selection Switch
166 Lower Signal Switch
167 Differential Lock Cut-out Relay
168 Differential Lock Cut-out Switch
169 7-pin Trailer Socket
170 13-pin Trailer Socket
172 Speedometer Output Signal (<20 kph)
173 Trailer ABS Socket
174 ABS Warning Light
175 Clutch Warning Relay
176 Clutch Warning Delay Relay
177 Clutch Warning Buzzer
178 Switch - Foot-on-Clutch Warning
179 Cold Advance Switch (Machines from No. 737001)
180 Waxstat (Machines from No. 737001)
181 Air Tank No. 1
182 Air Tank No. 2
183 Front Brake Reservoir
184 Rear Brake Reservoir
185 Air Dryer

Contents

Page No.	Contents
12-1 & 12-1A	Supply Circuit
12-2	Earth Circuit
12-3	Fuse A1 - Neutral Start, Selectronic Range Change Solenoids Fuse C6 - Starter Solenoid
12-4 & 12-4A	Fuse A2 - Brake Lights
12-5	Fuse A3 - Rear Wash/Wipe, Air Conditioning Relay
12-6	Fuse A4 - Front Wash/Wipe, Horn
12-7	Fuse A4 (cont'd) - Front Wiper
12-8 & 12-8A	Fuse A5 - Engine Shut-off Solenoid (ESOS)
12-8B	Four Wheel Steer (4WS) Control Circuit (if fitted)
12-9	Fuse A6 - Electronic Draft Control System - Ingition Feed Fuse C9 - Electronic Draft Control System - Battery Feed
12-10	Fuses A6/C9 - Electronic Draft Control System (cont'd)
12-11	Fuse A7 - Powersplit and Neutral Dump
12-12	Fuse A8 - Front PTO, Rear PTO, 2/4 WD & Diff Lock Solenoids, 4WD Engaged Light Relay, and Light
12-13	Fuse A9 - Feeds to Speedometer, Tachograph and Selectronic Ingition Fuse B8 - Tachograph Battery Feed, Selectronic Range Change Anti-surge
12-13A	Clutch Warning Buzzer
12-14	Fuse B1 - Radio/Cassette Memory, Beacon, Interior Lights & Digital Clock
12 - 15	Fuse B2 - Hazard Warning Lights. Fuse C2 - Direction Indicators
12-16	Fuse B3 - Front Working Lights
12-17	Fuse B4 - Rear Working Lights
12-18	Fuse B5 - Head Light Flash. Fuse W (Maxifuse) - Road Lights
12-19 & 12-19A	Fuse D1 - Main Beam. Fuse D2 - Dipped Beam
12-20	Fuse D3 - Rear Fog Lights
12-21	Fuse D4 - LH Side Lights, Panel Illumination, LH Marker Lights
12-22	Fuse D5 - RH Side Lights, Number Plate Light, RH Marker Lights
12-23	Fuse D6 - Auxiliary Light Switching (Optional)
12-24	Fuse B6 - Radio Cassette
12-25	Fuse B7 - Auxiliary Socket
12-26	Fuse B9 - Air Conditioning Controls
12-27 & 12-27A	Fuse C1 - Reverse Lights
12-28	Fuse C3 - Thermostart
12-29 & 12-29A	Fuse C4 - Speedometer and Transducer, Lights Switch illumination, Buzzer, Transmission Oil Relay and Warning Light
12-30	Fuse C4 (cont'd) - Instrument Cluster (Panel)
12-31 & 12-31A	Fuse C4 (cont'd) - Instrument Cluster (Controls)
12-32	Fuse C4 (cont'd) - Park Brake Switch
12-33	Fuse C5 - JCB Selectronic
12-34	Fuse C5 (cont'd) - JCB Selectronic - Air Cylinders
12-35	Fuse C5 (cont'd) - JCB Selectonic - Buzzer & Timer
12-36	Fuse C5 (cont'd) - JCB Selectronic - Neutral Dump Latching
12-37	Fuse C7 - Trailer Socket, Ignition Feed Fuse C8 - Trailer Socket, Battery Feed
12-38	Area Meter Cut-out & Differential Lock Cut-out
12-39	Trailer Sockets
12-40 & 12-40A	Trailer ABS Socket
12 - 41	Fuses E2 & E3 - Air Dryer/Suspension Seat Circuits (Machines from No. 737001)

9803/8010
Issue 3

MidWestTech | JCB Fastrac 1115, 1115S, 1125, 1135 Tractor Service Manual | Publication 9803-8010
Order the manual at mid-west-tech.com >