680H Construction King Loader & Backhoe

Operators Manual

9-8041

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 680H Construction King Loader Backhoe Operator's Manual | Publicat... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
After Delivery Check 3
Right and Left Sides of the Machine 3
Safety 4
Safety Rules 4
Before You Start the Engine 5
Machine Operation 9
Loader Operation 13
Backhoe Operation 14
Stopping the Machine 16
Service 17
Spark Arrester 24
Roll-Over Protective Structure 25
Location of Product Identification Number and Serial Numbers 30
Specifications 32
Engine 32
Cooling System 32
Electrical System 32
Hydraulic System 32
Capacities 33
Tires 33
Travel Speeds 33
Operating Weights 33
Buckets 34
Loader Operating Data and Dimensions 35
Backhoe Operating Data and Dimensions 36-40
Operating Instructions 41
Fast Reference for Instruments and Controls 41
Instrument Cluster 44
Machine Controls 46
Cab Controls 51
Cab Control Settings and Air Flow 53
Cab Door and Door Windows 54
Rear Cab Windows 55
Operators Seat 57
Operators Seat Belt 58
Loader Controls 59
Backhoe Controls 66
Engine Operation 70
First Period of Operation with a New Engine 70
Service and Checks Before You Start 71
Starting the Engine 72
Engine Speed 73
Procedure to Stop the Engine 73
Methods to Help Start the Engine 74
Ether Starting Aid 74
Case Starting Fluid 77
Coolant Heater 78
Booster Battery 79
Machine Operation 81
Adjusting the Seat 81
Operating the Machine 82
Selecting Transmission Speeds and Machine Direction 82
Operating on a Hill 84
Procedure to Move a Disabled Machine 84
Procedure to Transport the Machine on a Trailer 87
Operating in Cold Temperatures 89
Operating in Hot Temperatures 89
Loader Operation 90
Safety When You Work 90
Clutch Cutout 91
Return-to-Dig 91
Preparation for the Job 92
Loose Material 92
Filling the Bucket 93
Backhoe Operation 94
Safety When You Work 94
General Information 94
Stabilizer Pads 95
Backhoe Bucket Digging Positions 95
Before You Dig with the Backhoe 96
Moving Backhoe out of Transport Position 97
Digging with the Backhoe 97
Procedure to Move the Machine Forward When You Are Digging 99
Digging Next to a Fence or Building 101
Lifting with the Backhoe 102
Frost Point 103
Procedure to Put the Backhoe in the Transport Position 104
Fuels and Lubricants 106
Diesel Engine 106
Diesel Fuel Specifications 106
Fuel Storage 106
Fuel, Fluids and Lubricants Chart 107
Maintenance and Lubrication 108
Introduction 108
Maintenance Chart for the First Period of Operation with a New Machine 109
Maintenance Chart for Regular Intervals 109
Safety Before Servicing 112
Grease Fittings 115
Engine Lubrication System 120
Air Cleaning System 123
Engine Cooling System 128
Fuel System 131
Electrical System 137
Battery Service 142
Hydraulic System 147
Transmission Hydraulic System 152
Rear Axle 155
Brake System 157
Wheels and Tires 160
Front Wheel Bearings 161
Drive Belts 163
Spark Arrester Muffler 166
Loader Service 167
Bucket Teeth 169
Cab Service 172
Procedure to Put the Machine in Storage 176
Procedure to Remove the Machine from Storage 178
After Delivery Check of a New Machine 179

MidWestTech | Case 680H Construction King Loader Backhoe Operator's Manual | Publicat... Order the manual at mid-west-tech.com >