AGCO POWER

Workshop Service Manual

5th Generation AWF Engines

8370 79873



MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manual |...

Order the manual at mid-west-tech.com >

1 Introduction . . . 1-1
- **1.1 Safety instructions** . . . 1-3
- **1.2 To the user** . . . 1-5
  - 1.2.1 Engine type designations . . . 1-5
  - 1.2.2 Location of the engine serial number . . . 1-6
  - 1.2.3 Marking of the engine control unit . . . 1-7
  - 1.2.4 Lifting the engine . . . 1-8
- **1.3 Engine construction** . . . 1-10
  - 1.3.1 Engine construction overview . . . 1-10
  - 1.3.2 Technical data . . . 1-10
  - 1.3.3 Cylinder block . . . 1-12
  - 1.3.4 Flywheel housing . . . 1-12
  - 1.3.5 Valve mechanism . . . 1-12
  - 1.3.6 Cylinder head . . . 1-13
  - 1.3.7 Crank mechanism . . . 1-13
  - 1.3.8 Timing gears . . . 1-13
  - 1.3.9 Lubrication system . . . 1-15
  - 1.3.10 Cooling system . . . 1-16
  - 1.3.11 Air control system . . . 1-17

2 Specifications . . . 2-1
- **2.1 Technical data** . . . 2-3
  - 2.1.1 Cylinder block . . . 2-3
  - 2.1.2 Cylinder liners . . . 2-4
  - 2.1.3 Cylinder head . . . 2-4
  - 2.1.4 Valves and rockers . . . 2-6
  - 2.1.5 Tappets and push rods . . . 2-7
  - 2.1.6 Camshaft . . . 2-7
  - 2.1.7 Crankshaft . . . 2-8
  - 2.1.8 Flywheel . . . 2-12
  - 2.1.9 Balancing unit . . . 2-12
  - 2.1.10 Timing gears . . . 2-13
  - 2.1.11 Connecting rod . . . 2-13
  - 2.1.12 Piston, rings and pin . . . 2-14
  - 2.1.13 Lubrication system . . . 2-16
  - 2.1.14 Oil pump . . . 2-16
  - 2.1.15 Thermostat . . . 2-18
  - 2.1.16 Turbocharger . . . 2-19
- **2.2 Tightening torques** . . . 2-20
- **2.3 Special tools** . . . 2-22
  - 2.3.1 Cylinder block tools . . . 2-22
  - 2.3.2 Timing gear and flywheel housing tools . . . 2-23
  - 2.3.3 Cylinder head and valve mechanism tools . . . 2-24
  - 2.3.4 Crank mechanism tools . . . 2-25
  - 2.3.5 Coolant pump tools . . . 2-26
  - 2.3.6 Engine control system and fuel system tools . . . 2-27

3 Maintenance . . . 3-1
- **3.1 Cylinder block** . . . 3-5
  - 3.1.1 Measuring cylinder liner wear . . . 3-5

MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manu... Order the manual at mid-west-tech.com >

3.1.2 Removing cylinder liner . . . 3-6
3.1.3 Checking cylinder block . . . 3-6
3.1.4 Changing camshaft bushing . . . 3-6
3.1.5 Changing camshaft bushing . . . 3-7
3.1.6 Fitting plug at camshaft rear end . . . 3-8
3.1.7 Oversize bushings for camshaft . . . 3-8
3.1.8 Fitting plug at camshaft rear end (oversize bushings) . . . 3-9
3.1.9 Fitting cylinder liner . . . 3-10
3.2 Flywheel housing . . . 3-14
3.2.1 Fitting flywheel housing . . . 3-14
3.2.2 Changing crankshaft rear oil seal . . . 3-14
3.3 Cylinder head . . . 3-16
3.3.1 Removing cylinder head . . . 3-16
3.3.2 Removing valves . . . 3-16
3.3.3 Checking cylinder head . . . 3-16
3.3.4 Changing valve guides . . . 3-18
3.3.5 Machining valve seat . . . 3-19
3.3.6 Changing valve seat rings . . . 3-19
3.3.7 Grinding valves . . . 3-20
3.3.8 Fitting valves . . . 3-21
3.3.9 Fitting cylinder head . . . 3-21
3.4 Valve mechanism . . . 3-23
3.4.1 Reconditioning valve mechanism . . . 3-23
3.4.2 Changing camshaft or camshaft gear . . . 3-24
3.4.3 Preparations for valve adjusting . . . 3-25
3.4.4 Adjusting valves . . . 3-26
3.5 Crankshaft . . . 3-29
3.5.1 Removing crankshaft . . . 3-29
3.5.2 Checking crankshaft . . . 3-29
3.5.3 Changing crankshaft gears . . . 3-30
3.5.4 Fitting crankshaft . . . 3-31
3.5.5 Crankshaft hub piece . . . 3-32
3.5.6 Viscose type vibration damper . . . 3-33
3.6 Connecting rods and pistons . . . 3-34
3.6.1 Removing pistons together with connecting rods . . . 3-34
3.6.2 Checking connecting rod . . . 3-34
3.6.3 Changing piston rings . . . 3-36
3.6.4 Checking pistons . . . 3-37
3.6.5 Fitting piston pin . . . 3-38
3.6.6 Fitting piston together with connecting rod . . . 3-38
3.7 Changing connecting rod bearings . . . 3-39
3.7.1 Piston pin bushing . . . 3-39
3.7.2 Big-end bearing . . . 3-40
3.8 Counterbalance in 4 cylinder engines . . . 3-41
3.8.1 Removing and disassembling counterbalance unit . . . 3-41
3.8.2 Reconditioning counterbalance unit . . . 3-41
3.8.3 Fitting counterbalance unit . . . 3-42
3.8.4 Changing crankshaft gear rim . . . 3-42
3.9 Flywheel . . . 3-44
3.9.1 Changing starter ring gear on flywheel . . . 3-44
3.9.2 Fitting flywheel . . . 3-44
3.10 Timing gear assembly . . . 3-46
3.10.1 Removing timing gear casing . . . 3-46
3.10.2 Fitting timing gear casing . . . 3-47
3.10.3 Fitting the crankshaft hub . . . 3-50

MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manu... Order the manual at mid-west-tech.com >

3.10.4 Power take-off . . . 3-51
3.10.5 Fan drive device . . . 3-52
3.11 Lubrication system . . . 3-53
3.11.1 Oil pressure regulating valve . . . 3-53
3.11.2 Removing and dismantling lubricating oil pump . . . 3-53
3.11.3 Assembling and fitting lubricating oil pump . . . 3-54
3.11.4 Piston cooling nozzles . . . 3-54
3.11.5 Fitting oil sump gasket . . . 3-55
3.11.6 Lubricating oil cooler . . . 3-56
3.11.7 Removing lubricating oil cooler . . . 3-56
3.11.8 Fitting lubricating oil cooler . . . 3-57
3.11.9 Lubricating oil quality requirements . . . 3-57
3.11.10 Oil sump capacity . . . 3-58
3.11.11 Closed crankcase ventilation . . . 3-58
3.12 Cooling system . . . 3-60
3.12.1 Coolant quality requirements . . . 3-60
3.12.2 Thermostat . . . 3-60
3.12.3 Reconditioning coolant pump . . . 3-62
3.12.4 Installing the cylinder head connection part . . . 3-67
3.13 Air control system maintenance . . . 3-69
3.13.1 Checking the air cleaner . . . 3-69
3.13.2 Checking the inlet and exhaust pipes . . . 3-69
3.13.3 Removing actuator of the high pressure turbocharger . . . 3-70
3.13.4 Fitting actuator of the high pressure turbocharger . . . 3-70
3.13.5 Removing the high pressure turbocharger . . . 3-70
3.13.6 Checking the turbocharger . . . 3-70
3.13.7 Fitting the high pressure turbocharger . . . 3-71
3.13.8 Removing the EGR system . . . 3-72
3.13.9 Fitting the EGR system . . . 3-72
3.13.10 Removing the EGR actuator . . . 3-72
3.13.11 Fitting the EGR actuator . . . 3-73
3.13.12 EGR link rod . . . 3-73
3.14 Fuel system . . . 3-74
3.14.1 Fuel system . . . 3-74
3.14.2 Technical data of the fuel system . . . 3-75
3.14.3 Bleeding the fuel system . . . 3-76
3.14.4 Measuring fuel feed pressure . . . 3-77
3.14.5 Inspecting injectors . . . 3-77
3.14.6 High-pressure pump . . . 3-79
3.14.7 Rail . . . 3-81
3.14.8 Fuel quality requirements . . . 3-84
3.14.9 SCR system . . . 3-87
3.15 Engine control system . . . 3-92
3.15.1 Service tool of the engine control system . . . 3-93
3.15.2 Electronic diagnostic tool . . . 3-94
3.15.3 Changing the electronic control unit . . . 3-96
3.15.4 Wiring sets . . . 3-98

5 Index . . . Index-1

MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manu... Order the manual at mid-west-tech.com >

3.11.10 Oil sump capacity

Number of cylinders	Oil sump partnumber	Minimum oil capacity	Maximum oil capacity
4 cylinders	8361 20641	9,5	11,5
	8361 28794	8,0	10,0
	8370 84513	13	17
	8361 29147	8,0	10,0
6 cylinders	8363 47308	20,0	25,5
	8363 36229	21,5	25,5
	8370 74007	17	22
	8370 84152	19	24
	8370 84394	16	19
	8368 73817	16	19
	8368 74808	17	20
	8368 84674	17	20
	8368 84621	16,8	19,5
	8368 73994	21	25
	8368 74002	20	24
	8368 73779	16,5	21,5
7 cylinders	8368 73028	27	33
	8368 74866	29,5	35,5

3.11.11 Closed crankcase ventilation

All 5th Generation engines have closed crankcase ventilation (CCV) with filtering of ventilation gases. This is to prevent oil and soot getting into engine air intake with ventilation gases. CCV system is maintenance-free. There are two different types of CCV system. There is a centrifugal-type filtering in the 84 and 98 engines, which is driven by engine oil pressure. There is a filter that uses a small part of boost pressure for filtration boosting in the 33, 44, 49, 66 and 74 engines.

Installing the closed crankcase ventilation system components

33 - 74 engines

MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manu... Order the manual at mid-west-tech.com >

3.13.3 Removing actuator of the high pressure turbocharger

Procedure

1. Remove cooling pipe and cooling pipe support of the actuator.
2. Remove the actuator from the turbocharger without removing the mounting bracket of the actuator from the turbocharger.

   NOTE: *Do not remove the link rod of the actuator.*

3.13.4 Fitting actuator of the high pressure turbocharger

Procedure

1. Fit the actuator to the turbocharger.
2. Fit the cooling pipe and the cooling pipe support.
3. Finally, remove the air from the cooling system by using the highest bleeding plug of the engine.

3.13.5 Removing the high pressure turbocharger

Procedure

1. Remove the inlet and exhaust pipes and pressure and return oil pipes from the turbocharger.
2. Untighten the clamp between the HP turbocharger and the intermediate piece of the turbochargers.
3. Remove the cooling pipes of the actuator and the actuator wire.
4. Remove the fixing nuts and remove the turbocharger.

3.13.6 Checking the turbocharger

If a fault is suspected in the turbocharger, it can be located in the following way:

Procedure

1. Visually inspect the turbine and compressor wheels. The vanes must not show any signs of damage, deformation or wear caused by foreign objects.
2. Investigate any oil leaks through the sealing rings on the shaft in the turbine and compressor housing.

   NOTE: *At low idling speed there is always a certain amount of oil leakage on the compressor side. However, this should not cause too much concern unless the oil consumption is too great.*




Fig. 99

MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manu... Order the manual at mid-west-tech.com >




Fig. 11

(1) Air filter
(2) Low pressure turbocharger
(3) Interstage charge air cooler (ICAC)
(4) Mass air flow (MAF) sensor
(5) High pressure turbocharger
(6) Engine radiator
(7) Air to air intercooler
(8) Air intake throttle
(9) Intake manifold

The air control system includes pre-filter (or cyclone, if installed), air filter, turbocharger(s), intercooler(s), air mass flow meter, throttle valve, intake manifold, exhaust manifold, EGR valve, EGR cooler and air pipes. A mechanical or electric sensor can be fitted to indicate the service point of the air filter. If the engine is operating in very dusty conditions (for example spreading lime) it must be equipped with a special pre-filter and oil bath air filter.

MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manu... Order the manual at mid-west-tech.com >




Fig. 115

The exhaust gas aftertreatment system used is Bosch DENOXTRONIC2.2 (DNOX2.2). DNOX2.2 uses SCR (Selective catalyst reduction) technology in order to reduce the exhaust emissions from the engine.

AGCO POWER SCR system consists of engine control system and DNOX2.2 SCR system. These two systems are connected together via CAN bus.

See instructions of the appliance for location and instructions for removing and installing the SCR system components.

Supply module

Supply Module (SM) transfers NOx reductant (DEF) from tank and pressurizes it. It contains also filters for reductant (prefilter and mainfilter).

Dosing module

Dosing module (DM) is installed in the exhaust pipe between turbocharger and SCR catalyst. DM contains an electrically operated, ECU controlled solenoid valve, which will inject the required amount of DEF through the DM nozzle. DEF amount is calculated by EEM4 for optimal reduction of NOx.

Sensors

DNOX2.2 system includes several sensors:

- NOx sensors
- Exhaust temperature sensors
- DEF tank level sensor
- Temperature sensors: DEF tank, Supply Module internal

MidWestTech | JCB Agco 33, 44, 49, 66, 74, 84, 98 5th Gen AWF Engine Service Manu... Order the manual at mid-west-tech.com >