OPERATOR'S MANUAL

LOADER BACKHOE

580G

9-8393 NA

Issued 01April 08

MidWestTech | Case 580G Loader Backhoe Operator's Manual | Publication 9-8393NA

Order the manual at mid-west-tech.com >

Table of contents

Fuels and lubricants 161
Diesel fuel 161
Fuel, fluids and lubricants chart .. 163
Fuel storage 162
Introduction 3
After delivery check 4
To the Owner 3
Location of product identification number 39
Location of serial numbers 40
Maintenance and lubrication 165
After delivery check of a new machine III
Air cleaning system 190
Brakes 234
Cab service 243
Drive belts 237
Electrical system 206
Engine cooling system 196
Engine lubrication system 186
Final drives 228
Front axle (four-wheel drive machine) 232
Fuel system 199
Grease fittings 173
Hydraulic system 218
Introduction 165
Loader adjustements 240
Maintenance chart for regular intervals 167
Master cylinder for backhoe Hydraulic boom latch 231
Power shuttle transmission 222
Procedure to put the machine in storage 247
Procedure to remove the machine from storage 249
Run-in maintenance chart 186
Safety before servicing 170
Spark arrester muffler 242
Steering hydraulic system 229
Wheels and tires 239
Operating instructions 67
Instrument and Control symbols .. 70
Instrument cluster 72
Instruments and Controls 67
Machine Controls 75
Cab controls 86
Clutch Disconnect 84
Control for the creeper gear box 84
Control for four-wheel drive 85
Differential lock 83
Direction Control and Hand throttle 78
Instrument Panel Controls 75
Parking Brake 82
Transmission control and Foot Pedals 80
Backhoe Controls 104
Engine Operation 109
Loader Controls 100
Operator's seat belt 99
Suspension seat 95
Engine speed 113
Methods to help start the engine in cold weather 114
Procedure to start the engine 112
Procedure to stop the engine 113
Run-in period of operation with a new engine 109
Service and checks before you start 110
Machine operation 117
Adjusting the seat 117
Beginning of operation 118
Differential lock 120
Operating in cold temperatures ... 124
Operating in hot temperatures 124
Operating on a hill 121
Procedure to move a disabled machine 122
Procedure to transport the machine 122
Selecting transaxle gears and machine direction 118
Loader operation 125
Clutch disconnect 126
Digging procedure 128
Return-to-dig 127
Safety when you work 125

MidWestTech | Case 580G Loader Backhoe Operator's Manual | Publication 9-8393NA Order the manual at mid-west-tech.com >

Backhoe operation 131
Backhoe bucket digging positions . 136
Backhoe removal and installation . 151
Before you dig with the backhoe . 136
Digging with the backhoe 142
Lifting with the backhoe 146
Moving the backhoe out of the transport position 138
Moving the sideshift backhoe to the right or left 140
Procedure to put the backhoe in the transport position 147
Safety when you work 131
Stabilizer Pads 133
Backhoe Operation 18
Before you start the engine 6
Loader Operation 17
Machine Operation 13
Safety rules 7
Service 23
Spark Arrester 30
Stopping the machine 22
Roll-over protective structure 32

MidWestTech | Case 580G Loader Backhoe Operator's Manual | Publication 9-8393NA Order the manual at mid-west-tech.com >