FH4

Operators Manual

9-8470

CASE CONSTRUCTION

MidWestTech | Case FH4 Trencher Loader Backhoe Operator's Manual | Publication 9-8470

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

INTRODUCTION TO THE OWNER iv

SAFETY v
- Safety Rules v
- Before Starting the Engine vi
- Operation viii
- Service xiii
- Roll-Over Protective Structure xviii
  - Seat Belt with ROPS xviii
  - Damage to the ROPS xviii
  - ROPS Maintenance and Inspection xviii
  - ROPS Safety Rules xviii
  - ROPS Torque Specifications xix

PRODUCT IDENTIFICATION NUMBER (PIN) AND SERIAL NUMBERS xx

SPECIFICATIONS 1
- Basic Machine 1
  - Dimensions 4
- Backhoe 5
  - Dimensions 6
- Loader 7
  - Dimensions 8

INTERNATIONAL SYMBOLS 9

OPERATION 10
- Instruments and Controls — 1.8 Litre Engine 10
  - Instruments 10
- Instruments and Controls — 2.1 Litre Engine 12
  - Instruments 12
  - Controls — Instrument Panel — 1.8 Litre Engine 14
  - Controls — Instrument Panel — 2.1 Litre Engine 16
  - Controls — Console and Steering Tower 20
- Seat Adjustment 21
- Operator's Seat Belt 21
- Safety Rules Before Starting the Engine 22
- Engine Operation 23
  - Engine Run-In 23
  - Engine Starting Procedure 24
  - Engine Temperature 25
  - Engine Speed 25
  - Engine Stopping Procedure 25
- Machine Direction and Speed Control 26
  - Transporting Speeds 26
  - Working Speeds 26
  - Putting the Machine on a Trailer 27
- Loader Operation 27
  - Controls 29
  - Preparing the Work Area 29
  - Bucket Level Indicator 30
  - Loading Loose Material 30
  - Bank Excavations 30
  - Flat Area Excavations 31
  - Carrying a Load 31
  - Dumping the Bucket 31
  - Truck Loading 31

MidWestTech | Case FH4 Trencher Loader Backhoe Operator's Manual | Publication 9-8470 Order the manual at mid-west-tech.com >

Backhoe Operation 32
Backhoe Transport Position 32
Backhoe Controls 33
Putting the Machine into Operation 36
Starting the Excavation 36
Filling the Bucket 37
Dump and Return Cycle 37
Tips for Digging with the Backhoe 37
Hot Weather Operation 37
Cold Weather Operation 38

FUELS, FLUIDS AND LUBRICANTS 39
Fuels 39
Diesel Fuel Specifications 39
Fuel Storage 39
Lubricants 41
Fuels, Fluids and Lubricants Chart 41

PREVENTIVE MAINTENANCE 42
Preventive Maintenance is Important 43
Regular Maintenance Intervals 43
Loader Arm Service Support 44
Articulation Lock 45
Service Points 46
Basic Machine 47
Backhoe 48
Loader 49
Engine 50
Engine Cooling System 50
Coolant Level 50
Antifreeze 50
Cleaning the Cooling System 51
Thermostat 51
Thermostat Removal — 1.8 Litre Engine 52
Thermostat Removal — 2.1 Litre Engine 52
Engine Lubrication System 53
Oil Level 53
Oil Change 54
Oil Filter 5
Engine Air Cleaner 54
Air Cleaner Service 55
Washing the Element 55
Cleaning the Element with an Air Hose 56
Inspecting the Element 56
Fuel System 56
Fuel Tank 57
Fuel Filter — 1.8 Litre Engine 57
Removing Air from the Fuel System — 1.8 Litre Engine 58
Fuel Filter — 2.1 Litre Engine 59
Removing Air from the Fuel System — 2.1 Litre Engine 60
Hydraulic System 61
Oil Level 62
Hydraulic Filter 62
Cartridge Filter Replacement 62
Oil Change 63
Front and Rear Axles 63
Oil Level 63
Oil Change 64

MidWestTech | Case FH4 Trencher Loader Backhoe Operator's Manual | Publication 9-8470 Order the manual at mid-west-tech.com >

Final Drive Gearbox 64
Oil Level 64
Oil Change 64
Electrical System 65
Battery Maintenance 65
Alternator System 65
Booster Battery 66
Wiring Diagram — 1.8 Litre Engine 67
Wiring Diagram — 2.1 Litre Engine 68
Adjustments 69
Fan Belt Adjustment — 1.8 Litre Engine 69
Fan Belt Adjustment — 2.1 Litre Engine 69
Parking Brake Adjustment 70
Fastener Inspection and Maintenance 71
Seat Belt Inspection and Maintenance 72

MACHINE STORAGE 73
Engine 73
Fuel System 73
Cooling System 73
Battery 73
Hydraulic Equipment 74
Removing the Machine from Storage 74

NOTES 75

NOTICE

Laws of some states or provinces may require that this machine be equipped with a SPARK ARRESTOR or SPARK ARRESTING MUFFLER. The State of California, as an example, is one state which has such regulations for agricultural and forestry applications, plus a regulation for construction applications in forest-covered, brush-covered, or grass-covered lands.

Typically such laws and regulations require spark arresting devices to be maintained in good working order and typically to be attached to the exhaust system of naturally aspirated engines (engines without a turbo charger).

MidWestTech | Case FH4 Trencher Loader Backhoe Operator's Manual | Publication 9-8470 Order the manual at mid-west-tech.com >