W18B/W20C Loader

Operators Manual

9-8701

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W18B, W20C Loader Operator's Manual | Publication 9-8701

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
After Delivery Check 3
Safety 4
Safety Rules 4
Before You Start the Engine .. 5
Machine Operation 8
Stopping the Machine 13
Service 14
Spark Arrester 20
Roll-Over Protective Structure 21
Location of Product Identification Number and Serial Numbers 25,26
Operating Instructions 27
Fast Reference for Instruments and Controls 27
Loader Lift Arm and Bucket Controls 28
Bucket Clam Control 28
Left Instrument Panel 29
Right Control Panel 31
Optional Gauges 34
Cab Controls 35
Operators Seat 37
Bucket Level Indicator 39
Bucket Height Control ..... 39,59, and 107
Return-To-Dig .. 40, 59, and 106
4-In-1 Selector Gauge 41
Alcohol Evaporator 41,112
Engine Operation 42
First Period of Operation with a New Engine 42
Service and Checks Before You Start 43
Starting the Engine 44
Engine Speed 45
Procedure to Stop the Engine 45
Starting Aids 46
Machine Operation 51
Adjusting the Seat 51
Operating the Machine 51
Transmission Speeds 51
Changing Machine Direction . 52
Operating on a Hill 52
Towing the Machine 53
Transporting the Machine 53
Operating in Cold Temperatures 55
Operating in Hot Temperatures 55
Slow Moving Vehicle Emblem 56
Loader Operation 57
Fuels and Lubricants 60
Diesel Fuel 60
Fuel Storage 60
Fuel, Fluids and Lubricants .. 61
Maintenance and Lubrication .. 62
Introduction 62
Run-In Maintenance Chart ... 63
Maintenance Chart for Regular Intervals ..... 63, 64, and 65
Safety Before You Do Service 66
Transport/Service Link 67
Safety Decals on the Machine 68
Do Not Operate Tag 68
Grease Fittings 69
Engine Lubrication System .. 71
Air Cleaner System 73
Engine Cooling system 77
Fuel system 79
Electrical System 85
Battery Service 87
Hydraulic System 89
Transmission Hydraulic System 94
Axles 98
Drive Belts 99
Brake System 101
Wheels and Tires 104
Loader Service and Adjustments 107
ROPS Cab and Air Conditioner . 109
Alcohol Evaporator 112
Machine Storage 113
Specifications 116
After Delivery Check 121

MidWestTech | Case W18B, W20C Loader Operator's Manual | Publication 9-8701 Order the manual at mid-west-tech.com >