1835B Uni-Loader

Operators Manual

9-8932

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 1835B Uni-Loader Operator's Manual | Publication 9-8932

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
Delivery of the New Machine 3
After Delivery Check 3
Right, Left, Front, and Rear 3
Safety 4
Safety Rules 4
Spark Arrester Muffler 17
Roll-Over Protective Structure 18
Location of Product Identification Number and Serial Numbers 21
Operating Instructions 24
Instruments and Controls (Fast Reference) 24
Instruments and Switches 26
Controls 28
Seat Belts 30
Engine Operation 32
Run-In Period of Operation with a New Engine 32
Service and Checks Before You Start 33
Engine Starting Procedure 34
Gasoline Engine 34
Diesel Engine 35
Engine Speeds 35
Procedure to Stop the Engine 36
Methods to Help Start the Engine 36
Machine Operation 41
Steering Controls 42
Stopping 43
Operating in Cold Temperatures 44
Operating in Hot Temperatures 44
Moving a Disabled Machine 45
Procedure to Transport the Machine 46
Loader Operation 47
Safety When You Work 47
Control for Loader Lift Arms 48
Control for Loader Bucket/Forks 49
Filling and Dumping the Bucket 50
Tool-Tach 51
Backhoe Operation 53
Seat Position and Adjustment 53
Hydraulic Power for the Backhoe 54
Backhoe Controls 55
Engine Speed 55
Before You Dig with the Backhoe 56
Digging with the Backhoe 56
Procedure to Move the Machine When You Dig 57
Lifting with the Backhoe 58
Removing the Backhoe 59
Installing the Backhoe 60
Fuels and Lubricants 62
Diesel Fuel 62
Gasoline 62
Fuel, Fluids and Lubricants Chart 63
Maintenance and Lubrication 64
Introduction 64
Run-In Maintenance Chart 65
Maintenance Chart for Regular Intervals 65
Safety Before Servicing 66
Procedure to Use the Support Strut 69
Procedure to Put the Support Strut in Storage 70
Safety Decals on the Machine 71
Do Not Operate Tag 71
Grease Fittings 72
Engine Lubrication System 75
Air Cleaner System 77
Engine Cooling System 80
Diesel Fuel System 82
Gasoline Fuel Filter 87
Electrical System 88
Lamps 88
Rules Before You Service the Electrical System 90
Battery 90
Equipment Hydraulic/Hydrostatic System 93
Drive Chains 96
Drive Chain Compartment 99
Drive Belt 100
Maintenance of the Seat Belt 102
Spark Arrester Muffler 102
Installing Wheels and Tires 102
Backhoe Teeth 103
Machine Storage 103
Removal from Storage 104
Specifications 105
After Delivery Checks 113

MidWestTech | Case 1835B Uni-Loader Operator's Manual | Publication 9-8932 Order the manual at mid-west-tech.com >