1845B Uni-Loader

Operators Manual

9-8941

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case 1845B Uni-Loader Operator's Manual | Publication 9-8941

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
Delivery of the New Machine 3
After Delivery Check 3
Right, Left, Front, and Rear 3
Safety 4
Safety Rules 4
Spark Arrester Muffler 16
Roll-Over Protective Structure 17
Location of Product Identification Number and Serial Numbers 20
Operating Instructions 23
Instruments and Controls (Fast Reference) 23
Instrument Panel 25
Controls 27
Seat Belts 29
Engine Operation 31
Run-In Period of Operation with a New Engine 31
Service and Checks Before You Start 32
Engine Starting Procedure 33
Gasoline Engine 33
Diesel Engine 34
Engine Speeds 34
Procedure to Stop the Engine 35
Methods to Help Start the Engine ... 35
Machine Operation 40
Starting 40
Steering Controls 41
Stopping 42
Operating in Cold Temperatures ... 43
Operating in Hot Temperatures 43
Moving a Disabled Machine 44
Procedure to Transport the Machine .. 45
Loader Operation 47
Safety When You Work 47
Control for Loader Lift Arms 48
Control for Loader Bucket/Forks ... 49
Filling and Dumping the Bucket 50
4-in-1 Bucket 50
Tool-Tach 52
Scarifier Operation 54
Depth Shoe Adjustment 54
Teeth Adjustment 54
Stop Pin Adjustment 54
Rear Counterweights 55
Backhoe Operation 56
Safety When You Work 56
Seat Position and Adjustment 57
Backhoe Controls 57
Engine Speed 58
Flow Control Valve 58
Before You Dig with the Backhoe ... 59
Digging with the Backhoe 61
Procedure to Move the Machine When You Dig 62
Lifting with the Backhoe 63
Removing the Backhoe 64
Installing the Backhoe 66
Fuels and Lubricants 67
Diesel Fuel 67
Gasoline 67
Fuel, Fluids and Lubricants Chart 68
Maintenance and Lubrication 69
Introduction 69
Run-In Maintenance Chart 70
Maintenance Chart for Regular Intervals 70
Safety Before Servicing 73
Procedure to Use the Support Strut .. 74
Procedure to Put the Support Strut in Storage 75
Safety Decals on the Machine 76
Do Not Operate Tag 76
Grease Fittings 77
Engine Lubrication System 81
Air Cleaner System 83
Engine Cooling System 88
Diesel Fuel System 90
Gasoline Fuel Filter 93
Electrical System 94
Lamps 94
Alternator 95
Battery 95
Equipment Hydraulic/Hydrostatic System 98
Gear Reducer 100
Drive Chains 102
Drive Chain Compartment 105
Drive Belt 106
Maintenance of the Seat Belt 107
Spark Arrester Muffler 108
Installing Wheels and Tires 108
Backhoe Teeth 109
Machine Storage 109
Removal from Storage 110
Specifications 111
After Delivery Checks ..... 121 & 123

MidWestTech | Case 1845B Uni-Loader Operator's Manual | Publication 9-8941 Order the manual at mid-west-tech.com >