W36

Articulated Loader

PIN 9143979 and After

Operators Manual

9-9530

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W36 Articulated Loader Operator's Manual | Publication 9-9530

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
Delivery of the New Machine 3
After Delivery Check 3
Right, Left, Front, and Rear 3
Safety 4
Before You Start the Engine 4
Machine Operation 8
Stopping the Machine 12
Service 13
ROPS Safety Precautions 18
Slow Moving Vehicle Emblem 19
Operation Instructions 20
Instruments and Controls 20
Cab Controls 27
Operators Seat 29
Operator's Seat Belt 30
Engine Operation 32
Service and Checks Before Starting the Engine 32
Run-In Period for a New Engine 33
Starting the Engine 33
Stopping the Engine 34
Starting Aids 35
Machine Operation 38
Operating in Hot Temperatures 38
Operating in Cold Temperatures 38
Transmission Speeds 38
Operating the Machine 39
Changing the Machine Direction 39
Operating on a Hill 39
Stopping the Machine 39
Loader Operation 40
Engine Speed 40
Clutch Cutout 40
Bucket Height Control 40
Loader Control Accumulator 40
Height Adjustment of Loader Controls . . . 40
Loader Controls 41
Bucket and Lift Arm Control 41
Auxiliary Attachment Control 42
Return-To-Dig 43
Loader Operating Tips 44
Towing the Machine 45
Transporting the Machine 46
Maintenance and Lubrication 47
Safety Before You Service the Machine 47
Safety Decals on the Machine 48
Do Not Operate Tag 48
Transport/Service Link 48
Fuel, Fluids, and Lubricants Chart 49
Run-In Maintenance Chart 50
Maintenance Chart for Regular Intervals . . . 50
Grease Fittings 53
Engine Lubrication System 55
Air Cleaner 57
Engine Cooling System 60
Fuel System 62
Hydraulic System (Before PIN 9144046) . . . 65
Hydraulic System (PIN 9144046 and After) 67
Electrical System 71
Transmission 74
Axles 77
Brake System 79
Drive Belts 82
Cab and Canopy 84
Loader Service 86
Wheels and Tires 87
Machine Storage 89
Removal From Storage 90
Roll-Over Protection Structure (ROPS) 91
Specifications 95
Engine 96
Capacities 95
Hydraulic System 96
Electrical System 96
Travel Speeds 96
Tire Air Pressures 96
Operation Data and Dimensions 97
Loader Buckets 98
Diesel Fuel 99
Location of Product Identification Number (PIN) and Serial Numbers 101
After Delivery Check 103

MidWestTech | Case W36 Articulated Loader Operator's Manual | Publication 9-9530 Order the manual at mid-west-tech.com >