CAT Lift Trucks

Operation & Maintenance Manual

MC

GP15N	CT25C-55001-59999	GPE15N	CT34-00001-09999	DP15N	CT16D-54001-59999
GP15ZN	CT34-52001-59999	GPE18N	CT34-40001-49999	DP18N	CT16D-74001-79999
GP18N	CT25C-75001-79999	GPE20CN	CT34-30001-39999	DP20CN	CT16D-24001-29999
GP18ZN	CT34-72001-79999	GPE20N	CT17D-20001-29999	DP20N	CT18C-20001-29999
GP20CN	CT34-22001-29999	GPE20ZN	CT35-20001-29999	DP25N	CT18C-70001-79999
GP20N	CT17D-10001-19999	GPE25N	CT17D-70001-79999	DP30N	CT14E-10001-19999
GP20ZN	CT35-10001-19999	GPE25ZN	CT35-70001-79999	DP35N	CT14E-80001-89999
GP25N	CT17D-60001-69999	GPE30N	CT13F-10001-19999		
GP25ZN	CT35-60001-69999	GPE35N	CT13F-80001-89999		
GP30N	CT13F-40001-49999				
GP35N	CT13F-60001-69999				

Keep this manual in your lift truck as a ready reference

99710-3E140

MidWestTech | Caterpillar GP15N, GP15ZN, GP18N, GP18ZN, GP20CN, GP20N, GP20ZN... Order the manual at mid-west-tech.com >

1. SAFETY RULES FOR LIFT TRUCK OPERATORS 1-1
General 1-1
Warning Decals, Location 1-2
Warning Decals, Description 1-4
- Survive in a Tipover Decal 1-4
- Tipover Warnings 1-4
- Operation Warning Decal 1-5
- With Overhead Guard Decal / Load Backrest Extension 1-6
- Duel Fuel Instruction Decal 1-6
- Parking Brake Adjustment Decal 1-6
- Cooling Fan 1-7
- Radiator Cap 1-7
- No One under / on Forks 1-7
- Crush and Pinch Points 1-7
- Capacity Plate 1-8
- No Riders Warning Decal 1-8
- Backup Alarm Decal 1-8
- Precautions for Handling E.C.U Decal 1-9
- Engine Coolant Decal 1-9
- Operator Restraint System Decal 1-9
- Deflate Air Before Loosening Nut Decal 1-10
- No Contamination Permissible Decal 1-10

Safety Rules 1-11
Operating Precautions 1-21
Working Precautions 1-26
LPG 1-33

2. KNOW YOUR LIFT TRUCK 2-1
Serial Number and Capacity Plate 2-1
Electrical Components 2-2
Model View 2-3
- MC Model 2-4

Driving Switches and Controls 2-5
- Direction Lever (Powershift Model) 2-6
- Turn Signal / Light Switch 2-6
- Key Switch 2-7
- Steering Column Tilt Lever 2-7
- Inching Pedal 2-8

Meter Panel 2-9
- Warning and Indicator Icons 2-10
- LCD Screen 2-10
- Warning and Indicator Icons 2-11
- Basic Screen Display 2-13
- Basic Operation 2-16
- When Diagnostic Code is Shown on Display 2-20
- Optional Functions 2-21

Presence Detection System 2-26
- Mast Interlock System 2-26
- Driving Interlock System (Powershift Models Only) 2-27
- Driving Interlock System Functions (Powershift Models Only) 2-27
- Driving Interlock System With Operator Restraint Function (For Powershift Models With Australia Specification Only) 2-28
- Driving Interlock System Functions (For Powershift Models With Australia Specification Only) 2-30
- Neutral System 2-30
- Neutral System Functions 2-31
- Seat Belt Warning Light 2-31
- Seat Belt Warning Functions 2-31
- Parking Brake Warning Buzzer and Icon 2-32
- Parking Brake Warning Functions 2-32

Operating Switches and Controls (MC Model) 2-33
- Lift Lever 2-33
- Tilt Lever 2-33
- Mast Vertical Switch (Optional) 2-34
- Attachment Lever (Optional) 2-34

Operator Seat 2-35
- Seat Adjustment 2-35
- Forward and Back Adjustment 2-35
- Adjustment of Suspension 2-35
- Reclining Angle Adjustment 2-36
- Pocket for the Manual 2-36
- Magazine Box 2-36
- Operator Presence Switch and Buzzer 2-37

Seat Belt 2-37
Engine Hood 2-39
- Hood Latch 2-39

Hydraulic Tank Oil Level / Filler Hole 2-40
Fuel Filler 2-40
Fork Locking Pins 2-41
Replacing Forks 2-42
Drawbar Pin 2-42
Assist Grip 2-43

3. HOW TO AVOID A TIPOVER; HOW TO SURVIVE ONE 3-1
Know What Lift Truck Stability Is 3-1
Center of Gravity (CG) 3-1
Stability and Center of Gravity 3-1
Lift Truck Stability Base 3-2
Capacity (Weight and Load Center) 3-2
Capacity Plate 3-3
- For Example 3-3

Do's and Don'ts to Avoid Tipover 3-4
How to Survive in a Tipover 3-9

4. REFUELING 4-1
Gasoline and Diesel Engine Equipped 4-1
LPG Equipped 4-2
- For Standard LPG Tank 4-3
- For Optional LPG Tank 4-4

5. OPERATION 5-1
New Lift Truck Break-In 5-1
Before Starting Engine 5-1
- Starting Engine 5-2
- Gasoline / LPG Dual Fuel Type 5-3
- Instruction for Changeover of Fuel Between LPG and Gasoline 5-3

Starting Engine 5-4
- Gasoline Model 5-4
- LPG Model 5-5
- Diesel Model 5-5

Engine Won't Start 5-7
- When Engine Is "Flooded" 5-7
- When Engine Is Started after Long Idle Period 5-8

After Starting Engine 5-8
Before Moving Lift Truck 5-9
Lift Truck Operation 5-10
- Changing Speed 5-11

MidWestTech | Caterpillar GP15N, GP15ZN, GP18N, GP18ZN, GP20CN, GP20N, GP2... Order the manual at mid-west-tech.com >

- Changing Direction 5-12
- Operating Techniques 5-13
- Steering (Turning) 5-13
- Inching 5-14

Stopping Lift Truck 5-15
Parking Lift Truck (After Stopping) 5-17

6. OPERATING TECHNIQUES 6-1
Stacking Methods 6-1
- Stacking Different Loads in Size 6-1
- Stacking Small Identical Loads 6-1
- Stacking Large Identical Loads 6-1

Handling Loads Safely 6-2
- Fork Spread Adjustment 6-3

Before Operating the Lift Truck 6-4
Blinking of the Mast Interlock Indicator Icon 6-5
Inching Into and Lifting the Load 6-7
Traveling with the Load 6-9
Unloading 6-11
Working on Grades 6-13
- Normal Travel Position 6-13
- Traveling on a Grade 6-14
- Stopping on a Grade 6-14
- Starting on a Grade (Engine Stalls on a Grade) 6-14

7. STORING THE LIFT TRUCK 7-1
End of Each Shift Storage 7-1
Long Term Storage 7-1
- Storage within 3 Months 7-1
- Storage Exceeding 3 Months 7-2

8. TRANSPORTATION HINTS 8-1
Lift Truck Loading and Shipping 8-1
Lift Truck Lifting and Tiedown Information 8-1

9. SPECIAL SITUATIONS 9-1
Care in Cold Weather 9-1
- Fuel Oils and Lubrication Oils 9-1
- Battery 9-1
- Engine Coolant 9-2

Care in Hot Weather 9-2
- Fuel Oils and Lubrication Oils 9-2
- Battery 9-2
- Engine Coolant 9-2

Severe Dust or Lint Conditions 9-3
- Air Cleaner Element 9-3
- Engine Oil and Engine Oil Filter 9-3
- Hydraulic Oil 9-3
- Hydraulic Tank Return Filter 9-3

10. TROUBLESHOOTING 10-1
If a Tire Blows Out 10-1
- If a Tire Blows out During Traveling or Operation 10-1

Replacing Tires 10-1
- Before Replacing Tires 10-2
- To Remove Wheel 10-3
- To Raise Front Wheel 10-4
- To Raise Rear Wheel 10-5
- To Install Wheel 10-5
- To Add Air to Tires 10-6
- Dual Tire (Optional) 10-6

Stalled Engine 10-7
- Before Starting the Engine Again 10-7

If the Engine Coolant Temperature Gauge Shows Red Zone ... 10-8
If Torque Converter Oil Temperature Warning Light Glows (Powershift Model) 10-9
Trouble with the LPG Equipment 10-9
Starting with Jumper Cables 10-10
If Lights Won't Glow 10-11
- How to Check Fuses and Lights 10-11

If the forklift Truck Won't Change Directions 10-13
If the Lift Truck Won't Change Directions (For Powershift Models With Australia Specification Only) 10-14
If the Mast Stops Moving 10-14
Diagnostic Codes and Explanations 10-15

11. MAINTENANCE 11-1
General 11-1
Inspection Precautions 11-2
Maintenance Schedule 11-3
- Every 10 Service Hours or Daily (Pre-Start), Whichever Comes First 11-3
- Every 50 Service Hours or Weekly, Whichever Comes First 11-4
- One Month (30 days) or 200 Service Hours after Delivery of a New Truck, Whichever Comes First 11-5
- Every 500 Service Hours or 3 Months, Whichever Comes First 11-6
- Every 1000 Service Hours or 6 Months, Whichever Comes First 11-7
- Every 2000 Service Hours or 1 year, Whichever Comes First 11-7

Every 10 Service Hours or Daily (Pre-Start), Whichever Comes First 11-9
- Faulty Operation Found the Day Before 11-9
- Oil, Fuel or Coolant Leaks 11-9
- Fuel Cap 11-9
- Tires and Rims 11-10
- Tire Pressure 11-11
- Wheel Nuts 11-12
- Lights and Lens 11-12
- Assist Grip 11-12
- Overhead Guard 11-13
- Mast and Forks 11-13
- Load Backrest Extension 11-14
- Lift Chains 11-15
- Mast and Lift Bracket 11-16
- Lift Cylinder Mounting Bolts 11-17
- Tilt Cylinder Socket Bolts 11-17
- Battery 11-18
- Engine Coolant 11-19
- Engine Oil 11-20
- Engine Cooling Fan 11-21
- Hydraulic Oil 11-22
- Transmission 11-23
- Electrical Wires 11-24
- Operator Seat 11-24
- Steering Column 11-24
- Steering Wheel 11-24
- Horn 11-24
- Service Brakes 11-25
- Parking Brake Lever 11-25

MidWestTech | Caterpillar GP15N, GP15ZN, GP18N, GP18ZN, GP20CN, GP20N, GP2... Order the manual at mid-west-tech.com >

- Brake Pedal 11-26
- Inching Pedal (Powershift Model) 11-26
- Clutch Pedal 11-26
- Accelerator Pedal 11-26
- Seat Belt 11-27
- Fuel 11-27
- Head Light and Working Light 11-27
- Turn Signal Light 11-27
- Stop Lights 11-28
- Backup Lights 11-28
- Icons of Meter Panel 11-28
- Meter Panel 11-28
- Engine (Exhaust, Noise, and Vibration) 11-29
- Mast Strip Sliding Surfaces 11-29
- Clutch (Manual Model) 11-29
- Brake Pedal 11-30
- Steering Wheel 11-30
- Parking Brake Warning Buzzer 11-31
- Mast Interlock System 11-32
- Driving Interlock System 11-33
- After the Daily (Pre-Start) Inspection 11-33

Every 50 Service Hours or Weekly, Whichever Comes First 11-34

- Fan & Alternator Drive Belt 11-34
- Hydraulic Hoses, Pipes, and Joints 11-35
- Air Cleaner Element 11-35

One Month (30 days) or 200 Service Hours after Delivery of a New Truck, Whichever Comes First 11-36

- Radiator Filler Cap 11-36
- Radiator Rubber Hose 11-37
- Alternator 11-37
- Battery 11-37
- Electrical Wires 11-38
- Starter 11-38
- Cylinder Head Bolt & Manifold Nut 11-38
- Engine Idle Speed 11-38
- Intake & Exhaust Valve 11-38
- Engine Oil 11-39
- Bolts and Nuts (Frame & Chassis) 11-39
- Tar in Vaporizer (LPG Model) 11-39
- Fuel Filter (Diesel Model) 11-39
- Fuel Filter (Gasoline Model) 11-39
- Hydraulic Tank Return Oil Filter 11-39
- Spark Plug 11-39
- Lift Chains 11-40
- Mounting Bush of Rear Axle 11-40
- Mast Support 11-40
- Tilt Socket Pins 11-40
- King Pins 11-40
- Tie Rod Pins 11-41
- Differential 11-41
- Clutch Pedal Shifter Shaft (Manual Model) 11-42
- Transmission Change Levers (Manual Model) 11-42

Every 500 Service Hours or 3 Months, Whichever Comes First 11-42

- Radiator Fin 11-42
- Engine Idle Speed 11-42
- Engine Oil 11-43
- Bolts, Nuts (Frame & Chassis) 11-44
- Fuel Filter (LPG Model) 11-44

Every 1000 Service Hours or 6 Months, Whichever Comes First 11-45

- Alternator 11-45
- Starter 11-46
- Fuel Filter (Diesel Model) 11-46
- Fuel Filter (Gasoline Model) 11-46
- Hydraulic System 11-47
- Air Cleaner Element 11-48
- Transmission 11-48
- Differential 11-49

Every 2000 Service Hours or 1 Year, Whichever Comes First .. 11-50

- Service Brake Fluid 11-50
- Engine Coolant 11-50
- Fuel Filter (LPG Model) 11-52
- Hydraulic Oil 11-53
- Parts to Be Changed Periodically 11-55

12. SERVICE DATA 12-1
Fuel Information 12-1

- Gasoline (Gas) Specification 12-1
- Diesel Fuel Specifications 12-1
- Liquefied Petroleum (LPG Model) 12-1

Coolant Information 12-2

- Coolant Water 12-2
- Antifreeze Solution 12-3

Recommended Fuels and Oils 12-4
Specifications (Standard Models) 12-5
Refill Capacities 12-8
Capacities and Lift Truck Weight (Standard Models) 12-11

13. TO THE CAT LIFT TRUCK OWNER 13-1
The Importance of Genuine Parts 13-1
Instructions for Ordering Parts 13-2
Service Registration 13-3

MidWestTech | Caterpillar GP15N, GP15ZN, GP18N, GP18ZN, GP20CN, GP20N, GP2... Order the manual at mid-west-tech.com >


◆Operating Switches and Controls (MC Model)

Equipped with mast interlock system

The mast interlock system is one of the functions of the Presence Detection System on this lift truck.

If you are not properly seated in the operator seat, you cannot operate the mast operate until you are properly seated. In the following case, the mast interlock system disconnects power to the hydraulic control valve and the mast will not lift, lower or tilt even if the control levers are operated:

- The operator leaves the operator seat for approximately 3 seconds with the key switch in the ON position regardless of whether the engine is running or not.




1. Lift lever
2. Tilt control lever/Mast vertical switch (optional)
3. Attachment control lever

▶ Lift Lever

Lifting speed is controlled by the speed of the engine (the position of the accelerator pedal) and the position of the lift lever. Lowering speed is controlled only by the position of the lift lever regardless of the speed of the engine. The lever will return to the NEUTRAL position when released.

To deactivate the mast interlock system, the operator sits on the operator seat while the key switch is in the ON position with the engine running, and then operate the lift lever.




1. Lift lever
2. Lower
3. Raise

▶ Tilt Lever

Tilt speed is controlled by the speed of the engine (the position of the accelerator pedal) and the position of the tilt lever. The lever will return to the NEUTRAL position when released.

To deactivate the mast interlock system, the operator sits on the operator seat while the key switch is in the ON position with the engine running and then operate the tilt lever.



1. Tilt lever
2. Forward
3. Backward

MidWestTech | Caterpillar GP15N, GP15ZN, GP18N, GP18ZN, GP20CN, GP20N, GP2... Order the manual at mid-west-tech.com >

▶ Engine Oil

Replace oil and filter

- Replace oil and filter.

See 11-43 "Engine Oil".

▶ Bolts and Nuts (Frame & Chassis)

Check

Bolts and nuts of frame and chassis should be retightened.

▶ Tar in Vaporizer (LPG Model)

Check / Drain

Check the tar in vaporizer for dirt.

▶ Fuel Filter (Diesel Model)

Replace

- Replace filter.

See 11-46 "Fuel Filter (Diesel Model)".

▶ Fuel Filter (Gasoline Model)

Replace

- Replace filter. (Standard engine)

See 11-46 "Fuel Filter (Gasoline Model)".

▶ Hydraulic Tank Return Oil Filter

Replace


- Replace return filter.

See 11-47 "Hydraulic System".

▶ Spark Plug

Check gap

- Visually check electrode for dirt and damage and insulator for burning.
- Check if the electrode gap is within the standard (0.8 to 0.9 mm [0.0315 to 0.0354 in.]) with a feeler gauge.



1. Insulator
2. Terminal

1) Point gap

MidWestTech | Caterpillar GP15N, GP15ZN, GP18N, GP18ZN, GP20CN, GP20N, GP2... Order the manual at mid-west-tech.com >

■ SERVICE DATA

◆Fuel Information

Use only fuel recommended in this section.

▶ Gasoline (Gas) Specification

Your lift truck must use unleaded gasoline only.

Oxygenated gasoline

Some gasoline sold at service stations contain oxygenates such as ethanol, methanol, and MTBE (Methyl Tertiary Butyl Ether), although they may not be so identified. The use of fuels containing oxygenates is not recommended.

Ethanol (Gasohol)

A mixture of 10% ethanol (grain alcohol) and 90% unleaded gasoline may be used in your lift truck, provided the octane rating is at least as high as that recommended for unleaded gasoline.

Methanol

DO NOT operate your lift truck on gasoline containing methanol (wood alcohol). The use of this type of alcohol could result in lift truck performance problems and could damage critical fuel system parts.

MTBE (Methyl Tertiary Butyl Ether)

A mixture of 15% or less MTBE and unleaded gasoline may be used in your lift truck provided the octane rating is at least as high as that recommended for unleaded gasoline.

Note: If you experience driving problems which you suspect are fuel related, try switching to a different fuel.

▶ Diesel Fuel Specifications

Fuel types

The recommended fuels provide maximum engine service life and performance. They are distillate fuels. They are commonly called diesel fuel, furnace oil, gas oil, or kerosene (for cold weather operation).

Note: The manufacturer strongly recommends the use of fuels that meet the recommended fuels specification.

Fuel sulfur content

- The percentage of sulfur in the fuel will affect the engine oil recommendations. Fuel sulfur is chemically changed during combustion to form both sulfurous and sulfuric acid. These chemically attack metal surfaces and cause corrosive wear.
- Any API classification performance of oil should have sufficient TBN for fuels with less than 0. 5% sulfur.
- For fuels with 0.5% to 1. 5% sulfur by weight, engine oil must have a TBN of 20 times the percentage of fuel sulfur as measured by the ASTM (American Society of Testing Materials) D-2896 method. (ASTM D-2896 can normally be found at your local technological society, library or college.)

▶ Liquefied Petroleum (LPG Model)

Specifications

Use grade HD5 LPG.

Note: LP-Gas is a highly volatile fuel with an octane rating of 100 to 140. Follow local ordinances regarding storage and/or filling of LPG tanks.

MidWestTech | Caterpillar GP15N, GP15ZN, GP18N, GP18ZN, GP20CN, GP20N, GP2... Order the manual at mid-west-tech.com >