1494

Operators Manual

9-9812

CASE

MidWestTech | Case 1494 Tractor Operator's Manual | Publication 9-9812

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER III

SAFETY V
- Safety Rules V
- Before Starting V
- Operation VII
- Service XVII

HAND SIGNALS XX

DECALS XXII

SERIAL NUMBERS 1

DIESEL ENGINE SPECIFICATIONS 2,3

GENERAL SPECIFICATIONS 4-6

APPROXIMATE TRACTOR SPEEDS ... 7-11

FUEL SPECIFICATIONS 11

APPROXIMATE MEASUREMENTS ...12-15

APPROXIMATE TRANSPORT WEIGHTS 12-15

TIRE AND WHEEL EQUIPMENT 16,17

TIRE ARRANGEMENTS - MFD 18

FRONT WHEEL TREAD POSITIONS - 2WD 19

FRONT WHEEL TREAD POSITIONS - MFD 20,21

REAR WHEEL TREAD POSITIONS ... 22

POWER ADJUST REAR WHEEL TREAD POSITIONS 23

LUBRICATION 24
- Engine Hourmeter 24
- Diesel Engine Oil 25
- Lubrication Chart 26
- Capacities and Approved Lubricants 27
- Lubrication - MFD 28,29
- Grease Fittings 30,31
- Engine Oil Change 32
- Engine Oil Filter Change 33
- Transmission Oil Level Check & Change 34
- Transfer Gear Box Oil Level - MFD 34
- Hydraulic Oil Filter Change 35
- Differential Oil Axle - MFD 37
- Planetary Oil Axle - MFD 38

OPERATING INSTRUCTIONS 39
- Run-In Procedure 39
- Before Operating the Tractor 40
- Towing 41
- How to Transport the Tractor 41
- Operating Instruments 42,43
- Operating Lamps 44,45
- Operating Controls Tractor Without Cab 46-61
  - Instrument Panel 46-49
  - Levers, Left-Hand Side 50-55
  - Levers, Right-Hand Side 56-61
  - Pedals .....
- Operating Controls Tractor With Cab 62-82
  - Instrument Panel 62-65
  - Foot Pedals 66,67
  - Levers, Left-Hand Side 68-71
  - Levers, Right-Hand Side 72-77
  - Controls Cab Roof 78,79
  - Air Conditioning Operating 83-85
  - Controls Cab 80-82
- Operators Seat 86,87
- Seat Belt 88
- Amber Warning Lamps, Direction Turn Signals & SMV 89
- Implement Warning Lamps, SMV Symbol 90
- Auxiliary Outlet Socket 92
- Operating On The Road 91
- Auxiliary Outlet Socket 93
- Operating the Engine 44
- Starting Procedure 95,96
- Stopping the Engine 97,98
- Cold Temperature Operation 99
- Power Shift Transmission 102,103
- Synchromesh 100,101
- Differential Lock 104

MidWestTech | Case 1494 Tractor Operator's Manual | Publication 9-9812 Order the manual at mid-west-tech.com >

Power Takeoff 105,106
Operating Safety 107
Drawbar 108,109
Pick-Up Hitch/Drawbar 110-115
Combined Pick-Up Hitch Drawbar 116
Three Point Linkage 117
Jeffes Type Linkage 117
Lift Rod Adjustment 119
Leveling Lever Adjustment 120
Sway Blocks 123
Mechanical Floatation 121
Stabilizer Bar Adjustment 122
Top Link Adjustment 118
Spacer Bar Adjustment 118
Sensing Unit 125
Selector Dial 126
Operating Jeffes Linkage 124
Operating The Linkage 127
Operating Draft 128
Operating Above Ground 128
Operating External Equipment 129
Three Way Valve 135
Hydraulic Hose Couplers 136
Front Axle Adjustment - 2WD 137
Front Axle Adjustment - MFD 138
Rear Wheel Tread Adjustment 142
Tractor Ballast 144
Front End Weights 145
Rear Wheel Weights 146
Liquid Ballast 147
Measuring Wheel Slip .....
ROLLOVER PROTECTIVE STUCTURE (ROPS) 149-152
PREVENTIVE MAINTENANCE 153
First 20 Hours Service 154
Raising Engine Cover 155
Removing Front Panel 156
Removing Side Panels 157
Service Periods 159
Daily 10 Hour Inspection 160
50 Hour Service 161
100 Hour Service 165
200 Hour Service 165
400 Hour Service 166
800 Hour Service 174
Air Cleaner 170
Air Conditioning 178
Alternator 191
Auxiliary Battery 190
Battery 188
Brake Adjustment 161
Brake Fluid 163
Cab Air Filter 177
Coolant 164
Compressor Belt 165
Differential - MFD 37
Engine Cover 155
Engine Oil 32
Engine Oil Filter 33
Final Drives .....
Front Hubs - MFD 176
Fuel Filters 167
Fuel Pump Water Trap 163
Fuses 183
Injectors 166
Lamps 184
Power Steering 161
ROPS 173
Seat Belt 172
Transmission Oil 34
Transmission Filter 34
Valve Clearance 166
Wheel Nuts 164

OPTIONAL EQUIPMENT 193

MidWestTech | Case 1494 Tractor Operator's Manual | Publication 9-9812 Order the manual at mid-west-tech.com >