W14B Loader

Operators Manual

9-9881

Reprinted

CASE CONSTRUCTION

MidWestTech | Case W14B Loader Operator's Manual | Publication 9-9881

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Introduction 2
To the Owner 2
After Delivery Check 3
Right, Left, Front, and Rear of Machine ..3
Identification of Machine Components ..4
Safety 6
Controls and Instruments 17
Left Control Panel 17
Right Control Panel 18
Instrument Panel 20
Floor Controls 23
Control Tower 24
Cab Environment Controls 26
Overhead Controls 28
Operators Seat 30
Seat Belt 32
Cab Doors and Windows 34
Bucket and Lift Arm Controls 35
Operating Instructions 43
Walk-Around Inspection 43
Starting the Engine 44
Machine Operation 45
Parking the Machine 46
Engine Starting Aids 47
Towing the Machine 51
Preparing Machine for Transport 52
Operating Tips 53
Maintenance and Lubrication 56
Transport/Service Pin 57
Systemgard™ Lubricant Analysis Service 58
Fluids and Lubricants 59
Run-In Period 61
Run-In Maintenance Schedule 61
Maintenance Schedule 62
Lubrication 67
Air Cleaner 72
Engine Cooling System 75
Engine Lubrication System 78
Engine Fuel System 81
Hydraulic System 86
Transmission 90
Axles 96
Brake System 101
Drive Belt 103
Electrical System 104
Wheels and Tires 110
Cab Air Filters 111
Air Conditioner (If equipped) 112
Starting Fluid Can 115
Spark Arrester Muffler (If equipped) ..116
Loader Service 117
Bucket Height Control Adjustment ..117
Return-To-Dig Adjustment 118
Loader Arm Bellcranks 120
Priming the Turbocharger 121
Decals 122
Roll-Over Protective Structure 129
Machine Storage 133
Specifications 135
Product Identification and Serial Numbers 140
Case Technical Manuals 142
Index 143
After Delivery Check 147

MidWestTech | Case W14B Loader Operator's Manual | Publication 9-9881 Order the manual at mid-west-tech.com >