Model "W5" Terraload'r

Parts Catalog

A1029

CASE CONSTRUCTION

MidWestTech | Case W5 Terraload'r Loader Parts Catalog | Publication A1029

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX
ENGINE PARTS

	PAGE
A	
Air Cleaner	18
B	
Battery	29
C	
Camshaft	9
Carburetor	15
Connecting Rods	7
Crankshaft and Liners	7
Cylinder Block and Head	5
Cylinder Sleeves	7
D	
Distributor	23-25-27
E	
Exhaust Pipe	13
F	
Fan	35
Flywheel	7
Flywheel Housing	36
Fuel Filters	20-21
Fuel Tank	20
G	
Gasket Kits	10
Generator	28
Governor	16
M	
Manifold Intake and Exhaust	13
Muffler	13
O	
Oil Filter	12
Oil Pan	5
Oil Pump	11
P	
Pistons and Sleeves	7
Push Rods	9
R	
Regulator - Generator	28
Rocker Arm	9
S	
Solenoid - Starting Motor	28
Spark Plugs	23
Starting Motor	28
T	
Thermostat	35
Throttle, Foot	17
Timing Gear Cover	5
Tachometer Drive	23
V	
Valves	9
Valve Cover	5
W	
Water Pump	35

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

TERRALOAD'R PARTS

	PAGE
A	
Axle, Housing, Front	49
Axle, Rear	54
B	
Battery	29
Brake - Differential	50
Brake - Pedal and Linkage	52
Bucket - Level Link	77
Bucket - Lift Arm	77
Bucket - Sight Gauge	75
Bucket and Cutting Edge	77
C	
Chassis	65
Clutch - Transmission	40
Compartment - Operators	64
Converter - Torque	37
Cylinder and Valve, Power Steering	60-62
D	
Driveshaft and Joints	44
Drawbar	65
G	
Gauge - Fuel and Sender	22-31
Gauge - Temperature	31
Gauge - Converter Oil Pressure	30
Gauge - Converter Oil Temperature	31
Gear Shift Parts - 4 Speed Transmission	48
H	
Hood and Side Panels - Engine	65
Horn	29
Horn Button	59
I	
Instrument Panel	30-31
L	
Lamps - Front, Rear, Dash	30-33-34
Loader Hydraulic Control	
Linkage	66
Hoses and Tube	69
Lift Cylinder	75
Oil Filter	71
Oil Tank	71
Pump and Drive	71-72
Tilt Cylinder	73
Valve	67
M	
Mounts - Engine Front and Rear	36
Mount - Rear Axle Pivot	54
R	
Radiator and Grill	35
S	
Seat - Operators	63
Steering - Gear and Wheel	59
Steering - Drag Link	60
Steering - Pump, Hydraulic	57
Steering Tie Rod	56
Switch Light	30-31
Switch Starting	30-31
T	
Transmission - Forward and Reverse	39
Control Valve	41
Clutch Control	43
Oil Cooler Hoses & Tubes	36
Shifter Control	42
Transmission - 4 Speed Shaft and Gears	47
Transmission - Case, 4 Speed	45
U	
Universal Joints	44
W	
Wheel - Front	49
Wheel - Rear	55
Weights - Counter	65

MidWestTech | Case W5 Terraload'r Loader Parts Catalog | Publication A1029 Order the manual at mid-west-tech.com >