Model W10 Industial

Unit Loader

Parts Catalog

A1033

CASE CONSTRUCTION

MidWestTech | Case W10 Industial Unit Loader Parts Catalog | Publication A1033

Order the manual at mid-west-tech.com >

CASE MODEL W10 UNIT LOADER

ALPHABETICAL INDEX
ENGINE SECTION

AIR INTAKE AND EXHAUST SECTION:
- AIR CLEANER-OIL BATH 27B
- AIR CLEANER-DRY TYPE 27
- EXHAUST PIPE 29
- MANIFOLDS 29
- MUFFLER 29

COOLING SECTION:
- FAN 43
- THERMOSTAT 43
- WATER MANIFOLD 43
- WATER PUMP 43

ELECTRICAL SECTION:
- ALTERNATOR WIRING 51
- ALTERNATOR 53
- BATTERY 57
- BLOCK HEATER 41
- GENERATOR 49
- GENERATOR WIRING 47
- HARDWARE-ELEC. EQUIP 57
- MANIFOLD HEATER 61
- STARTING MOTOR 55-57

ENGINE BLOCK SECTION:
- CAMSHAFT 17
- CONNECTING RODS 19
- CRANKSHAFT 17B
- BLOCK ASSEMBLY 9-15
- FLYWHEEL & HOUSING 17B
- PISTONS & RINGS 19
- SLEEVES-CYLINDER 19
- TIMING GEAR COVER 9-15

ENGINE HEAD SECTION:
- GASKET KIT 25
- HEAD ASSEMBLY 7
- POWERCEL 35
- PUSH RODS 7
- ROCKER ARMS 7
- VALVES 7
- VALVE COVER 5

FUEL SECTION:
- DECOMPRESSOR 41
- FILTER ASSY. -PRIMARY 37
- FUEL FILTER SYSTEM 31
- FUEL INJECTOR 35
- FUEL INJECTION SYSTEM 35
- FUEL PUMP 33
- FUEL TANK 37

LUBRICATION SECTION:
- DIPSTICK 9-15
- OIL FILTER 21
- OIL PAN 21
- OIL PUMP 21

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX
LOADER SECTION

ATTACHMENT SECTION:
- BUCKET-REGULAR. 187
- BUCKET-4 IN 1 199
- COUNTERWEIGHTS 147
- DOZER BLADE 187
- DRAWBAR 147
- FORK LIFT. 187
- LIFT ARM 185
- TRASH RAKE 187

AXLE SECTION:
- AXLE SECTION-FRONT . .103
- AXLE SHAFT-REAR. 105
- DIFFERENTIAL. 99
- HOUSING-FRONT. 103
- HOUSING-REAR. 105
- PLANETARY-REAR 107
- PLANETARY-FRONT . . . 103
- STEERING KNUCKLE . . . 105

BRAKE SECTION:
- HYDRAULIC LINES 119
- HYDROVAC ATT. 121
  - AIR CLEANER. . . 125
  - CHECK VALVE . . 125
  - CYLINDER 127
  - CYLINDER KITS . 129
  - VACUUM PUMP. . .125
  - MASTER CYL. . . . 115
- PARKING LEVER. 93
- PEDAL 113

CAB ATTACHMENT:
- CAB 151
- ELECTRICAL EQUIP.. . . 153
- HEATER-DEFROSTER . . .155
- WIPERS 153

CHASSIS SECTION:
- AXLE PIVOT. 149
- CHASSIS 143
- DECALS 157
- ENGINE MOUNTS. 149
- HOOD-ENGINE 147
- OPERATORS COMP.. . . . 143
- OPERATORS SEAT. 145

HYDRAULIC SECTION:
- ACCUMULATOR 179
- CYLINDER ASSY.
  - CLAM 201
  - LIFT 181
  - TILT 183

HYDRAULIC SECTION:
- TANK & FILTER. 159
- THREE SPOOL SYSTEM
  - CONTROLS 189
  - LINES & HOSES . . 195
  - VALVE. 189
- TWO SPOOL SYSTEM
  - CONTROLS. 161
  - LINES 173-175
  - VALVE. 163

INSTRUMENT SECTION
- CIGARETTE LIGHTER . . 59B
- DASH LAMP 59B
- FUSE HOLDER 59B
- INSTRUMENT CLUSTER. 59B
- PANEL ASSY. 59

STEERING SECTION:
- CYLINDER-HYD 141
- DRAG LINK. 139
- GEAR & WHEEL 133
- LINES & HOSES. 135
- PUMP-HYD. 137
- PUMP MOUNTING. 135
- RESERVOIR 135
- TIE ROD 139

TRANSMISSION SECTION:
- BRAKE 93
- CLUTCH ASSEMBLIES
  - F'WD. & REVERSE. 83
  - HIGH & LOW 85
  - INTERMEDIATE . . 85
- CONTROL LINKAGE. 79
- FILTER-CONV. 67
- LINES & TUBES. 67
- PUMP-CONVERTER. 75
- SEAL & GASKET KIT 95
- TRANSFER HOUSING 77
- VALVE-BY-PASS. 67
- VALVE-CLUTCH CONT. . . 81
- VALVE-REGULATOR 75

WHEELS-DRIVE 111B

Order the manual at mid-west-tech.com >