Model W12
Unit Loader

Parts Catalog

B1035

CASE CONSTRUCTION

MidWestTech | Case W12 Unit Loader Parts Catalog | Publication B1035

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

ENGINE SECTION

AIR INTAKE & EXHAUST SECTION:
- AIR CLEANER, DRY TYPE 39
- AIR CLEANER, OIL BATH. 41,43
- EXHAUST PIPE 21
- HEATER KIT, MANIFOLD 73
- MANIFOLD, INTAKE & EXHAUST. 21
- MUFFLER, EXHAUST. 21

COOLING SECTION:
- RADIATOR & SHUTTER 163
- WATER MANIFOLD & THERMOSTAT 25
- WATER PUMP, BELT & FAN. 25

ENGINE SECTION:
- BLOCK HEATER, CYLINDER. 75
- CAMSHAFT & BUSHING 11
- CONNECTING RODS & BRGS 15
- CRANKSHAFT & BRGS.. 13
- CYLINDER BLOCK 5
- CYLINDER HEAD. 7
- CYLINDER SLEEVES 15
- FLYWHEEL & HOUSING 13
- GASKET KITS, ENGINE. 23
- DECOMPRESSOR 19
- MOUNT, ENGINE 157
- OIL PAN. 5
- OIL PUMP. 17
- PISTONS & RINGS 15
- POWRCEL. 7
- ROCKER ARMS & SHAFT. 9
- TIMING GEARS 11,13
- TIMING GEAR COVER 5
- VALVE TRAIN, INTAKE & EXHAUST. 9

FUEL SECTION:
- COLD START KIT, ENGINE 75
- FUEL FILTERS, FINAL STAGE 27
- FUEL FILTERS, PRIMARY 31
- FUEL INJECTION LINES. 27,29
- FUEL INJECTION PUMP. 33
- FUEL INJECTORS 31
- FUEL PRIMER 19
- FUEL TANK & LINES 35
- THROTTLE & CONTROLS 37

LUBRICATION SECTION:
- OIL FILTER 11
- OIL PAN. 5
- OIL PUMP. 17

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

BASIC LOADER SECTION

AXLE SECTION:
- AXLE HOUSINGS 147,151
- AXLE PLANETARY 149,151
- DIFFERENTIAL. 145
- DRIVE SHAFTS 143
- KNUCKLE & SPINDLE
- REAR AXLE 147
- REAR AXLE PIVOT & MTG. . . 157

BRAKE SECTION:
- AIR CLEANER, HYDROVAC. . . 89
- AIR FILTER, HYDROVAC 89
- BRAKE ASSY. 153,155
- BRAKE CYLINDERS 153,155
- BRAKE CYLINDER, HYD. . . 81,83
- BRAKE CYL., HYDROVAC . . . 83
- BRAKE LINES 79
- BRAKE PEDAL 77
- CHECK VALVE, HYDROVAC . . 89
- HYDROVAC CYLINDER. . . . 91,93
- HYDROVAC BRAKE SYS.. . . 85,87
- PARKING BRAKE. 97
- REPAIR KITS, HYDV. CYL. . . 95
- VACUUM PUMP, HYDROVAC. . 89

CHASSIS SECTION:
- BRUSH RAKE 195
- BUCKETS 193
- CHASSIS 161
- COUNTERWEIGHTS 159
- DRAWBAR 159
- DOZER BLADE 195
- GRILLE HOUSING 163
- LIFT ARMS. 191
- SEAT, OPERATORS 167

ELECTRICAL SECTION:
- ALTERNATOR. 61,65
- BATTERY & CABLES . . . 47,53,57
- CAB ELECTRICAL. 199,201
- GENERATOR. 63
- HORN & BUTTON. 73,133
- INSTRUMENT CLUSTER 71
- INSTRUMENT GAUGES . . 45,49,59
- LAMPS. 69
- STARTER MOTOR 67
- WIRING, CHASSIS. . . . 47,51,53-57
- WIRING, PANEL 45,49,59

HYDRAULIC SECTION:
- ACCUMULATOR & VALVE . . 189
- CONTROL VALVE 173-179
- HYDRAULIC CONTROLS 181
- HYD. HOSES & LINES 169
- HYD. OIL TANK & FILTER. . 171
- HYDRAULIC PUMP 183
- LIFT CYLINDER 185
- TILT CYLINDER 187

SHEET METAL SECTION:
- CAB, OPERATORS 197
- DECALS 203
- FRONT & SIDE PANELS 161
- HOOD, ENGINE 161
- PANEL, INSTRUMENT . . 45,49,59
- PLAT. & BAT. TRAY 165

STEERING SECTION:
- PWR. STRG. HOSES & TUBES . 135
- PWR. STR. PUMP & RES. . . 137
- PWR. STRG. PUMP MTG. 135
- STRG. ARMS & DRAG LINK . . . 139
- STEERING CYLINDER 141
- STEERING WHEEL & GEAR. . 133
- TIE ROD. 143

TRANSMISSION SECTION:
- BY-PASS VALVE & FILTER . 105
- CHARGING PUMP. 113
- CLUTCH DISCONNECT . . . 125,129
- CLUTCH CONTROL 125,129
- CONTROL VALVE 101,103
- CONVERTER HOUSING 111
- CONV. PUMP DRIVE 111
- CONV. & TRANS. LINES . . . 105
- CUT-OFF & VALVE 115
- FRWD. & REVERSE CLUTCH . . 117
- HIGH & LOW CLUTCH . . . 119,121
- INTERMEDIATE CLUTCH . 119,121
- REGULATOR VALVE 113
- SEAL & GASKET KIT 131
- TORQUE CONVERTER . . . 107,109
- TRANS. HSG. & GEARS. . . . 123,127
- TRANSMISSION HOUSING 115
- TRANSMISSION MOUNTS. 157
- TRANS. SHIFT CONTROL. . . . 99

WHEEL SECTION: 159

Order the manual at mid-west-tech.com >