1070 Agri-King Tractors Prior to S/N 8675001

Parts Catalog

B1118

CASE IH AGRICULTURE

MidWestTech | Case 1070 Agri King Tractor Parts Catalog | Publication B1118

Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.	PART NO.	DESCRIPTION	REQ'D
	A 55159	CYLINDER ASSY. - rear steering	1
28	A 56208	SOCKET ASSY. rear cylinder	1
29	NSS	PLUG - adjusting, socket assy	1
30	NSS	SEAT - socket ball	2
31	NSS	SPRING - socket	1
32	NSS	SEAT - socket spring	1
33	G 45175	CLAMP ASSY. - socket assy.	1
	16- 836	BOLT - 1/2" x 2-1/4" N.F. hex.	1
34	132- 104	PIN - cotter, 3/16" x 3"	UAR
35	A 55889	STUD - ball, socket & cylinder	2
36	13- 410	BOLT - 1/4" x 5/8" N.C., hex	4
37	92- 4	LOCKWASHER - 1/4" SAE	4

NOTE **NSS** IN PART NO. COLUMN INDICATES THIS PART IS NOT SERVICED SEPARATELY.
UAR IN AMT. REQ'D COLUMN INDICATES THIS PART IS USED AS REQUIRED.

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.

Order the manual at mid-west-tech.com >

CASE 1070 AGRI-KING TRACTORS

ALPHABETICAL INDEX

ENGINE SECTION

Air Intake and Exhaust Section
- Air Cleaner 11
- Manifold 13
- Muffler 13
- Pre-Cleaner 11

Cold Weather Starting Aids
- Block Heater 103
- Ether Starting Kit 11B
- Manifold Heater 13

Cooling Section
- Oil Cooler 7
- Radiator Baffles 5B
- Radiator 5
- Water Manifold and Thermostat 9
- Water Pump and Attaching Parts 9

Engine Section
- Camshaft 17B
- Connecting Rods and Bearings 23
- Crankshaft and Bearings 21
- Cylinder Block 19
- Cylinder Head Cover 15
- Cylinder Head 15
- Engine Gasket Kits 29
- Flywheel 21
- Manifolds 13
- Pistons and Rings 23
- Rocker Shaft and Arms 17
- Timing Gear Cover 39
- Timing Gear 39
- Valve Train 17

Fuel Section
- Fuel Injection Filter System 37,37B
- Fuel Injection Pump 39B-39F
- Fuel Injection Pump Drive 39
- Fuel Injection System 35
- Fuel Injectors 35,35B
- Fuel Lines 35
- Fuel Tank 33,33B
- Throttle and Linkage 31,31B

Lubrication Section
- Oil Filter 27
- Oil Pan 27
- Oil Pump 25

Order the manual at mid-west-tech.com >

CASE 1070 AGRI-KING TRACTORS

ALPHABETICAL INDEX

BASIC TRACTOR SECTION

Axle Section
- Tie Rods
  - Tread 53 to 73" 85
  - Tread 60 to 80" 87
- Front Axle
  - Tread 53 to 73" 81
  - Tread 60 to 80" 83
- Rear Axle
  - Long 143
  - Short 145

Brake Section
- Hydraulic
  - Controls 149
  - Differential 141
  - Hoses and Lines 73
  - Master Cylinder 149,155
  - Oil Filter 71-75
  - Parking Brake 141B
  - Slave Cylinder 141,147,149,155
- Power Assist
  - Controls 147
  - Differential 141
  - Hoses and Lines 71
  - Oil Filter 71,75
  - Parking Brake 141B
  - Slave Cylinder 141,147,149,155
  - Valve 71,147,151-153B

Cab Section
- Acoustical Covers 265,265B
- Air Compressors 289B-289F
- Air Conditioner 287,289
- Air Filter 273F
- Blower 283
- Compressor Clutch 289H
- Door 259,259B
- Electrical Wiring 279,279B
- Glass 293
- Headliner 267,267B
- Instrument Panel 275-277B
- Insulation 261-263
- Lights 281,281B
- Mirrors 291
- Platforms 257
- Plenum
  - Air Conditioner 273-273D
  - Blower 269,269B
  - Heater 271,271B
- Protective Frame and Canopy 253
- Radio 285
- Sheet Metal 255-255F
- Windows 259D, 259F
- Windshield Wiper 281,281B

Order the manual at mid-west-tech.com >