# W11 Loader

# Parts Catalog

**B1364**

CASE CONSTRUCTION



Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## A


Accelerator and Linkage ..... 47
Air Cleaner ..... 43
Alternator ..... 67-71
Alternator Mounting ..... 75
Auxiliary Steering ..... 91, 119
Axle Assemblies
  Axle Housing ..... 163
  Brakes ..... 169
  Differential ..... 165, 167
Axle Mounting ..... 159


## B


Backup Alarm ..... 93
Battery ..... 77
  Cables ..... 77
Belts
  Alternator and Fan ..... 41
  Seat ..... 249, 251
Block, engine cylinder ..... 23
Blower, cab ..... 267
Brake Assemblies and Circuits
  Axle Brake ..... 169
  Front Brake and Clutch Cutout ..... 175
  Parking Brake ..... 153, 171
  Rear Brake ..... 177
Buckets
  Clam ..... 237
  Standard ..... 235
  Teeth ..... 235


## C


Cab, operator's ..... 259-269
Camshaft, engine ..... 21
Canopy, ROPS ..... 271
Clutch, transmission ..... 139, 141
Cold Start System (Ether Injection) ..... 99
Connecting Rods, engine ..... 29
Control Levers
  Loader Lift and Dump ..... 223, 225
  Parking Brake ..... 171
  Pedal, accelerator ..... 47
  Pedal, brake ..... 173
  Transmission ..... 127
Converter, torque ..... 135, 137
Cooler, transmission oil ..... 131
Crankshaft, engine ..... 25
Cushions, seat ..... 249, 253
Cylinder Block, engine ..... 23
Cylinder Head, engine ..... 15, 17
Cylinders, brake
  Master ..... 179, 181
  Wheel ..... 169


## C


Cylinders, hydraulic
  Bucket ..... 219
  Clam ..... 221
  Loader Lift ..... 217
  Steering ..... 121


## D


Decals
  Engine Data ..... 15, 17
  Machine ..... 273
Dipsticks
  Engine Oil ..... 23
  Transmission Oil ..... 129
Drive Shaft
  Center Bearing ..... 157
  Front, axle end ..... 157
  Middle, transmission to front axle drive shaft . 155
  Rear ..... 155
Drum Brakes ..... 169


## E


Electrical Systems
  Auxiliary Steering ..... 91
  Backup Alarm ..... 93
  Battery and Cables ..... 77
  Bucket Height ..... 229
  Cold Start System ..... 99
  Front Harness ..... 83, 85
  Instrument Panels ..... 87, 89
  Operator's Compartment ..... 97
  Rear Harness ..... 79, 81
  Return-To-Dig ..... 227
  Turn Signals, Flood Lights and Strobe ..... 95
Emblem - slow moving ..... 275
Engine Mount ..... 39
Engine Components
  Alternator ..... 67-71
  Camshaft ..... 21
  Crankshaft ..... 25
  Cylinder Block ..... 23
  Cylinder Head and Cover ..... 15, 17
  Flywheel and Housing ..... 27
  Fuel Filter System ..... 53-57
  Fuel Injection System ..... 53, 55, 59-65
  Gasket Kits ..... 35
  Injection Nozzles ..... 59
  Injection Pump ..... 63, 65
  Injection Pump Drive ..... 61
  Manifolds, intake and exhaust ..... 13
  Piston and Connecting Rods ..... 29
  Starter ..... 73
  Timing Gear Cover ..... 31, 33
  Valve Mechanism ..... 19
  Water Pump ..... 11
Exhaust, pipe and mufflers ..... 45


Printed in U.S.A.

Issued January, 1983

MidWestTech | Case W11 Loader Parts Catalog | Publication B1364

Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## F


Fan, defroster ..... 109
Fan, heater ..... 267
Fan, radiator ..... 41
Fenders ..... 243, 247
Filters
  Air Cleaner ..... 43
  Cab Air ..... 267
  Engine Oil ..... 31, 33
  Fuel ..... 53-57
  Hydraulic Oil ..... 187
  Hydraulic Tank ..... 185
  Transmission Oil ..... 129
Flasher Lights ..... 93, 95, 103
Flywheel, engine ..... 27
Frames
  Front ..... 245, 247
  Rear ..... 239
  Loader Lift ..... 231
Fuel Filter System ..... 53-57
Fuel Injection System ..... 59-65
Fuel Injector Nozzles ..... 59
Fuel Lines ..... 51, 53, 55
Fuel Tank ..... 49


## G


Gasket, engine (Service Kits) ..... 35
Gauges-See Electrical Systems
Gears
  Engine-See Engine Components
  Transmission-See Transmission Components
Grille ..... 241
Guards
  Engine Side Panels ..... 243


## H


Head, engine ..... 15, 17
Heater
  Block, engine ..... 23
  Cab ..... 269
Hood ..... 241
Horn ..... 83, 111
Hose, radiator ..... 41
Hose and Fitting Conversion Part Numbers ... 276
Hoses-See Fuel Lines, Brakes Assemblies and
  Hydraulic Circuits
Hydraulic Circuit
  Auxiliary Steering Hydraulic Circuit ..... 119
  Clam bucket ..... 199
  Loader Arm Auxiliary ..... 197
  Loader Bucket ..... 195
  Loader Lift ..... 193
  Pump Flow ..... 189, 191


## H


  Return Lines ..... 187
  Steering ..... 117
  Transmission ..... 129, 131
Hydraulic Reservoir Assembly ..... 185


## I


Index, numerical ..... 277
Instrument Panel ..... 87, 89
Instruments-See Gauges


## L


Lamps ..... 87, 93-97, 101, 103
Loader
  Buckets ..... 235, 237
  Hydraulic Circuits ..... 185-199
  Lift Frame ..... 231


## M


Manifold
  Exhaust ..... 13
  Intake ..... 13
Mirrors ..... 259, 271
Motor - Auxiliary Steering ..... 125
Mounting
  Axle ..... 159
  Cab ..... 259
  Engine ..... 39
  Radiator ..... 41
  Transmission ..... 39
Mufflers ..... 45


## N


Nozzle, cold starting fluid ..... 99
Nozzle, fuel injector ..... 59
Numerical Index ..... 277


## O


Oil Cooler, transmission ..... 131
Oil Filter
  Engine ..... 31, 33
  Hydraulic ..... 185, 187
  Transmission ..... 129
Oil Pan, engine ..... 31, 33
Oil Pump, engine ..... 31, 33


MidWestTech | Case W11 Loader Parts Catalog | Publication B1364 Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## P


Pan, engine oil ..... 31, 33
Panel, instrument ..... 87, 89
Parking Brake ..... 153, 171
Pedal, accelerator ..... 47
Piston Assemblies, engine ..... 29
Pulleys
  Alternator ..... 67-71
  Alternator and Fan Drive ..... 25
Pump Drive, water ..... 11
Pumps
  Auxiliary Steering ..... 123
  Engine oil ..... 31, 33
  Fuel Injection ..... 63, 65
  Fuel, electric ..... 51
  Hydraulic Oil ..... 201
  Steering ..... 201
  Transmission Charging ..... 149
  Water, engine ..... 11


## R


Radiator, cooling ..... 41
Regulator, voltage ..... 67-71
Reservoirs
  Fuel ..... 49
  Hydraulic Oil ..... 185
Return To Dig ..... 227
Rims, wheel ..... 161
Rings, engine piston ..... 29
Rocker Arms, engine ..... 19
Rods, connecting ..... 29
Rods, push ..... 19


## S


Seat Assemblies ..... 249-257
Seat Belts ..... 249, 251
Senders
  Engine Oil Pressure ..... 23
  Fuel Gauge ..... 49
  Temperature, transmission ..... 81
  Temperature, water ..... 15, 17, 81
Shafts
  Axle (See Axle Assemblies)
  Drive ..... 155, 157
  Engine (See Engine Components)
  Transmission (See Transmission Components)
Shroud, radiator ..... 241
Side Panels, engine ..... 241, 243


## S


Sleeve, piston ..... 29
Solenoid, auxiliary steering ..... 79
Solenoid, starter ..... 73, 79
Starter, engine ..... 73, 77
Starting Aid (Ether Injection) ..... 99
Steering ..... 111-125
Steps ..... 247
Switches
  Auxiliary Steering ..... 87
  Backup Alarm ..... 81
  Blower Fan, cab ..... 97
  Clutch Pressure ..... 81
  Cold Start ..... 89
  Defroster, cab ..... 109
  Dome Lamp, cab ..... 97
  Heater, cab ..... 269
  Key and Starter ..... 89
  Lamp, driving ..... 89
  Loader Height Control ..... 229
  Neutral Start ..... 145
  Parking Brake ..... 85
  Return-To-Dig ..... 227
  Stop Lamp ..... 83
  Strobe Lamp ..... 89
  Turn Signal and Flasher ..... 95


## T


Tachometer ..... 77
Tank
  Fuel ..... 49
  Hydraulic Oil ..... 185
Temperature Sending Unit ..... 81
Thermostat, water temperature ..... 11
Timing Gear Cover, engine ..... 37
Torque Converter ..... 135, 137
Transmission Mounts ..... 39
Transmission
  Charging Pump ..... 149
  Control Valve ..... 145, 147
  First, Forward and Third Clutches ..... 141
  Front Housing and Idler ..... 143
  Front Housing, Input Shaft and Pump Drive . 133
  Output Shaft and Cover ..... 151
  Second and Reverse Clutches ..... 139
  Torque Converter and Flex Plates ..... 135, 137
  Yoke and Brake ..... 153
Trunnion, rear frame ..... 239
Turn Signals ..... 95, 103


Printed in U.S.A.

Issued January, 1983

MidWestTech | Case W11 Loader Parts Catalog | Publication B1364

Order the manual at mid-west-tech.com >