ILLUSTRATED PARTS LIST

KUBOTA

B2400HSE

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C040-58200	ASSY CLEANER AIR	1			NOT SALE ORDER BY PART No.6A100-5820-0	0	0
020	6C040-82510	BODY AIR CLEANER	1				0.23	0.506
030	67980-82553	ASSY COVER A/C	1				0.1	0.22
040	T0070-16342	BOLT WING	1				0.021	0.0462
050	67980-82610	WASHER	1				0.001	0.0022
060	67980-82620	LABEL CAUTION	1				0.001	0.0022
070	67980-82630	ASSY ELEMENT	1				0.21	0.462
080	6C040-58233	BRACKET AIR CLEANER	1				0.54	1.188
090	02131-50100	NUT	2				0.01	0.022
100	6C040-58250	HOSE INLET	1	<=30154			0.115	0.253
100	6C040-58253	HOSE INLET	1	>=30155	←		0.12	0.264
110	15261-11720	BAND PIPE	1				0.03	0.066
120	6C040-58260	HOSE INLET	1				0.27	0.594
130	67955-58260	BAND AIR CLEANER	2				0.028	0.0616

MidWestTech | Kubota B2400HSE Tractor Parts Manual | Publication B2400HSE
Order the manual at mid-west-tech.com >

LOWER LINK

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
005	6C040-96980	SET CASE DIFF.GEAR	1				11.34	24.948
010	6C040-65600	COMP.HITCH	1	<=30154		ORDER BY REF No.005	3.24	7.128
010	6C040-65604	COMP.HITCH	1	>=30155	≠		3.35	7.37
020	01123-51230	BOLT	4				0.04	0.088
030	6C040-67110	DRAWBAR	1				4.5	9.9
040	6C040-65610	PIN HITCH	1				0.18	0.396
050	31150-29730	PIN SPRING	1				0.044	0.0968
060	6C040-66010	PIN LOWER LINK	1				1.14	2.508
070	6C040-65120	BOLT	1				0.02	0.044
075	02118-50100	NUT	1				0.005	0.011
077	04512-60100	WASHER SPRING	1				0.002	0.0044
080	02174-50160	NUT	2				0.022	0.0484
090	04512-60160	WASHER SPRING	2				0.01	0.022
100	04015-60160	WASHER PLAIN	2				0.058	0.1276
110	6C040-65210	COMP.LINK LOWER	2				5.24	11.528
120	34150-37640	PIN SET	4				0.06	0.132
130	66204-65350	SPACER	2				0.12	0.264
140	6C040-65294	BRACKET CHECK CHAIN	1				0	0
150	6C040-65323	BOLT TURNBUCKLE	1				0	0
160	6C040-65390	TURNBUCKLE	1				0.2	0.44
170	05515-61200	PIN SNAP	1				0.005	0.011

MidWestTech | Kubota B2400HSE Tractor Parts Manual | Publication B2400HSE Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C040-51315	STEP LH	1	<=30280			0	0
010	6C040-51318	STEP LH	1	>=30281	←		3.4	7.48
010	6C040-51319	STEP LH	1	>=30477	≠		2.22	4.884
020	6C040-51323	STEP RH	1	<=30280			0	0
020	6C040-51325	STEP RH	1	>=30281	←		3.4	7.48
020	6C040-51326	STEP RH	1	>=30477	≠		2.2	4.84
030	6C040-51330	SUPPORT STEP RH	1				0.073	0.1606
040	6C040-51380	CUSHION	6	<=30294			0	0
040	6A100-51380	CUSHION	6	>=30295	↔		0.003	0.0066
040	6A100-51380	CUSHION	4	>=30477			0.003	0.0066
045	6A100-51380	CUSHION	4	>=30477			0.003	0.0066
050	6C040-51342	BOLT	4				0.017	0.0374
060	6C040-51390	COLLAR	2	<=30476			0.003	0.0066
060	6C040-51390	COLLAR	4	>=30477			0.003	0.0066
070	02121-50080	NUT	4	<=30476			0.01	0.022
070	02121-50080	NUT	6	>=30477			0.01	0.022
080	6C040-51350	CUSHION	1				0.002	0.0044
090	6C040-51364	MAT STEP	1				2.08	4.576
100	67955-51340	STOPPER	12				0.001	0.0022

MidWestTech | Kubota B2400HSE Tractor Parts Manual | Publication B2400HSE Order the manual at mid-west-tech.com >