ILLUSTRATED PARTS LIST

KUBOTA

B2910HSD

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C070-36303	ASSY PUMP HYDRAULIC	1	<=2K0898			0	0
010	6C070-36306	ASSY PUMP HYDRAULIC	1	>=2L0006	←		2.32	5.104
020	6C070-36390	COMP.GEAR HYD.PUMP	1				0.3	0.66
025	6A100-37230	BUSH	2	<=2K0898			0.005	0.011
025	6A100-37232	BUSH	2	>=2L0006	←		0.005	0.011
026	05012-00814	PIN STRAIGHT	2				0.006	0.0132
030	6C140-36350	PLATE SIDE	1				0.05	0.11
040	6C040-36342	RING DOUBLE	1	<=2K0898			0	0
040	6C040-36344	RING DOUBLE	1	>=2L0006	←		0.003	0.0066
050	6A100-37430	COUPLING	1				0.01	0.022
060	6A100-37230	BUSH	4	<=2K0898			0.005	0.011
060	6A100-37232	BUSH	4	>=2L0006	←		0.005	0.011
070	05012-00814	PIN STRAIGHT	2				0.006	0.0132
080	6A100-37442	COMP.GEAR HYD.PUMP	1				0.18	0.396
090	6C140-36350	PLATE SIDE	1				0.05	0.11
100	6C040-36342	RING DOUBLE	1	<=2K0898			0	0
100	6C040-36344	RING DOUBLE	1	>=2L0006	←		0.003	0.0066
110	6C140-37400	COMP.COVER	1				0.23	0.506
120	6A100-37230	BUSH	2	<=2K0898			0.005	0.011
120	6A100-37232	BUSH	2	>=2L0006	←		0.005	0.011
130	01754-51090	BOLT FLANGE	4				0.05	0.11
140	31381-76390	SEAL OIL	1				0.01	0.022
150	04611-00300	CIR CLIP INTERNAL	1				0.004	0.0088

MidWestTech | Kubota B2910HSD Tractor Parts Manual | Publication B2910HSD Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C170-45830	PLATE LINK RH	1				0.75	1.65
020	6C170-45840	PLATE LINK LH	1				0.73	1.606
030	6C140-45910	ADJUSTER SEAT LH	1				0.65	1.43
040	6C140-45920	ADJUSTER SEAT RH	1				0.85	1.87
050	6C170-45970	BRACKET ADJUSTER	1				0	0
060	6C170-45990	BRACKET ADJUSTER	1				0	0
070	02114-50080	NUT	6				0.005	0.011
080	04512-60080	WASHER SPRING	6				0.002	0.0044
090	02552-50080	NUT LOCK	4				0.005	0.011
100	03014-50820	SCREW PAN-HEAD	2				0.01	0.022
110	TA140-47780	CUSHION	2				0.043	0.0946
120	K2561-56850	ASSY BELT SEAT	1				0.81	1.782
130	01123-50820	BOLT	4				0.011	0.0242
140	6C170-45712	STAY SEAT RH	1				0.19	0.418
150	6C170-45722	STAY SEAT LH	1				0.19	0.418
160	6C170-45930	PIN SEAT ADJUSTER	1				0.1	0.22
170	05525-61000	PIN SNAP	1				0.002	0.0044
180	01135-61020	BOLT	1				0.015	0.033
190	01135-61025	BOLT	1				0.04	0.088
200	6C070-88710	ASSY SEAT	1				13.25	29.15
201	6C070-88720	SEAT	1				8.4	18.48
202	6C070-88730	KIT ARM REST	1				3.185	7.007
210	6C170-45940	SPRING SEAT SWITCH	1				0	0
220	01125-60820	BOLT	1				0.015	0.033
230	6C060-45990	CAP SPRING	1				0.011	0.0242
240	6C170-45730	SPRING RETAINER	1				0.02	0.044

MidWestTech | Kubota B2910HSD Tractor Parts Manual | Publication B2910HSD Order the manual at mid-west-tech.com >

REAR WHEEL(12.4-16) [AU]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66419-50010	ASSY REAR WHEEL	1				90	198
020	66419-50100	ASSY TIRE LH	1				45	99
030	66418-27950	WHEEL	1				14	30.8
040	67810-50120	TUBE	1				4.5	9.9
050	67810-50130	TIRE	1				27	59.4
060	32150-27700	ASSY VALVE	1				0.001	0.0022
070	32150-27740	VALVE	1				0.003	0.0066
080	38240-11690	CAP VALVE	1				0.001	0.0022
090	66419-50140	LABEL LH	1			NOT SALE	0.001	0.0022
100	66419-50200	ASSY TIRE RH	1				45	99
110	66418-27950	WHEEL	1				14	30.8
120	67810-50120	TUBE	1				4.5	9.9
130	67810-50130	TIRE	1				27	59.4
140	32150-27700	ASSY VALVE	1				0.001	0.0022
150	32150-27740	VALVE	1				0.003	0.0066
160	38240-11690	CAP VALVE	1				0.001	0.0022
170	66419-50150	LABEL RH	1			NOT SALE	0.002	0.0044
180	01517-51632	STUD	4				0.076	0.1672
185	04011-60160	WASHER PLAIN	12				0.01	0.022
190	04512-60160	WASHER SPRING	12				0.01	0.022
200	02076-50160	NUT	4				0.03	0.066
210	01173-51635	BOLT	8				0.008	0.0176

MidWestTech | Kubota B2910HSD Tractor Parts Manual | Publication B2910HSD Order the manual at mid-west-tech.com >