ILLUSTRATED PARTS LIST

KUBOTA

B7200HSTD

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	67061-45900	ASSY SEAT	1	<=50112		ORDER BY REF.NO.010 020 AND 030	8.71	19.162
010	67061-45910	SEAT	1	>=50113	≠		7.3	16.06
020	67061-45920	BRACKET	2	>=50113			0.18	0.396
030	01123-50816	BOLT	4	>=50113			0.011	0.0242
040	67401-45920	STAY	1				0	0
050	01123-50816	BOLT	2				0.011	0.0242
060	05122-51045	PIN JOINT	2				0	0
070	05515-51000	PIN SNAP	2				0	0
080	66591-41540	RUBBER	4				0.01	0.022
090	66591-41550	COLLAR	2				0.02	0.044
100	67061-45932	ASSY ADJUSTER SEAT	1				0	0
110	67061-45942	COMP ADJUSTOR SEAT	1				0	0
120	67061-45952	SUPPORT ADJUSTER	1				0.5	1.1
130	67061-45960	SUPPORT ADJUSTER	1				0.46	1.012
140	04512-50100	WASHER SPRING	4				0	0
150	02018-50100	NUT	4				0.011	0.0242
160	01123-50825	BOLT	2				0.013	0.0286
170	01120-51020	BOLT	2				0.02	0.044
180	67061-45970	SPRING SEAT	2				0.13	0.286
190	04015-50080	WASHER PLAIN	2				0	0
200	01123-50820	BOLT	2				0.011	0.0242
210	66301-52820	CAP SPRING	2				0.04	0.088
220	66704-54950	BRACKET SMV	1				0	0
230	01050-50610	BOLT	2				0	0
240	04013-50060	WASHER PLAIN	2				0	0
250	04512-50060	WASHER SPRING	2				0	0
260	02014-50060	NUT	2				0.003	0.0066

MidWestTech | Kubota B7200HSTD Tractor Parts Manual | Publication B7200HSTD Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66591-14980	SHIM DIFF SIDE	2				0.005	0.011
010	66591-14990	SHIM DIFF SIDE	2				0.002	0.0044
010	67121-56630	SHIM DIFF SIDE	2				0.005	0.011
020	67121-56640	SHAFT	2				0.98	2.156
030	67121-56650	GEAR BEVEL	2				0.38	0.836
040	08101-06305	BEARING BALL	2				0.23	0.506
050	04612-00250	CIR-CLIP EXTERNAL	4				0.002	0.0044
060	67121-56710	GEAR BEVEL	2				0.35	0.77
070	67121-56720	SHAFT BEVEL GEAR	2				0.73	1.606
080	67121-56730	COLLAR SUPPORT	2				0.075	0.165
090	04612-00250	CIR-CLIP EXTERNAL	2				0.002	0.0044
100	08101-06303	BEARING BALL	2				0.112	0.2464
110	67121-56760	BEARING BALL	4				0	0
120	04611-00520	CIR-CLIP INTERNAL	4				0.009	0.0198
130	04811-10250	O RING	2				0.001	0.0022
140	67121-56740	SEAL OIL	4				0.016	0.0352
150	67221-56750	GEAR BEVEL	2				0.58	1.276
160	08101-06007	BEARING BALL	2				0.16	0.352
170	67121-56810	GEAR BEVEL	2				2	4.4
180	67121-56820	COLLAR SET	4				0	0
190	67401-56830	HUB FRONT WHEEL	2				1.66	3.652
200	66204-56840	COLLAR	2				0.02	0.044
210	08101-06305	BEARING BALL	2				0.23	0.506
220	08101-06206	BEARING BALL	2				0.196	0.4312
230	63733-17150	SEAL OIL	2				0.04	0.088
240	66758-56970	BOLT	12				0.03	0.066

MidWestTech | Kubota B7200HSTD Tractor Parts Manual | Publication B7200HSTD Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	67401-65100	ASSY 3-POINT LINKAGE	1				26	57.2
020	67401-65200	ASSY ROD	1				23.7	52.14
030	96316-06110	BRACKET TOP LINK	1				1.22	2.684
040	01123-51230	BOLT	2				0.04	0.088
050	66706-65332	LINK TOP	1				1	2.2
060	67211-42940	NIPPLE GREESE	2				0.001	0.0022
070	66706-65340	NUT TOP LINK	1				0.05	0.11
080	66706-65352	JOINT TOP LINK LH	1				0.73	1.606
090	66706-65362	JOINT TOP LINK RH	1				0.77	1.694
100	05411-00422	PIN SPRING	2				0.001	0.0022
110	34150-37640	PIN	9				0.06	0.132
120	31150-71360	PIN JOINT	2				0.166	0.3652
130	67401-65210	COMP.LINK LOWER	2				0	0
140	05511-50425	PIN SPLIT	3				0.003	0.0066
150	04013-50120	WASHER PLAIN	3				0	0
160	67401-65230	ROD LIFT UPPER RH	1				0.53	1.166
170	67401-65240	ROD LIFT LOWER LH	1				0.5	1.1
180	67401-65250	ROD LIFT MIDDLE	1				0.44	0.968
190	02172-50180	NUT	1				0.021	0.0462
200	05122-51240	PIN JOINT	3				0.039	0.0858
210	67401-65270	ROD LIFT LH	1				1.34	2.948
220	96316-18250	PIN LINK	2				0	0
230	67401-65290	BRACKET CHECK CHAIN	1				0.63	1.386
240	66204-65350	SPACER	2				0.12	0.264
250	67401-65370	JOINT CHAIN	4				0.1	0.22
260	66706-65380	PIN SET	4				0.021	0.0462
270	02174-50120	NUT	2				0.01	0.022
280	04512-50120	WASHER SPRING	2				0	0
290	05511-50318	PIN SPLIT	4				0.001	0.0022
300	66706-65310	BOLT TURNBUCKLE RH	2				0.153	0.3366
310	66706-65320	BOLT TURNBUCKLE LH	2				0.153	0.3366
320	02112-50120	NUT	2				0.007	0.0154
330	96316-05580	TURNBUCKLE	2				0.14	0.308
340	66704-86110	PIN LOWER LINK	1				1.19	2.618
350	66204-65120	BOLT	1				0.055	0.121
360	66616-34550	CHAIN	1				0.66	1.452
370	02174-50140	NUT	1				0.014	0.0308
380	66204-65500	ASSY HITCH	1				0	0
390	66204-65600	COMP.HITCH	1				0	0
400	01153-51235	BOLT	3				0.039	0.0858
410	04512-50120	WASHER SPRING	3				0	0
420	66204-65610	PIN HITCH	1				0	0
430	31150-29730	PIN SPRING	1				0.044	0.0968
440	66204-86510	DRAWBAR	1				3.06	6.732

MidWestTech | Kubota B7200HSTD Tractor Parts Manual | Publication B7200HSTD Order the manual at mid-west-tech.com >