ILLUSTRATED PARTS LIST

KUBOTA

B8200DP

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	67800-52400	ASSY SEAT	1			REF.No.002, 003	4.4	9.68
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001 OR 031	0	0
004	38240-24420	PIN, JOINT	2				0.028	0.0616
005	05515-51000	PIN, SNAP	2				0	0
006	67800-54970	BRACKET, SMV	1				0.3	0.66
007	01053-50616	BOLT	2				0.005	0.011
008	04013-50060	WASHER, PLAIN	2				0	0
009	04512-50060	WASHER, SPRING	2				0	0
010	67810-52600	ASSY ADJUSTOR, SEAT	1			REF.No.011 TO 021	0	0
011	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
012	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
013	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
014	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
015	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
016	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
017	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
018	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
019	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
020	67810-52710	SUPPORT, REAR	1				0.54	1.188
021	01123-50814	BOLT	2				0	0
022	01153-51025	BOLT	4				0.019	0.0418
023	66591-41540	CUSHION	4				0.01	0.022
024	66591-41550	COLLAR	2				0.02	0.044
025	32160-18440	CUSHION	2				0.013	0.0286
026	66204-45980	SPRING, SEAT	2				0.1	0.22
027	66204-45970	SUPPORT, SPRING	2				0.1	0.22
028	04012-50080	WASHER, PLAIN	2				0.001	0.0022
029	05511-50215	PIN, SPLIT	2				0.001	0.0022
030	04512-50100	WASHER, SPRING	4				0	0
031	66704-83500	ASSY COVER, SEAT	1			REF.No.003, 032 AND 033	0.4	0.88
032	35110-85050	EYE-LET	4				0.005	0.011
033	35110-85060	PROTECTOR	3				0.01	0.022

MidWestTech | Kubota B8200DP Tractor Parts Manual | Publication B8200DP
Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	67800-53750	ASSY PIPE, FUEL OVER	1			REF.No.002, 003	0.02	0.044
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	10244-42320	CLIP, PIPE	2				0.001	0.0022
004	67211-58323	ASSY PIPE, FUEL OVER	1	>=54116		REF.No.005, 006	0.03	0.066
005	99999-99999	BLANK	0			ORDER BY REF.No.004	0	0
006	10244-42320	CLIP, PIPE	2	>=54116			0.001	0.0022
007	67061-58350	ASSY PIPE, FUEL	1			REF.No.008 TO 010	0.04	0.088
008	99999-99999	BLANK	0			ORDER BY REF.No.007	0	0
009	14301-42750	CLIP, PIPE	2				0.005	0.011
010	67111-53790	SPRING, PIPE PROTECT	1				0.01	0.022
011	67211-58340	ASSY PIPE, FUEL 1	1			REF.No.012 TO 014	0	0
012	99999-99999	BLANK	0			ORDER BY REF.No.011	0	0
013	14301-42750	CLIP, PIPE	2				0.005	0.011
014	67111-53790	SPRING, PIPE PROTECT	1				0.01	0.022

MidWestTech | Kubota B8200DP Tractor Parts Manual | Publication B8200DP Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	66301-55100	ASSY WIRE HARNESS	1	<=61102		[A] REF.No.002 TO 007	0.57	1.254
001	66301-55102	ASSY WIRE HARNESS	1	>=61103		[A] REF.No.002 TO 007	0.4	0.88
001	67820-55100	ASSY WIRE HARNESS	1	<=53759		[CA] REF.No.002 TO 006, 032 TO 034	0	0
001	66321-55100	ASSY WIRE HARNESS	1	>=53760		[CA] REF.No.002 TO 007, 032 TO 034	0.92	2.024
001	66321-55102	ASSY WIRE HARNESS	1	>=61103		[CA] REF.No.002 TO 007, 032 TO 034	0.8	1.76
002	67800-55112	WIRE HARNESS 1	1	<=61102			0.26	0.572
002	67061-55150	WIRE HARNESS 1	1	>=61103			0	0
003	67800-55120	WIRE HARNESS 2	1	<=61102		REF.No.004	0.12	0.264
003	67800-55122	WIRE HARNESS 2	1	>=61103		REF.No.004	0.125	0.275
004	67111-55190	RING, FUSIBLE	1				0.005	0.011
005	67800-55130	WIRE HARNESS 3	1				0.125	0.275
006	67800-55140	WIRE HARNESS 4	1				0.06	0.132
007	66301-55150	WIRE HARNESS, F.GAUGE	1				0.02	0.044
008	67800-55160	ASSY SWITCH, STARTER	1			REF.No.009, 010	0.28	0.616
009	66711-55140	KEY	2				0	0
010	66711-55130	SWITCH, STARTER	1				0.241	0.5302
011	35110-32420	PLUG	1				0.002	0.0044
012	15531-65950	INDICATOR, GLOW PLUG	1				0.05	0.11
013	01050-50512	BOLT	2				0.003	0.0066
014	04512-50050	WASHER, SPRING	2				0	0
015	02054-50050	NUT	2				0.002	0.0044
016	54617-41140	SWITCH, LIGHT	1				0.08	0.176
017	55311-41120	SWITCH, HAZARD LIGHT	1				0.05	0.11
018	66908-54750	GAUGE, FUEL	1				0.15	0.33
019	67800-55400	ASSY METER, HOUR	1				0	0
020	67800-55410	CABLE, HOUR METER	1				0.25	0.55
021	67800-55420	SPACER, HOUR METER	1				0.008	0.0176
022	67800-55450	ASSY MONITOR, OK	1			REF.No.023	0.12	0.264
023	67111-55460	BULB	2				0.005	0.011
024	67800-55460	SPACER, OK MONITOR	1				0.015	0.033
025	15533-64600	ASSY REGULATOR	1			[A]	0.2	0.44
026	03014-50630	SCREW	2			[A]	0.006	0.0132
027	04012-50060	WASHER, PLAIN	2			[A]	0.001	0.0022
028	04512-50060	WASHER, SPRING	2			[A]	0	0
029	35170-33700	UNIT, FLASHER	1				0.06	0.132
030	01202-50620	BOLT	1				0.007	0.0154
031	04013-50060	WASHER, PLAIN	1				0	0
032	67820-55150	HARNESS, ALTERNATOR 1	1			[CA]	0	0
033	67820-55160	HARNESS, ALTERNATOR 2	1			[CA]	0.108	0.2376
034	66907-55190	TUBE	1			[CA]	0.001	0.0022
035	33251-74010	ASSY REGULATOR	1			[CA]	0.35	0.77
036	37300-33430	CUSHION	1			[CA]	0.1	0.22
037	37300-33420	COVER, REGULATOR	1			[CA]	0.07	0.154
038	01053-50616	BOLT	2			[CA]	0.005	0.011
039	04015-50060	WASHER, PLAIN	2			[CA]	0	0

MidWestTech | Kubota B8200DP Tractor Parts Manual | Publication B8200DP
Order the manual at mid-west-tech.com >