ILLUSTRATED PARTS LIST

KUBOTA

B8200HST-DP

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	67115-5700	ASSY LAMP,HEAD	2			REF.No.002 TO 004	0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	67111-55780	SOCKET	2				0.03	0.066
004	67111-55790	BULB	2				0.01	0.022
005	01202-50616	BOLT	4				0.006	0.0132
006	04013-50060	WASHER,PLAIN	4				0	0
007	15241-67570	CLAMP,CORD	1				0.003	0.0066
008	67401-54250	GASKET,LAMP	1				0.01	0.022
009	35450-75010	ASSY LAMP,FLASHER	2			[A],[CA] REF.NO.010	0.3	0.66
010	35450-75022	BULB	2			[A],[CA]	0.008	0.0176
011	34350-34100	ASSY LAMP,TAIL	2			[A],[CA] REF.No.012 TO 014	0.13	0.286
012	99999-99999	BLANK	0			ORDER BY REF.No.011 [A],[CA]	0	0
013	34350-34120	LENS	2			[A],[CA]	0.05	0.11
014	34350-34140	BULB	2			[A],[CA]	0.008	0.0176
015	33251-75860	ASSY LAMP,PLATE	1			[U] REF.No.016 TO 018	0.075	0.165
016	99999-99999	BLANK	0			[U] ORDER BY REF.No.015	0	0
017	36200-75830	BULB,LAMP	1			[U]	0.015	0.033
018	99999-99999	BLANK	0			[U] ORDER BY REF.No.015	0	0
019	04512-50040	WASHER,SPRING	2			[U]	0	0
020	02054-50040	NUT	3			[U]	0.001	0.0022
021	66706-55730	ASSY FLASHER LAMP, R	2			[U] REF.No.022 TO 026	0.34	0.748
022	66706-55910	SOCKET	2			[U]	0.192	0.4224
023	66706-55920	BULB 21W	2			[U]	0.01	0.022
024	66706-55930	BULB 5W	2			[U]	0.01	0.022
025	66706-55940	LENS	2			[U]	0.15	0.33
026	66706-55950	BOLT	4			[U]	0.004	0.0088
027	35171-34200	ASSY FLASHER LAMP, F	2			[U] REF.No.028 TO 032	0.37	0.814
028	66706-55910	SOCKET	2			[U]	0.192	0.4224
029	66706-55920	BULB 21W	2			[U]	0.01	0.022
030	66706-55930	BULB 5W	2			[U]	0.01	0.022
031	35171-34210	LENS	2			[U]	0.15	0.33
032	66706-55950	BOLT	4			[U]	0.004	0.0088
033	67840-55510	SUPPORT	2			[U]	0.35	0.77
034	01202-50614	BOLT	4			[U]	0.006	0.0132
035	02014-50060	NUT	4			[U]	0.003	0.0066
036	67880-55140	ASSY HORN	1			[U] REF.No.037 TO 039	0.49	1.078
037	66706-55710	HORN	1			[U]	0.37	0.814
038	67880-55160	STAY,HORN	1			[U]	0.09	0.198
039	01123-50828	BOLT	2			[U]	0.014	0.0308
040	67840-45910	STAY,COUPLER	1			[U]	0.07	0.154
041	01123-50814	BOLT	2			[U]	0	0
042	36200-77390	CAP	1			[U]	0.008	0.0176
043	66706-55230	ASSY COUPLER	1			[U]	0.014	0.0308

MidWestTech | Kubota B8200HST-DP Tractor Parts Manual | Publication B8200HST-DP Order the manual at mid-west-tech.com >

FRONT WHEEL (24 X 8.50-12) [B8200HST-DPT]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	67810-57500	ASSY FRONT WHEEL	1			REF.No.002,013	31	68.2
002	67810-57510	ASSY FRONT WHEEL LH	1			REF.No.003,005	16	35.2
003	67810-57530	TIRE,RUBBER	1			REF.No.004	7.6	16.72
004	34159-11850	VALVE,TIRE	1				0.013	0.0286
005	67800-57560	ASSY WHEEL	1			REF.No.006,009 TO 012	8.15	17.93
006	67800-57520	WHEEL	1			REF.No.007,008	7.9	17.38
007	67800-57540	RIM 1	1				3.88	8.536
008	67800-57550	RIM 2	1				3.92	8.624
009	35260-11860	GASKET	1				0.065	0.143
010	01173-51022	BOLT	8				0.019	0.0418
011	04512-50100	WASHER,SPRING	8				0	0
012	02118-50100	NUT	8				0.005	0.011
013	67810-57570	ASSY FRONT WHEEL RH	1			REF.No.014,016	16	35.2
014	67810-57530	TIRE,RUBBER	1			REF.No.015	7.6	16.72
015	34159-11850	VALVE,TIRE	1				0.013	0.0286
016	67800-57560	ASSY WHEEL	1			REF.No.017,020 TO 023	8.15	17.93
017	67800-57520	WHEEL	1			REF.No.018,019	7.9	17.38
018	67800-57540	RIM 1	1				3.88	8.536
019	67800-57550	RIM 2	1				3.92	8.624
020	35260-11860	GASKET	1				0.065	0.143
021	01173-51022	BOLT	8				0.019	0.0418
022	04512-50100	WASHER,SPRING	8				0	0
023	02118-50100	NUT	8				0.005	0.011
024	04013-50120	WASHER,PLAIN	12				0	0
025	04512-50120	WASHER,SPRING	12				0.003	0.0066
026	02174-50120	NUT	12				0.01	0.022

MidWestTech | Kubota B8200HST-DP Tractor Parts Manual | Publication B8200HST-DP Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	66301-36110	ASSY HST-ACC	1	<=60401		EP REF.No.002,051	0	0
001	66301-11602	ASSY HST	1	>=50001		EP REF.No.003 TO 041,051	0	0
002	66301-36142	ASSY HST	1	<=60401		EP REF.No.003 TO 041	23	50.6
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
006	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
007	66301-39310	SHAFT (P)	1				0.93	2.046
008	66301-39320	SHAFT (M)	1				0.82	1.804
009	66301-39350	FLANGE	1				0.42	0.924
011	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
012	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
013	66301-39520	PIN	2				0.002	0.0044
014	66301-39530	PIN	2				0.005	0.011
015	66301-39540	PIN	1				0.01	0.022
016	66301-39580	NAME,PLATE	1				0	0
017	66301-39590	SCREW	2				0	0
018	66301-39610	SCREW	6				0.005	0.011
019	66301-39620	PLUG	1				0.04	0.088
020	66301-39670	RING,SNAP	1				0.015	0.033
021	04612-00250	CIR-CLIP, EXTERNAL	1				0.002	0.0044
022	04611-00450	CIR-CLIP,INTERNAL	1				0.01	0.022
023	04611-00620	CIR-CLIP,INTERNAL	1				0.011	0.0242
024	01350-10520	BOLT	2				0.004	0.0088
025	01315-11055	BOLT	2				0.04	0.088
026	01315-11040	BOLT	6				0.031	0.0682
027	66301-39810	WASHER,SPRING	8				0.002	0.0044
029	66301-39840	FLANGE	1				0.12	0.264
030	01350-10512	BOLT	2				0.003	0.0066
032	66301-39930	PLUG	1				0.07	0.154
033	66301-83100	ASSY BLOCK, CYL.(P)	1			REFER TO 0E08-L0 FOR FIG.	1.88	4.136
034	66301-83200	ASSY BLOCK, CYL.(M)	1			REFER TO 0E08-L0 FOR FIG.	2.65	5.83
035	66301-83300	ASSY COVER (A)	1			REFER TO 0E08-L0 FOR FIG.	0.58	1.276
036	66301-83400	ASSY COVER (B)	1			REFER TO 0E08-L0 FOR FIG.	0.63	1.386
037	66204-84400	ASSY VALVE, REL-CASE	1			REFER TO 0E08-L0 FOR FIG.	0.02	0.044
038	66301-83600	ASSY VALVE, NEUTRAL	1			REFER TO 0E08-L0 FOR FIG.	0.112	0.2464
039	66301-83700	ASSY VAL.L-P.RELIEF	1			REFER TO 0E08-L0 FOR FIG.	0.03	0.066
040	66301-83800	ASSY VALVE, RELIEF	1			REFER TO 0E08-L0 FOR FIG.	0	0
041	66301-84100	KIT SEAL	1			REF.No.042 TO 050	0.1	0.22
042	66301-39550	GASKET	1				0.005	0.011
043	66301-39560	SEAL,OIL	2				0.02	0.044
044	66301-39490	SEAL,OIL	1				0.02	0.044
045	66301-39510	SEAL,OIL	1				0.02	0.044
046	66301-39830	SEAL	2				0.002	0.0044
047	66301-35630	SEAL	4			REFER TO L.No.0E08-R0 FOR FIG.	0.005	0.011
048	04811-00180	O RING	3				0.001	0.0022

MidWestTech | Kubota B8200HST-DP Tractor Parts Manual | Publication B8200HST-DP Order the manual at mid-west-tech.com >