ILLUSTRATED PARTS LIST

KUBOTA

BX23D

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2561-11130	SAHFT BRAKE DISK	1				0.05	0.11
020	K2561-11310	SHAFT CLUTCH	1				0.33	0.726
030	08101-06005	BEARING BALL	1				0.157	0.3454
040	08101-06204	BEARING BALL	1				0.102	0.2244
050	04612-00200	CIR CLIP EXTERNAL	1				0.001	0.0022
060	37410-75320	RING SEAL	1				0.01	0.022
070	K2561-11320	GEAR	1			13T	0.12	0.264
080	K2561-11330	COLLAR SPACER	1				0.08	0.176
090	K2561-11340	GEAR CLUTCH	1			12T	0.001	0.0022
100	08821-82213	BEARING NEEDLE	2				0.009	0.0198
110	K2561-11353	CASE CLUTCH	1				0.56	1.232
120	04816-05190	O RING	2				0.002	0.0044
130	K2561-11363	PISTON CLUTCH	1				0.26	0.572
140	37410-75370	D RING	1				0.002	0.0044
150	34070-15250	DISK CLUTCH	4				0.04	0.088
160	TA040-69070	PLATE	2				0.036	0.0792
170	TA040-69080	PLATE	2				0.036	0.0792
180	TA040-69090	RUBBER	6				0.001	0.0022
190	37410-75430	PLATE PRESSURE	1				0.065	0.143
200	04611-00920	CIR CLIP INTERNAL	1				0.04	0.088
210	K2561-13933	BOSS SPLINE CLUTCH	1				0.26	0.572
220	K2561-13960	BEARING BALL	1				0.03	0.066
230	K2561-13970	CIR-CLIP INTERNAL	1				0.004	0.0088
240	K2561-11390	COLLAR BEARING	1				0.005	0.011
250	K2561-11373	SPRING CLUTCH	1				0.045	0.099
260	K2561-11383	COLLAR SPRING	1				0.022	0.0484
270	04612-00220	CIR CLIP EXTERNAL	1				0.001	0.0022
280	K2561-13910	DISK BRAKE	1				0.06	0.132
290	K2561-13922	PRESSURE PLATE BRAKE	1				0.18	0.396
300	04612-00600	CIR CLIP EXTERNAL	2				0.012	0.0264
310	K2561-13940	SHIM BRAKE	2			0.5mm	0.005	0.011

MidWestTech | Kubota BX23D Tractor Parts Manual | Publication BX23D_2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2561-12110	SHAFT 4WD	1				0.26	0.572
020	08101-06004	BEARING BALL	1				0.065	0.143
030	K2561-12120	BEARING NEEDLE	1				0.02	0.044
040	09500-20428	SEAL OIL	1				0.012	0.0264
050	04611-00420	CIR CLIP INTERNAL	1				0.006	0.0132
060	04612-00200	CIR CLIP EXTERNAL	2				0.001	0.0022
070	K2561-12130	GEAR FWD SELECT	1			19T	0.2	0.44
080	67910-12330	COLLAR	1				0.006	0.0132
090	K2561-14310	SHAFT FWD DRIVE	1				1.47	3.234
100	K2561-14320	COUPLING FWD	1				0.15	0.33
110	07715-01605	BALL	4				0.003	0.0066
120	K2561-14330	COLLAR COUPLING	1				0.05	0.11
130	04612-00280	CIR CLIP EXTERNAL	1				0.003	0.0066
140	04817-00160	O RING	1				0.001	0.0022
150	K2561-16810	ASSY JOINT UNIVERSAL	1				0.63	1.386
160	K2561-16820	ASSY JOINT UNIVERSAL	1				0.73	1.606
170	K2561-16830	SHAFT DRIVE FRONT	1				0.69	1.518
180	05411-00650	PIN SPRING	1				0.006	0.0132
190	K2561-16780	PIN JOINT	2				0.01	0.022
200	04013-60060	WASHER PLAIN	2				0.001	0.0022
210	K2561-16790	PIN SPLIT	2				0.002	0.0044
220	15875-24320	RING SNAP	2				0.003	0.0066
230	08141-06304	BEARING BALL	1				0.142	0.3124
240	K2561-16890	HOLDER BEARING	2				0.256	0.5632
250	01123-50820	BOLT	3				0.011	0.0242
260	99999-99999	BLANK	0				0	0
270	02114-50080	NUT	3				0.005	0.011
280	01133-51230	BOLT	2				0.04	0.088
290	99999-99999	BLANK	0				0	0
300	02174-50120	NUT	2				0.01	0.022
310	K2511-16850	COVER JOINT	1				0.05	0.11
320	01025-50612	BOLT	1				0.005	0.011

MidWestTech | Kubota BX23D Tractor Parts Manual | Publication BX23D_2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2571-65250	LABEL 4WD	2				0.002	0.0044
020	99999-99999	NAME PLATE ROPS	1				0	0
030	K6072-63910	RIVET BLIND BLACK	4				0.002	0.0044
040	K2561-65263	LABEL HYD ADJUST	1				0.001	0.0022
045	K2567-65660	LABEL DIFF.LOCK	1				0	0
050	K2561-65200	LABEL SET	1				0.016	0.0352
060	K2561-65270	LABEL GUIDE LH	1			NOT SALE	0	0
070	K2561-65280	LABEL GUIDE RH	1			NOT SALE	0	0
080	K2591-65390	LABEL COVER	1				0	0
090	K2567-65405	LABEL SET CA	1				0.045	0.099
100	K2567-65482	LABEL SAFETY	1			NOT SALE	0	0
110	K2567-65520	LABEL SPACE WARNING	2			NOT SALE	0	0
120	K2567-65540	LABEL PTO WARNING	1			NOT SALE	0	0
130	K2567-65550	LABEL ADJUST CAUTION	1			NOT SALE	0	0
140	K2567-65560	LABEL HITCH WARNING	1			NOT SALE	0	0
150	K2567-65570	LABEL ROPS WARNING	1			NOT SALE OUT OF USE	0	0
160	K2561-65622	LABEL SHIFT LEVER	1			NOT SALE	0	0
170	K2561-65405	LABEL SET	1				0.022	0.0484
180	K2561-65440	LABEL DIFF.LOCK	1			NOT SALE	0	0
190	K2561-65450	LABEL	1			NOT SALE	0	0
200	K2561-65460	LABEL ADJUSTPOSITION	1			NOT SALE	0	0
210	K2561-65482	LABEL SAFETY	1			NOT SALE OUT OF USE	0	0
220	K2561-65490	LABEL FUEL	1			NOT SALE	0	0
230	K2561-65522	LABEL SPACE WARNING	2			NOT SALE OUT OF USE	0	0
240	K2561-65540	LABEL PTO WARNING	1			NOT SALE OUT OF USE	0	0
250	K2561-65550	LABEL ADJUST CAUTION	1			NOT SALE OUT OF USE	0	0
260	K2561-65560	LABEL HITCH WARNING	1			NOT SALE OUT OF USE	0	0
270	K2561-65570	LABEL ROPS WARNING	1			NOT SALE OUT OF USE	0	0
280	K2597-65640	LABEL CAUTION(ROPS)	1				0.01	0.022
290	K2597-65570	LABEL WARNING(ROPS)	1				0.008	0.0176
300	K2591-65410	LABEL REFLECTOR	2				0.01	0.022

MidWestTech | Kubota BX23D Tractor Parts Manual | Publication BX23D_2 Order the manual at mid-west-tech.com >