CEAM022901

Operation & Maintenance Manual

960E-1

DUMP TRUCK

SERIAL NUMBERS **A30025 - A30026**

KOMATSU®

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

INTRODUCTION **10-1**

FOREWORD 10-1
TRUCK MODEL ILLUSTRATION 10-2
ABOUT THIS MANUAL 10-3
ALERTS PAGE 10-4
TABLE OF CONTENTS 10-5

TORQUE TABLES AND CONVERSION CHARTS **12-1**

SAFETY **20-1**

GENERAL 20-1
Safety Rules 20-1
Safety Features 20-1
Fire Extinguishers And First Aid Kit 20-1
Clothing And Personal Items 20-1
Leaving The Operator Seat 20-2
Mounting And Dismounting 20-2
Fire Prevention For Fuel And Oil 20-2
Precautions With High Temperature Fluids 20-3
Asbestos Dust Hazard Prevention 20-3
Prevention Of Injury By Work Equipment 20-3
Unauthorized Modification 20-3
ROPS Precautions 20-3
Precautions For Attachments 20-4
Precautions For Starting The Truck 20-4
PRECAUTIONS BEFORE OPERATING THE TRUCK 20-4
Safety At The Work Site 20-4
Fire Prevention 20-5
Ventilation In Enclosed Areas 20-5
Preparing For Operation 20-5
Mirrors, Windows, And Lights 20-5
In The Operator Cab (Before Starting The Engine) 20-5
Seal Belts 20-5
PRECAUTIONS WHILE OPERATING THE TRUCK 20-6
When Starting The Engine 20-6
General Truck Operation 20-6
Ensuring Good Visibility 20-6

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (cont.)

Traveling 20-7
Traveling In Reverse 20-7
Traveling On Slopes 20-7
Operating On Snow Or Ice 20-7
Avoiding Damage To The Dump Body 20-7
Driving Near High Voltage Cables 20-8
When Dumping 20-8
When Loading 20-8
Working On Loose Ground 20-8
Parking The Truck 20-8
Towing 20-8
WORKING NEAR BATTERIES 20-9
Battery Hazard Prevention 20-9
Starting With Booster Cables 20-9
PRECAUTIONS BEFORE PERFORMING SERVICE 20-10
Stopping The Engine 20-10
Warning Tag 20-10
Proper Tools 20-10
Securing The Dump Body 20-10
PRECAUTIONS WHILE PERFORMING SERVICE 20-11
Keeping The Truck Clean 20-11
Attachments 20-11
Working Under The Truck 20-11
Rotating Fan And Belts 20-11
Waste Materials 20-11
Adding Fuel Or Oil 20-12
Radiator Coolant Level 20-12
Use Of Lighting 20-12
Precautions With The Battery 20-12
Handling High Pressure Hoses 20-12
Precautions With High Pressure Oil 20-12
Performing Maintenance Near High Temperature Or High Pressure 20-12
TIRES 20-13
Handling Tires 20-13
Storing Tires After Removal 20-13
PRECAUTIONS FOR PERFORMING REPAIRS 20-14
Engine Shutdown Procedure After AC Drive System Failure 20-14
PRECAUTIONS FOR WELDING ON THE TRUCK 20-15

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (cont.)

CAPACITOR DISCHARGE SYSTEM 20-16
Necessary Tools 20-16
Warnings And Cautions 20-17
Manual DC Link Capacitor Discharge Procedure 20-18
Failure of the Discharge System 20-20
Manual Discharge of Capacitors 20-21
Short Isolated Capacitor Terminals 20-23

WARNINGS AND CAUTIONS 22-1

OPERATING INSTRUCTIONS 30-1

PREPARING FOR OPERATION 30-1
WALK AROUND INSPECTION 30-1
ENGINE START-UP 30-5
AFTER ENGINE START-UP 30-6
EMERGENCY STEERING SYSTEM 30-6
Operation 30-6
Pre-Operation Testing 30-6
PRECAUTIONS DURING TRUCK OPERATION 30-7
OPERATING ON A HAUL ROAD 30-8
STARTING ON A GRADE WITH A LOADED TRUCK 30-9
SUDDEN LOSS OF ENGINE POWER 30-9
FUEL DEPLETION 30-10
TOWING 30-10
Special Wiring Harness 30-11
LOADING THE DUMP BODY 30-13
Overload Speed Limit Function 30-13
DUMPING A LOAD 30-14
Raising The Dump Body 30-14
Lowering The Dump Body (On Flat Ground) 30-15
Lowering The Dump Body (Over A Berm Or Into A Crusher) 30-15
DISABLED TRUCK DUMPING PROCEDURE 30-16
Hookup 30-16
Raising the Body 30-16
Lowering the Body 30-16
SAFE PARKING PROCEDURE 30-17
NORMAL ENGINE SHUTDOWN PROCEDURE 30-17

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio...
Order the manual at mid-west-tech.com >

Manual discharge of capacitors

If the voltage is greater than 1V on any of the capacitors, the capacitor must be manually discharged. With a suitable capacitor discharge device, such as ground stick pair (PC3299), discharge the capacitors where needed per the following instructions:

1. With the control cabinet high voltage compartment doors closed, connect the ground stick pair ground lead to ground. The most convenient location is the middle top bolt that attaches the door center post to the control cabinet frame.
2. Verify the ground connection and ground stick resistance levels. Measure the resistance between each individual ground stick tip to either the GND1 or GND2 ground block in the low voltage compartment of the control cabinet using a multimeter (Figure 20-9). Ensure that the resistance is within the manufacturer's specifications for the ground sticks.

   For PC3299 grounding sticks, the valid range is 80 to 125 ohms per stick.

⚠WARNING

Hazardous voltages are present in this equipment. Avoid touching any energized equipment when the door to the low voltage area is open. Failure to do so may result in personal injury and equipment damage.

3. Discharge the relevant capacitors. Open the door(s) and place one grounding stick on one of the positive (+) capacitor terminals and the other on the diagonally located negative (-) terminal. Refer to Figure 20-8 and Figure 20-10. Attempt to minimize the time between application of the positive stick and the negative stick so that the current flow will be positive to negative rather than either to ground. Leave sticks in place until capacitors are discharged. Refer to Figure 20-10.

NOTE: On the capacitors located behind the door post, it is difficult to access diagonal terminals on the same capacitor. If using adjacent terminals, use care to keep the tips separated while discharging or else use a positive terminal on one capacitor and negative terminal of the adjacent capacitor on the same bus bar.

For PC3299 grounding sticks, the discharge times from 2000 volts are:

- 15 seconds (maximum) for 2 capacitors
- 75 seconds (maximum) for 10 capacitors




FIGURE 20-9. GROUNDING STICK LEAD CONNECTION AND CHECK

Order the manual at mid-west-tech.com >

INSTRUMENT PANEL

The operator must understand the function and operation of each instrument and control. Control functions are identified with "international" symbols that the operator should learn to recognize immediately. This knowledge is essential for proper and safe operation.

Items that are marked "optional" do not apply to every truck.

Control Symbols

Many control functions are identified with international symbols that the operator should learn to recognize immediately. The operator must understand the function and operation of each instrument and control. This knowledge is essential for proper and safe operation of the machine.

The following symbols are general indicators and may appear in multiple locations and combinations on the instrument panel.



This symbol may be used alone or with another symbol. This symbol identifies the OFF position of a switch or control.



This symbol when it appears on an indicator or control identifies that this indicator or control is NOT used.



This symbol may be used alone or with another symbol. This symbol identifies the ON position of a switch or control.



This symbol identifies a rotary control or switch. Rotate the knob clockwise or counterclockwise for functions.



This symbol identifies the "Pushed-In" position of a push-pull switch or control.



This symbol identifies a switch used to test or check a function. Press the switch on the side near the symbol to perform the test.



This symbol identifies the "Pulled-Out" position of a push-pull switch or control.

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

1000 HOUR LUBRICATION AND MAINTENANCE CHECKS

Every *10 Hour (Daily) Inspection*, *250 Hour* and *500 Hour Lubrication and Maintenance Check* should also be performed at this time.

NOTE: "Lube Key" references are to the ***Lubrication Chart*** *on page 40-9.*

Truck Serial Number_____ **Site Unit Number**_____ **Date**_____

Hourmeter_____ **Name of Service Technician**_____

	TASK	COMMENTS	CHECKED	INITIALS
1.	HYDRAULIC TANK - Drain the hydraulic tank and clean the inlet strainer. Refill the tank with approximately 947 L (250 gal) of oil. Use Lube Key "B".			
2.	COOLING SYSTEM - Drain the cooling system. Clean the cooling system with a quality cleaning compound. Flush with water. Refill the system with anti-freeze and water solution. Refer to the Cooling Specifications on page 40-2 for the correct mixture.			
3.	FUEL TANK - Remove the breather and clean it in solvent. Dry it with pressurized air and reinstall.			
4.	OPERATOR'S SEAT - Apply grease to the slide rails. Use Lube Key "D".			
5.	AUTOMATIC BRAKE APPLICATION - Ensure that the brakes are automatically applied when brake pressure decreases below the specified limit. Refer to the shop manual for instructions.			
5.	BRAKE DISC WEAR INSPECTION - Use the front and rear brake wear indicators included in the truck's tool group to check for brake disc wear. Refer to the shop manual for instructions.			
6.	AUTO LUBE PUMP HOUSING OIL LEVEL - Remove the plug on the auto lube pump housing and check the oil level. The oil level should be at the bottom of the fill port. Add oil if necessary. Use Lube Key "C".			

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

Failure of the discharge system

If the capacitor charge lights remain illuminated, a failure of the normal (fast) capacitor discharge system (RP discharge path) has likely occurred. The slow discharge resistors that are hard wired across the DC link should then discharge the capacitors. The slow discharge resistors will discharge the DC link to less than 1 VDC in under 7.5 minutes. If after 7.5 minutes, the capacitor charge lights are still illuminated, it must be assumed that the automatic discharge system is not working and that high voltage is present in the high voltage area.

1. Open the high voltage area doors.
2. With a suitable high voltage meter rated for at least 2000 VDC, such as PC3186 or equivalent, plus suitable protective equipment, measure the voltage across each of the DC link capacitors. Place one meter lead on the positive (+) capacitor terminal, and the other meter lead on the negative (-) capacitor terminal, and observe the voltage. See Figure 20-7 and Figure 20-8. If the voltage is less than 1.0 V the capacitor is sufficiently discharged. Repeat on all DC Link capacitors. If the voltage of any capacitor is above 1.0 V, manually discharge the capacitor as described in "Manual discharge of capacitors" on page 20-21.



FIGURE 20-7. DC METER ON CAPACITOR




FIGURE 20-8. CAPACITOR TERMINAL POLARITY

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

Setting the Computer Subnet Mask and IP Address

If the adaptor software does not allow for setting an IP address, then this must be done manually.

The Windows TCP/IP settings must be modified for the correct subnet mask and an adequate IP address. The steps to reach the point where the TCP/IP settings can be modified vary according to the operating system and are described below. The actual steps for making the changes to the settings are described for the following operating systems.

Windows 2000:

1. Click on the start menu, select settings and then "Network and Dial-up Connections."
2. Right click on the wireless network adaptor and select "properties." Skip instructions for other Operating Systems and continue to the topic of "Properties".

Windows XP:

1. Click on the start menu, right click on "My Networks" and select "Properties." A window with all available networks will be shown.
2. Right click on the wireless network and select "Properties." Skip instructions for Windows Vista and continue to the topic of "Properties".




FIGURE 32-15. RESET LOCATION

1. Komatsu Wireless Bridge
2. Reset Button Hole

Windows Vista:

1. Click on the Windows menu, right click on "Network" then select "Properties." A window will open with the option "Manage network connections" as one of the options on the left side. Select that option.
2. A new window showing all available networks will open. Right click on the wireless network to be used to connect to the KWB and select "Properties." Vista will inquire if this was an intentional selection; select "Continue." Continue to the topic of "Properties".

Properties

Once the window with the list of available protocols is shown, the TCP/IP should then be selected. Click on "Properties" and bring up a window for setting the IP address and the subnet mask (alternatively, double click on TCP/IP). Before making any changes, write down the current settings. These settings will be needed to restore the original computer settings if needed.

3. Select "Use the following IP address," then set the IP address to 192.168.0.xxx, where xxx represents any number between 1 and 255. 123 is generally used. However, no two computers should use the same IP address). The subnet mask should now be set to 255.255.0.0. If a gateway address is requested, this is set to the same as the IP address.

This prepares the computer to communicate with the KWB and to interact with the automatic download software.

NOTE: The previous steps are not necessary if the software that comes with the computer/adaptor allows an IP address and mask to be assigned to each profile. This is done automatically by selecting the profile.
It may be necessary to repeat these steps to restore the computer settings when connecting to another network.

MidWestTech | Komatsu 960E-1 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >