Operation & Maintenance Manual

Dump Truck

960E-2

Serial Numbers A30027 — A30106

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

INTRODUCTION
FOREWORD 1-2
ABOUT THIS MANUAL 1-3
WARNINGS 1-4
California Proposition 65 Warnings 1-4
ALERTS 1-5
TRUCK MODEL ILLUSTRATION 1-6
NON-OEM PARTS IN CRITICAL SYSTEMS 1-7
STANDARD CHARTS AND TABLES
GENERAL INFORMATION 2-2
Effect Of Special Lubricants 2-2
Suggested Sources For Rust Preventive Grease 2-2
STANDARD TIGHTENING TORQUES 2-3
Class 10.9 Capscrews And Class 10 Nuts 2-3
SAE Grade 5 And Grade 8 Capscrews 2-4
SAE Grade 9 Capscrews 2-5
T-Bolt Clamps 2-5
Split Flange Clamps 2-6
Flared Tube And Hose Fittings 2-6
JIC 37° Swivel Nuts 2-7
Pipe Thread Fittings 2-8
O-Ring Boss Fittings 2-9
O-Ring Face Seal Fittings 2-10
CONVERSION MULTIPLIERS 2-11
Metric To English 2-11
English To Metric 2-12
Temperature Conversions 2-13
GENERAL SAFETY
GENERAL SAFETY 3-2
Safety Rules 3-2
Truck Safety Features 3-2
Clothing And Personal Items 3-2
Unauthorized Modification 3-2
Leaving The Operator's Seat 3-2
Mounting And Dismounting 3-2
Fire Extinguishers And First Aid Kits 3-3
Precautions For High Temperature Fluids 3-3
Asbestos Dust Hazard Prevention 3-3
Fire Prevention 3-3
ROPS Precautions 3-3
Preventing Injury From Work Equipment 3-4
Precautions For Optional Attachments 3-4
Precautions When Starting The Machine 3-4
PRECAUTIONS FOR TRUCK OPERATION 3-5
Safety Is Thinking Ahead 3-5
Safety At The Worksite 3-5
Preparing For Operation 3-5
Ventilation For Enclosed Areas 3-5
Mirrors, Windows, And Lights 3-5
Before Starting The Engine 3-5
Seat Belts And Tethers 3-5
Emergency Egress Ladders 3-6
OPERATING THE MACHINE 3-7
General Information 3-7

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

Starting The Engine 3-7
Traveling In The Machine 3-7
Traveling In Reverse 3-7
Traveling On Slopes 3-8
Traveling On Snow 3-8
Traveling Near High Voltage Cables 3-8
Traveling On Loose Ground 3-8
Ensuring Good Visibility 3-8
Avoid Damage To The Dump Body 3-8
Safe Parking Of The Machine 3-9
Loading The Machine 3-9
Dumping The Machine 3-9
Towing The Machine 3-9
EXTERIOR LIGHTING 3-10
Fog Lights 3-10
Headlights 3-10
Ladder Lights and Deck Mounted Flood Lights 3-10
Mirror Mounted Backup Lights 3-10
Brake Light 3-10
Retard Light 3-11
Clearance/Turn Signal Lights 3-11
Backup Lights 3-11
Retard Lights 3-11
Brake Lights 3-11
Backup Alarm 3-11
PRECAUTIONS FOR MAINTENANCE 3-12
BEFORE PERFORMING MAINTENANCE 3-12
Securing The Dump Body 3-12
DURING MAINTENANCE 3-13
Warning Tag 3-13
Proper Tools 3-13
Attachments 3-13
Working Under The Machine 3-13
Keeping The Machine Clean 3-13
Adding Fuel Or Oil To The Machine 3-13
Radiator Coolant Level 3-14
Use Of Lighting 3-14
Handling High Pressure Hoses 3-14
Precautions With High Pressure Oil 3-14
Maintenance Near High Temperatures And High Pressures 3-14
Rotating Fan And Belts 3-14
Waste Materials 3-14
Use Of Tie-Off Anchor During Maintenance 3-15
Handling Tires 3-15
Tire Maintenance 3-15
Storing Tires After Removal 3-15
Battery Hazard Prevention 3-16
Jump Starting With Jumper Cables 3-16
Jump Starting With Receptacles 3-17
WHEN REPAIRS ARE NECESSARY 3-18
Observe The Following Precautions 3-18
SPECIAL PRECAUTIONS 3-19
Preliminary Procedures Before Welding Or Performing Maintenance 3-19
Engine Shutdown Procedure Before Welding or Performing Maintenance 3-19

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

Before Welding On The Machine, Obey The Following Guidelines: 3-19
Discharging Control Cabinet Capacitors 3-20
WARNING AND CAUTIONS
GENERAL INFORMATION 4-2
PIN PLATE 4-2
GRADE SPEED CHART 4-3
MACHINE SAFETY 4-3
KEY SWITCH 4-5
OIL FILL AND CHECK 4-5
HIGH PRESSURES 4-6
BATTERY AND ENGINE SHUTDOWN 4-9
HIGH VOLTAGE 4-11
WELDING 4-14
LIFTING POINTS 4-15
EMERGENCY DUMPING 4-16
ROPS/FOPS 4-17
TOWING 4-17
LUBRICATION CHART 4-17
OPERATING INSTRUCTIONS
PREPARING FOR OPERATION 5-2
Safety Is Thinking Ahead 5-2
Walk Around Inspection 5-2
RETRACTABLE LADDER SYSTEM (If Equipped) 5-7
General Information 5-7
Ladder System Description 5-7
Ladder System Operation 5-7
In-Cab Control Panel 5-8
Ground Level Control Box 5-10
Emergency Down Valve 5-10
PRE-SHIFT BRAKE TEST 5-11
OPERATION 5-11
Service Brake Test 5-12
Parking Brake Test 5-12
Retard System Test 5-13
Brake Test Exit Criteria 5-13
TRUCK OPERATION 5-14
ENGINE START-UP SAFETY 5-14
After Engine Has Started 5-14
MACHINE OPERATION SAFETY PRECAUTIONS 5-15
Machine Operation On The Haul Road 5-16
Starting On A Grade With A Loaded Truck 5-16
Retarding On A Grade 5-16
Passing 5-17
Loading 5-17
Overload Speed Limit Function 5-18
Dumping 5-18
Lowering The Dump Body (When Dumping On Flat Ground) 5-19
Lowering The Dump Body (When Dumping Over A Berm Or Into A Crusher) 5-19
SUDDEN LOSS OF ENGINE POWER OR LOSS OF DRIVE SYSTEM FUNCTION 5-20
EMERGENCY STEERING SYSTEM 5-20
Operation 5-20
Pre-Operation Testing 5-21
Additional Guidelines 5-21
FUEL DEPLETION 5-22

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

GENERAL INFORMATION E.2-0000051234

This manual provides dual dimensioning for many specifications. Metric units are specified first, with U.S. standard units in parentheses. When torque values are not specified in the assembly instructions contained in this manual, use the standard torque value for the hardware being used. Standard value torque tables are contained in this chapter for metric and SAE hardware.

This truck is assembled with both metric and SAE (U.S.) hardware. Reference the correct table when determining the proper torque value.

⚠ CAUTION

- **References throughout the manual to standard torques or other standard values will be to one of the following tables. Do not use standard values to replace specific torque values in assembly instructions.**

For values not shown in any of the charts or tables, standard conversion factors for most commonly used measurements are provided in the following tables.

Effect Of Special Lubricants

The Komatsu engineering department does not recommend the use of special friction-reducing lubricants, such as Copper Coat, Never-Seez®, and other similar products, on the threads of standard fasteners where standard torque values are applied. The use of special friction-reducing lubricants will significantly alter the clamping force being applied to fasteners during the tightening process.

If special friction-reducing lubricants are used with the standard torque values listed in this chapter, excessive stress and possible breakage of the fasteners may result.

Where the torque tables specify "Lubricated Threads" for the standard torque values listed, these standard torque values are to be used with simple lithium base chassis grease (multi-purpose EP NLGI) or a rust-preventive grease (see below) on the threads and seats unless specified otherwise.

NOTE: *Ensure the threads of fasteners and tapped holes are free of burrs and other imperfections before assembling.*

Suggested Sources For Rust Preventive Grease

NOTE: *This list represents the current engineering approved sources for use in Komatsu manufacture. It is not exclusive. Other products may meet the same specifications of this list.*

- American Anti-Rust Grease #3-X from Standard Oil Company (also American Oil Co.)
- Gulf NoRust #3 from Gulf Oil Company.
- Mobilarma 355, Product No. 66705 from Mobil Oil Corporation.
- Rust Ban 326 from Humble Oil Company.
- Rustolene B Grease from Sinclair Oil Co.
- Rust Preventive Grease - Code 312 from the Southwest Grease and Oil Company.

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

A ground level engine stop switch is also located at the right or left front corner of the truck, depending on ladder access.


Window Control Switches

The window control switch (5, 6) controls the operation of the window. The switch is spring-loaded to the OFF position.

- Pushing the front of the switch raises the cab window.
- Pushing the rear of the switch lowers the window.

Hoist Control Lever

Hoist control lever (7) is a four position hand-operated lever located between the operator seat and the center console (see Figure 6-4 HOIST CONTROL, page 6-7).



1. Raise
2. Hold
3. Float
4. Lower

Figure 6-4 HOIST CONTROL

Raising The Dump Body

1. Pull the hoist control lever to the rear to actuate hoist circuit. (Releasing the lever anywhere during "hoist up" will place the body in HOLD at that position.)
2. Raise engine rpm to increase hoist speed.
3. Reduce engine rpm as the last stage of the hoist cylinders begin to extend and then let the engine go to low idle as the last stage reaches half-extension.
4. Release hoist control lever as the last stage reaches full extension.
5. After material being dumped clears the body, lower the body to frame.

   Refer to Dumping, page 5-18 for more complete details concerning this control.

Lowering The Dump Body

Move hoist control lever forward to DOWN position and release. Releasing the lever places hoist control valve in the FLOAT position allowing the body to return to frame.

Retard Speed Control (RSC) Adjust Dial

The retard speed setting will be displayed to the operator on the digital display in the instrument panel.

Retard speed control (RSC) adjust dial (8) allows the operator to vary the downhill truck speed that the retard speed control system will maintain when descending a grade. This function can be overridden by the throttle pedal, retarder lever, or brake/retarder pedal.

When the dial is rotated counterclockwise toward this symbol, the truck will descend a grade at lower speeds.



When the dial is rotated clockwise toward this symbol, the truck speed will increase.



Always refer to the Grade/Speed Chart in the operator's cab and follow the recommendations for truck operation. DO NOT exceed these recommended MAXIMUM speeds when descending grades with a loaded truck.

Throttle pedal position will override RSC setting. If operator depresses throttle pedal to increase truck speed, dynamic retarding will not come on unless truck over speed setting is reached or the brake/retarder pedal (or retarder lever) is used. When throttle pedal is released and RSC switch is on, dynamic retarding will come on at, or above, the RSC dialed speed and will adjust truck speed to, and maintain, the dialed speed. The dialed speed will be displayed on the digital display in the instrument panel.


MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

EVERY 3000 HOUR LUBRICATION AND MAINTENANCE A.1-0000061694

NOTE: *Maintenance for every 10, 250, 500 & 1,000 hour Lubrication and Maintenance Checks must also be performed at this time. "Lube Key" references are to the lubrication chart.*

EVERY 3000 HOUR MAINTENANCE	
Item	**Task**
WHEEL MOTOR OIL	Change or filter the wheel motor gear oil. The oil must be filtered/changed prior to 3000 hours if oil analysis indicates contaminated oil.

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >




1. HVAC Recirculation Filter Element

Figure 7-7 HVAC RECIRCULATION FILTER LOCATION

1. Clean both filter elements (1, Figure 7-6 CAB AIR FILTER LOCATION, page 7-5 and Figure 7-7 HVAC RECIRCULATION FILTER LOCATION, page 7-6) with mild soap and water.
2. Rinse completely clean and air dry with a maximum of 275 kPa (40 psi).
3. Reinstall the filters.

FUEL SYSTEM SERVICE G.33-0000051601

Fuel Tank Cleaning




1. Fuel Tank Drain

Figure 7-8 FUEL TANK

Open fuel tank drain (1, Figure 7-8 FUEL TANK, page 7-6) to drain water and sediment from the fuel tank. The fuel tank is provided with a drain and a cleaning port in the side that allows steam or solvent to be utilized in cleaning tanks that have accumulated foreign material.

It is not necessary to remove the tank from the truck for cleaning of sediment, however rust and scale on the walls and baffles may require complete tank removal. Prior to a cleaning procedure of this type, all vents, fuel gauge, and hose connections should be removed and temporarily sealed. After all scale, rust, and foreign material has been removed, the temporary plugs can be removed. A small amount of light oil must be sprayed into the tank to prevent rust if the tank is to remain out of service. All openings should be sealed for rust prevention.




1. Fuel Tank Breather

Figure 7-9 FUEL TANK BREATHER

Remove breather (1, Figure 7-9 FUEL TANK BREATHER, page 7-6) and clean in solvent. Dry with pressurized air and reinstall.

Fuel Filter Service



1. Water Drain Valves

Figure 7-10 WATER SEPARATOR DRAIN

Open water drain valves (1, Figure 7-10 WATER SEPARATOR DRAIN, page 7-6) to remove water from the fuel/water separators daily.

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >

Lubricant Required For Automatic Lubrication System

Grease requirements will depend on ambient temperatures encountered during truck operation:

- Above 32°C (90°F) - Use NLGI No. 2 multipurpose grease (MPG).
- -32° to 32°C (-25° to 90°F) - Use NLGI No. 1 multipurpose grease (MPG).
- Below -32°C (-25°F) - Refer to local supplier for extreme cold weather lubricant requirements.


Priming The Automatic Lubrication System

The system must be full of grease and free of air pockets to function properly. After maintenance, if primary or secondary lubrication lines were replaced, it will be necessary to prime the system to eject all entrapped air.



1. Vent Valve
2. Main Supply Line

Figure 5-18 AUTO LUBE MAIN SUPPLY LINE



1. Injector Indicator
2. Injector Grease Zerk
3. Injector Cover
4. Injector Grease Zerk Cap
5. Injector Manifold Plug

Figure 5-19 INJECTOR MANIFOLD

To prime the main supply lines, perform the following:

1. Fill lube reservoir with lubricant, if necessary.
2. Remove injector manifold plug (5, Figure 5-19 INJECTOR MANIFOLD, page 5-50) from injector manifold. Always start with the injector manifold closest to the pump. The last grease line to be purged should be the main grease line to the rear axle (longest grease line).
3. Disconnect main supply line (2, Figure 5-18 AUTO LUBE MAIN SUPPLY LINE, page 5-50) from vent valve (1). Connect an external grease supply to main supply line (2).
4. Pump grease in main supply line (2) until grease appears at the injector manifold plug.
5. Re-install the injector manifold plug. Repeat for remaining injector groups.

After all main supply lines are purged of air, the injector circuits must now be primed.

To prime the secondary supply lines, perform the following:

1. If necessary, disconnect an injector grease line from the component that particular injector supplies grease to.
2. Remove injector grease zerk cap (4) from each injector and connect an external grease supply to injector grease zerk (2) on the injector.
3. Pump grease into the injector until grease appears at the far end of the individual grease line or the joint being greased.
4. Reconnect injector grease line to the component, remove the external grease supply, and reinstall injector grease zerk cap.
5. Repeat steps 1 through 4 until all secondary supply lines have been primed.
6. After all grease lines are primed, use the override switch to cycle the automatic lubrication pump a few times to lube the components.

PREVENTIVE MAINTENANCE PROCEDURES E.6-0000051465

Use the following maintenance procedures to ensure proper system operation.

Daily Lubrication System Inspection

1. Check the grease reservoir level after each shift of operation. Grease usage should be consistent from day-to-day operations. Lack of lubricant usage would indicate an inoperative system. Excessive usage would indicate a broken supply line.

MidWestTech | Komatsu 960E-2 Dump Truck Operation & Maintenance Manual | Publicatio... Order the manual at mid-west-tech.com >