CEAMG58101

Operation & Maintenance Manual

830
850
870

MOTOR GRADER

SERIAL NUMBERS 200000 and up

KOMATSU®

October 1993

MidWestTech | Komatsu 830, 850, 870 Motor Grader Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

This manual covers instructions for operation, lubrication, adjustments and maintenance for normal daily care. These instructions are divided into five sections to simplify your reference to the information most important to you. Refer to contents page at the beginning of each section for a complete listing of subjects covered except for Section 1, which should be read entirely.

This manual has been prepared to help you operate and maintain your machine with utmost efficiency and safety. Read this manual thoroughly and learn your machine before you attempt to operate it. If this machine is used by an employee or is loaned, rented, or leased, be certain that the operator reviews this manual and is instructed in safe and proper use.

Section-Page

SAFETY PRECAUTIONS 1-1

INTRODUCTION 2-1
- GENERAL 2-1
- P.I.N. NUMBER LOCATIONS 2-2
- MACHINE SHIPPING 2-4
- MACHINE TRANSPORT 2-6
  - GENERAL 2-6
  - SHIPPING (LONG DISTANCE) 2-6
    - TRUCK 2-6
    - RAILROAD FLATCAR 2-6
    - DRIVING 2-7
  - MOVING A DISABLED MACHINE 2-7
    - METHODS OF TOWING 2-8
      Method One (2-8); Method Two (2-9); Method Three (2-9)
- MACHINE STORAGE 2-11
  - PREPARING FOR STORAGE 2-11
  - SERVICING MACHINE DURING STORAGE 2-13
    - ONE-MONTH REPETITIVE SERVICE PERIOD 2-13
    - SIX-MONTH REPETITIVE SERVICE PERIOD 2-14
  - PREPARING FOR OPERATION 2-14
- ROLLOVER PROTECTIVE STRUCTURE 2-16
- THEFT DETERRENT PRACTICES 2-16
  - ACTION TO DISCOURAGE THEFT AND VANDALISM 2-16
  - ACTIONS TO AID IN RECOVERY OF STOLEN MACHINES 2-16

OPERATING 3-1
- PREPARATION FOR USE 3-1
- UNIVERSAL SYMBOLS FOR INSTRUMENTS AND CONTROLS 3-2
- OPERATION UNDER NORMAL CONDITIONS 3-3
  - OPERATIONAL CONTROLS AND INSTRUMENTATION 3-3
    - OPERATOR'S CAB AND CONTROLS 3-4
    - CONTROL VALVE LEVERS 3-5
      R.H. Control Lever Bank (Standard Machine) (3-6)
    - L.H. Control Lever Bank (Standard Machine) 3-6
    - FOOT CONTROLS 3-7
      Decelerator Pedal (3-7); Foot Brake Pedal (3-7); Accelerator Pedal (3-7); Inching Pedal (3-7)

MidWestTech | Komatsu 830, 850, 870 Motor Grader Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Section-Page

STEERING CONSOLE CONTROLS AND GAUGES 3-8
Instrument Panel (3-8); Turn Signals & Emergency Flashers Lever (3-12); Horn Button - The horn button is located in the center of (3-13); Console Release Lever (3-13); Hour Meter (3-13); Steering Wheel Tilt Knob (3-14); Audible Alarm (Standard for Engine Coolant and Hydraulic Oil Pressure) (Optional) (3-14)
SHIFT CONSOLE AND CONTROLS 3-15
Transmission Gear Range Lever and Engine Speed Control Lever (3-15); Shift Console Controls (3-16)
HEATER AND WIPER CONTROLS 3-19
Instrument Panel Light (3-19); Heater Control Lever (3-19); Heater Blower Switch (3-20); Instrument Panel Light (3-20); Front Upper Wiper Switch (3-20); Front Lower Wiper Switch (Optional) (3-20); Rear Wiper Switch (3-20); Upper Front/Rear Washer Button (Optional) (3-20); Lower Front Washer Button (Optional) (3-20); Air Pressurization Recirculation Vents (Optional - Non-Air Conditioned Cabs) (3-20)
OPERATOR'S SEATS 3-21
Ridged Seat (Standard) (3-21); Suspension Seat (Optional) (3-21); Seat Belt (3-22)
DOME LIGHTS AND FANS 3-22
Front Dome Light (3-22); Front (Standard) and Rear (Optional) Fans (3-23)
"AWD" (ALL WHEEL DRIVE) CONTROL MODULE (OPTIONAL) 3-23
MISCELLANEOUS GAUGES AND VALVES 3-24
Hydraulic Oil Tank Sight Gauge (3-24); Parking/Emergency Brake Release Valve (3-24); Fuel Tank Shutoff Valve (3-24); Flow Control Adjustment Valve (9040 Series Control Valves) (3-25)
ACCESS COVERS, HOOD SIDES AND DOORS 3-25
Fuel Tank and Hydraulic Oil Tank Access Covers - Two (3-25); Radiator Access Cover (3-25); Engine Hood Sides (Optional) (3-26); Cab Doors (3-26); Lower Opening Front Cab Windows (3-26); Tool Box (3-27)
INTERACTING CONTROLS 3-27
PUSH STARTING & TOWING 3-28
BEFORE STARTING ENGINE 3-29
ENGINE STARTING 3-30
ENGINE WARM-UP 3-31
WHILE WARMED-UP - ENGINE RUNNING ABOVE IDLE 3-31
PARKING GRADER 3-32
ENGINE SHUTDOWN 3-32
AFTER SHUTTING DOWN THE ENGINE 3-32
OPERATION UNDER UNUSUAL CONDITIONS 3-33
OPERATION IN EXTREME COLD 3-33
OPERATION IN EXTREME HEAT 3-34
OPERATION IN DUSTY OR SANDY AREAS 3-35
OPERATION IN RAINY OR HUMID CONDITIONS 3-35
OPERATION IN SALT WATER AREAS 3-35
OPERATION AT HIGH ALTITUDES 3-35

MidWestTech | Komatsu 830, 850, 870 Motor Grader Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Section-Page

OPERATION OF AUXILIARY/OPTIONAL ACCESSORIES 3-36
HYDRAULIC LOCK/UNLOCK DIFFERENTIAL 3-36
AIR CONDITIONING 3-37
ALL WHEEL DRIVE (AWD) 3-38
APPLICATION AND GENERAL DESCRIPTION 3-38
USE OF ALL WHEEL DRIVE (AWD) 3-38
OPERATIONAL CHECKS 3-39
BATTERY CHARGING RECEPTACLE 3-39
COLD WEATHER STARTING AID 3-39
PRECAUTIONS 3-39
ETHER STARTING AID 3-40
STARTING PROCEDURES 3-40
PREVENTIVE MAINTENANCE 3-40
Changing the Fluid Container (3-40); Inspection and Cleaning (3-41)
ENGINE BLOCK HEATER 3-41
FIRE EXTINGUISHER 3-41
TO OPERATE 3-41
MAINTENANCE 3-42
RECHARGE 3-42
RECORDS 3-42
WEIGHT 3-42
HYDRAULIC ACCUMULATOR (DRAWBAR AND CIRCLE OPTION) 3-43
ACCUMULATOR P/N 1279 537 H1 3-43
MASTER SWITCH 3-44
FRONT MOUNTED SCARIFIER AND REAR MOUNTED RIPPER 3-44
FRONT MOUNTED SCARIFIER SETUP 3-45
REAR MOUNTED RIPPER SETUP 3-46
Rear Mounted Ripper with Ripper Shanks (3-46); Rear Mounted Ripper with Scarifier Shanks (3-47)
RIPPER TOOTH REPLACEMENT 3-48
SCARIFIER TOOTH REPLACEMENT 3-48
REAR MOUNTED RIPPER EQUIPPED WITH A HITCH PIN 3-48
APPLICATION 3-50
LEANING WHEELS 3-50
USE OF LEANING WHEELS IN STEERING 3-50
SURFACE WORK 3-51
ARTICULATION 3-51
USE OF ARTICULATION IN STEERING 3-52
BANKSLOPING 3-53
SADDLE PIN INDICATORS 3-53
R.H. BIAS BLADE SUSPENSION 3-54
Recommendation for 45° Extended Reach Right (3-54); Recommendation for 90° Bankslope Right (3-55)
R.H. & L.H. 90 DEGREE BLADE SUSPENSION 3-55
Recommendation for 45° Extended Reach Right (3-55); Recommendation for 90° Bankslope Right (3-56); Recommendation for 45° Extended Reach Left (3-56); Recommendation for 90° Bankslope Left (3-57)
CIRCLE REVERSE 3-58
BLADE TILT 3-59
DITCHING 3-60
SNOW REMOVAL 3-62

MidWestTech | Komatsu 830, 850, 870 Motor Grader Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >