CEBM011200

Shop Manual

KOMATSU®

830B
850B
870B
830C
850C
870C

MOTOR GRADER

	830B	203163
	830C	202753
	850B	202575
SERIAL NUMBERS	850C	202727 and UP
	870B	202599
	870C	202775

This material is proprietary to Komatsu America Corp/ and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America Corp.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, periodic revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

October 2003
Printed in USA

Copyright 2003 Komatsu
DataKom Publishing Division

Order the manual at mid-west-tech.com >

CONTENTS

01	GENERAL	01-1
10	STRUCTURE AND FUNCTION	10-1
20	TESTING, ADJUSTING AND TROUBLESHOOTING	20-1
30	DISASSEMBLY AND ASSEMBLY	30-1
40	MAINTENANCE STANDARD	40-1
90	OTHER	90-1

MidWestTech | Komatsu 830B, 850B, 870B, 830C, 850C, 870C Motor Grader Service Manu... Order the manual at mid-west-tech.com >

PRODUCT PUBLICATIONS INFORMATION

Various product Parts and Service Publications are available to all **KOMATSU** construction equipment owners, including operation and maintenance manuals, parts books and service manuals.

Special publications, such as service tool, air conditioning and turbocharger service manuals are also available as well as selected Operation and Service manuals in foreign languages.

The Publications listed below are available for this particular machine(s).


DESCRIPTION	FORM NUMBER
PARTS BOOK - PAPER:	
Chassis and Engine 830B/C	BEPB002801
Chassis and Engine 850B/C	BEPBG58612
Chassis and Engine 870B/C	BEPBG78100
OPERATION AND MAINTENANCE MANUAL:	
Chassis and Engine	CEAM009800
SHOP MANUAL	
Chassis	CEBM011200
Engine 114E-2 Series	CEBM000601
Engine 102E-2 Series	SEBM010016
SAFETY MANUAL	
Machine specific	1085 960 R2

Parts and Service Publications can *only* be acquired by authorized KOMATSU distributors using the Komatsu America Corp. Extranet Literature Ordering System.

If the Extranet Literature Ordering System is not available at the distributor location, then the following Requisition for Technical Service Publications and Service Forms can be used. Form KDC91E is shown on the reverse side of this page. Komatsu America Corp. reserves the right to add a surcharge to all fax orders.

MidWestTech | Komatsu 830B, 850B, 870B, 830C, 850C, 870C Motor Grader Service Manu... Order the manual at mid-west-tech.com >

LEGEND



A. FLOATING BODY
B. CHECK POPPET ASSEMBLY
C. CHECK SEAT/VALVE SPOOL ASSEMBLY
D. CHECK SPRING
E. MAJOR BIAS SPRING
F. PILOT PASSAGE

Remark


The valve action discussed is for moving the circle to the right.

At right, a cutaway view of a counterbalance valve. Positive internal-piloting pressure from supply line "**V2**", opposite the controlled (counterbalanced) line "**C1**". Utilized with the load-induced pressure from line "**C1**", pressure against the check valve seat end of the spool opens the valve. With the pilot-assist feature, internal pilot pressure from supply line "**V2**" effectively reduces the pressure setting of the valve by allowing pilot pressure through pilot passage (F). This pressure forces the check seat and valve spool assembly (C) against the major bias spring (E). The loaded machine member is restrained until pressure is available from the opposite cylinder line "**C1**". That means the actuator cannot move faster than the speed resulting from the pressurized supply (pump) fluid in line "**V2**". This action permits smooth, positive control of overrunning loads and cushioned deceleration. This positive control of overrunning loads occurs due to a pressure drop that takes place during the overrun condition in the supply pilot line "**V2**". This action allows the major bias spring (E) to move the valve spool assembly to the right, closing the valve.

MidWestTech | Komatsu 830B, 850B, 870B, 830C, 850C, 870C Motor Grader Service Manu... Order the manual at mid-west-tech.com >

TRANSMISSION POWER SHIFT

TRANSMISSION SHIFTER



When the LED flashes an error code, the transmission automatically shifts to Neutral despite the gearshift remaining at the selected position. Thus, the machine cannot move.

Move the gearshift to the Neutral position to coincide with the transmission being in neutral, and which also clears the controller's memory. After clearing the controller's memory, the transmission gears can once again be engaged.

To determine if the problem is a "glitch" or one-time occurrence, reposition the gearshift to the desired gear range and continue with the operation. If the LED flashes again, count the number of flashes because a problem exists. See the table Section 20-100 TRANSMISSION SHIFTER for a diagnostic interpretation of the LED flash code, and make the needed repairs. After repairing the problem, clear the controller's memory before returning the machine to service.

PIN USAGE

PIN#	USAGE	OTHER NAME
1	Logic power	Logic power (+BATT)
2	Logic ground	Logic ground (-BATT)
3	Solenoid power	Dirty power (+BATT)
4	Solenoid power	
5	Solenoid ground	Dirty ground (-BATT)
6	Solenoid ground	
7	Solenoid S4	Drive S4
8	Not park	
9	Not used	
10	De-clutch pedal	Communication input 3
11	Not used (CAN/H)	
12	Variable horsepower	Drive S8
13	Solenoid S3	Drive S3
14	Not used (J1708/A)	
15	Not used (J1708/B)	
16	Parking brake	Communication input 1
17	Not used (CAN/L)	
18	Reverse signal	Communication output 1
19	Forward signal	Communication output 2
20	Solenoid S2	Drive S2
21	Solenoid S1	Drive S1
22	Solenoid S5	Drive S5
23	Solenoid S6	Drive S6
24	Neutral START	Drive S7

MidWestTech | Komatsu 830B, 850B, 870B, 830C, 850C, 870C Motor Grader Service Manu... Order the manual at mid-west-tech.com >

PRESSURE TEST

After completing the brake pedal adjustments, perform a hydraulic pressure check to assure that the adjustments are correct.

1. Connect a calibrated 2,000 psi (140.6 kg/cm²) gauge to the test port fitting.
2. Start the engine.
3. With the engine running and the brake pedal (2) released, the gauge should register 0 psi (0.0 kg/cm²).

   _____ psi with the Brake Pedal Released
4. Depress the brake pedal (2) against the pedal stop bolt (5). The gauge should register 1160 ±75 psi (81.5 ±5.3 kg/cm²).

   _____ psi with the Brake Pedal Applied
5. Turn the engine off.
6. If both pressure readings are correct, remove the pressure gauge. If the pressure readings do not meet specifications, readjust the pedal linkage as done previously.
7. Connect a calibrated 50 psi (3.5 kg/cm²) gauge.

WARNING! Do not depress the brake pedal with the 50 psi (3.5 kg/cm^2) gauge installed.

8. Start the engine.
9. With the brake pedal (2) released, the pressure should register 0 psi (0.0 kg/cm²). However, if the pressure increases:

   A. Loosen the jamnut at the rubber bumper (4).


   B. Turn the bumper (4) CW to increase the 1.50 in (38.1 mm) Dimension until pressure equals 0.0 (0.0 kg/cm²), then increase an additional 0.060 in (1.52 mm).

   C. Tighten the jamnut.

   _____ psi with Brake Pedal Released _____ psi with Brake Pedal Applied
10. Turn the engine off and make the adjustments.
11. Recheck the brake system until the proper readings are obtained.

MidWestTech | Komatsu 830B, 850B, 870B, 830C, 850C, 870C Motor Grader Service Manu... Order the manual at mid-west-tech.com >

REVISED ELECTRICAL DIAGRAM (Sheet 1 Part 2 of 2)



MidWestTech | Komatsu 830B, 850B, 870B, 830C, 850C, 870C Motor Grader Service Manual | Publication CEBM011200 Order the manual at mid-west-tech.com >