DG723

Operation & Maintenance Manual

830E

DUMP TRUCK

SERIAL SUFFIX **AFE32-DK & Up**
With MTU Engine

KOMATSU®

MidWestTech | Komatsu 830E Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT . . . . . **SECTION / PAGE**

INTRODUCTION . . . . . **SECTION 1**
Foreword 1-1
ALERTS Page - a description of the DANGER, WARNING, and CAUTION symbols used in this manual. . . . 1-2
TABLE OF CONTENTS 1-3
Truck Model Illustration 1-6
About This Manual 1-7
STANDARD CHARTS and TABLES 1-9

SAFETY . . . . . **SECTION 2**

Safety records of most organizations will show that the greatest percentage of accidents are caused by unsafe acts of persons. The remainder are caused by unsafe mechanical or physical conditions. Report all unsafe conditions to the proper authority. These safety rules are provided as a guide for the HAULPAK® operator. However, local conditions and regulations may add many more to this list.

General Safety Rules 2-1
SAFETY IS THINKING AHEAD 2-1
Safe practices start before the operator gets to the equipment! 2-1
At The Truck - Ground Level Inspection 2-1
Preparing For Operation 2-2
Truck Operation 2-2
Additional Job Site Rules 2-3
WHEN REPAIRS ARE NECESSARY 2-4
WARNING, CAUTION, and Instruction Plates / Decals 2-5

OPERATION . . . . . **SECTION 3**

This portion of the manual covers identification, location,and operation of the controls, switches, and indicators in the Operator's Cab and use / function of these controls, switches, and indicators.

OPERATING INSTRUCTIONS
Preparing For Operation 3-1
Safety Is Thinking Ahead 3-1
At The Truck - Ground Level Walk-Around Inspection 3-1
Walk-Around Inspection - Illustration 3-2
ENGINE START-UP SAFETY PRACTICES 3-4
AFTER ENGINE HAS STARTED 3-5
MACHINE OPERATION SAFETY PRECAUTIONS 3-5
LOADING 3-6
HAULING 3-6
PASSING 3-6
DUMPING 3-7
TOWING 3-8
SAFE PARKING PROCEDURES 3-8
ENGINE SHUTDOWN PROCEDURE 3-9
DELAYED ENGINE SHUTDOWN PROCEDURE (OPTIONAL) 3-9

MidWestTech | Komatsu 830E Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (Continued)

SUBJECT . . . . . **SECTION / PAGE**

OPERATION (Continued) . . . . . **SECTION 3**

OPERATOR CAB and CONTROLS 3-11
THROTTLE PEDAL 3-11
DYNAMIC RETARDER PEDAL 3-11
SERVICE BRAKE PEDAL 3-11
HOIST CONTROL LEVER 3-11
CENTER CONSOLE 3-12
SELECTOR SWITCH 3-12
RETARD SPEED CONTROL (RSC) SWITCH 3-12
RETARD SPEED CONTROL (RSC) ADJUST DIAL 3-12
OVER-RIDE PUSH BUTTON 3-13
ENGINE IDLE SWITCH 3-13
STEERING WHEEL AND CONTROLS 3-14
OPERATOR SEAT 3-15
OPTIONAL ISRINGHAUSEN OPERATOR SEAT 3-16
INSTRUMENT PANEL AND INDICATOR LIGHTS 3-17
Control Symbols 3-17
INSTRUMENT PANEL (Figure 3-7) 3-18
PANEL GAUGES, INDICATORS, AND CONTROLS (Discussion of Items 1 - 38, Figure 3-7) . . . 3-19 thru 3-28

MAINTENANCE . . . . . **SECTION 4**

This portion of the manual pertains mainly to the periodic Lubrication and Service required to keep the truck operating at its design potential. Routine lubrication and maintenance procedures are provided in this section. For major repairs, refer to the appropriate section in the Truck Service Manual.
Refer to the engine manufacturer's service manual when servicing the engine.

Lubrication and Service 4-1
Lubrication Chart 4-2
10 HOUR (SHIFT) Lubrication And Maintenance Checks 4-3
50 HOUR Lubrication And Maintenance Checks 4-4
100 HOUR Lubrication And Maintenance Checks 4-5
250 HOUR Lubrication And Maintenance Checks 4-6
500 HOUR Lubrication And Maintenance Checks 4-7
1000 HOUR Lubrication And Maintenance Checks 4-7
5000 HOUR Lubrication And Maintenance Checks 4-8

Lincoln Automatic Lubrication System (OPTIONAL) 4-9
Operation 4-9
Components 4-9
24 VDC Solid State Timer Checkout & Adjustment 4-10
Injectors & Adjustment 4-10
General Instructions 4-11
Lubricant Required 4-11
Initial Reservoir Fill 4-11
System Priming 4-11
System Checkout 4-12
Troubleshooting Chart 4-13

MidWestTech | Komatsu 830E Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >