DG756

Operation & Maintenance Manual

730E

DUMP TRUCK

SERIAL NUMBERS 730E A30123 – A30180

KOMATSU®

April 2000

MidWestTech | Komatsu 730E Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT . . . . . **SECTION / PAGE**

INTRODUCTION . . . . . **SECTION 1**
- Foreword 1-1
- ALERTS Page - a description of the DANGER, WARNING, and CAUTION symbols used in this manual. . . . 1-2
- TABLE OF CONTENTS 1-3
- Truck Model Illustration 1-6
- About This Manual 1-7
- STANDARD CHARTS and TABLES 1-9

SAFETY . . . . . **SECTION 2**

Safety records of most organizations will show that the greatest percentage of accidents are caused by unsafe acts of persons. The remainder are caused by unsafe mechanical or physical conditions. Report all unsafe conditions to the proper authority. These safety rules are provided as a guide for the Haulpak truck operator. However, local conditions and regulations may add many more to this list.

- General Safety Rules 2-1
- PRECAUTIONS DURING OPERATION 2-5
  - Before Starting Engine 2-5
  - Operating Machine 2-6
  - Battery 2-9
  - Towing 2-10
- PRECAUTIONS FOR MAINTENANCE 2-11
  - Before carrying out Maintenance 2-11
  - During Maintenance 2-12
  - Tires 2-15
- ADDITIONAL JOB SITE RULES 2-16
- WHEN REPAIRS ARE NECESSARY 2-17
- WARNING, CAUTION, and Instruction Plates / Decals 2-19

OPERATION . . . . . **SECTION 3**

This portion of the manual covers Identification, location,and operation of the controls, switches, and indicators in the Operator's Cab and use / function of these controls, switches, and indicators.

- OPERATING INSTRUCTIONS
  - Preparing For Operation 3-1
  - Safety Is Thinking Ahead 3-1
  - At The Truck - Ground Level Walk-Around Inspection 3-1
- ENGINE START-UP SAFETY PRACTICES 3-4
- AFTER ENGINE HAS STARTED 3-5
- MACHINE OPERATION SAFETY PRECAUTIONS 3-6
- LOADING 3-7
- HAULING 3-7
- PASSING 3-8
- DUMPING 3-8

MidWestTech | Komatsu 730E Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (Continued)

SUBJECT . . . . . **SECTION / PAGE**

OPERATION (Continued) . . . . . **SECTION 3**

TOWING 3-10
SAFE PARKING PROCEDURES 3-10
SHUTDOWN PROCEDURE 3-11
OPERATOR CAB and CONTROLS 3-13
STEERING WHEEL AND CONTROLS 3-14
SERVICE BRAKE PEDAL 3-15
DYNAMIC RETARDER PEDAL 3-15
THROTTLE PEDAL 3-15
HEATER / AIR CONDITIONER VENTS 3-15
HEATER / AIR CONDITIONER COMPARTMENT AND CONTROLS 3-16
OVER HEAD PANEL AND DISPLAYS 3-17
CENTER CONSOLE 3-18
OPERATOR SEAT 3-22
INSTRUMENT PANEL AND INDICATOR LIGHTS 3-23
Control Symbols 3-23
INSTRUMENT PANEL (Figure 3-6) 3-24
PANEL GAUGES, INDICATORS, AND CONTROLS (Discussion of items 1 - 28, Figure 3-6) 3-25
OVERHEAD STATUS / WARNING INDICATOR LIGHT PANEL (Figure 3-7) 3-30
INDICATOR LIGHT SYMBOLS - Refer to Figure 3-7 by rows (A-E) and columns (1 - 8). 3-31
Hazard Warning Lights (9) 3-37
Lamp Test Switch / Centry™ Diagnostic Test Switch (10) 3-37
CUMMINS ENGINE CENTRY™ FUEL SYSTEM DIAGNOSTICS 3-38
DETERMINING "FAULT" CODES 3-38
EXITING THE DIAGNOSTICS MODE 3-39

MAINTENANCE . . . . . **SECTION 4**

This portion of the manual pertains mainly to the periodic Lubrication and Service required to keep the truck operating at its design potential. Routine lubrication and maintenance procedures are provided in this section. For major repairs, refer to the appropriate section in the Truck Service Manual.
Refer to the engine manufacturer's service manual when servicing the engine.

Lubrication and Service 4-1
Lubrication Chart 4-2
10 HOUR (SHIFT) Lubrication And Maintenance Checks 4-3
50 HOUR Lubrication And Maintenance Checks 4-4
100 HOUR Lubrication And Maintenance Checks 4-5
250 HOUR Lubrication And Maintenance Checks 4-6
500 HOUR Lubrication And Maintenance Checks 4-7
1000 HOUR Lubrication And Maintenance Checks 4-7
5000 HOUR Lubrication And Maintenance Checks 4-8

Lincoln Automatic Lubrication System (OPTIONAL) 4-9
System Components 4-9
System Operation 4-11
General Instructions 4-12
Lubricant Required 4-12
Initial Reservoir Fill 4-12
System Priming 4-12
System Checkout 4-13

MidWestTech | Komatsu 730E Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (Continued)

SUBJECT . . . . . **SECTION / PAGE**

MAINTENANCE (Continued) . . . . . **SECTION 4**
24 VDC Solid State Timer Checkout & Adjustment 4-13
Injectors & Adjustment 4-14
Pump Cycle ("Flasher") Timer, Installation & Adjustment 4-14

Troubleshooting Chart **4-17**

SPECIFICATIONS . . . . . **SECTION 5**

This portion of the manual covers major component descriptions and truck specifications.
Major Component Descriptions 5-1
Specifications 5-3

OPTIONAL EQUIPMENT . . . . . **SECTION 6**
This portion of the manual covers operation/maintenance of OPTIONAL EQUIPMENT.

PAYLOAD METER II (Refer to separate PAYLOAD METER II Index) 6-1
RADIO, AM/FM STEREO CASSETTE 6-35

MidWestTech | Komatsu 730E Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >