W14 Loader

Parts Catalog

E1211

CASE CONSTRUCTION

MidWestTech | Case W14 Loader Parts Catalog | Publication E1211

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accelerator and Backhoe throttle 63,63B
Air Cleaner 59
Alternator 35
  Mounting And Adjusting Strap 35,43
Axle Assemblies 93B
  Axle Brakes 107
  Axle Housing 103
  Front Axle Differential 95-97D
  Planetary 103,105
  Rear Axle Differential 99-101D
Axle Mounting 103,105

B

Backhoe - 26C, see parts catalog #1207
Backhoe Related Parts 53B,61B,63B,151B
Backup Alarm 89B
Battery 51
  Cables 51
Beacon, rotating 171,173
Belts
  Alternator 43
  Compressor 43
  Seat 159
Block, engine cylinder 17,17B
Block Heater 17,17B
Brake Assemblies And Circuits
  Air Compressor and Related Parts 113-121
  Air Pressure Protection Valve 127,135
  Alcohol Evaporator 115
  Axle Brake 107
  Brake Valve 129
  Emergency Brake To Safety Chamber . 111,111B
  Governor, air compressor 121
  Master Cylinder 131
  Master Cylinder To Wheel Cylinders 125
  Parking Brake, transmission 77
  Treadle Assembly 129
  Treadle To Master Cylinder And Reservoir 123
  Treadle To Hydraulic Tank And Horn 127
Buckets
  Standard 177
  Teeth 177,179
  4-in-1 Bucket 179,179B

C

Cab, operators 165-165H
Camshaft, engine 13B
Clutch, transmission 71,73,75
Cold Starting System (Ether injection) 55
Compartment, operators 159
Compressor, air 113-121
Connecting Rods, engine 21,21B
Control Levers
  Clutch Cutout 123
  Loader Height And Leveling 203
  Loader Lift And Dump 199,201
  Pedal, accelerator 63
  Pedal, brake (Treadle) 123,127,129
  Transmission 87,89
Crankshaft, engine 19,19B
Cushions, seat 159
Cylinders, brake
  Master 123,131
  Slave 107
Cylinders, hydraulic
  Bucket Clam 195,195B
  Bucket Dump 193,193B
  Loader Lift 191,191B
  Steering 145

D

Decals
  Bucket (4-in-1) 179
  Engine Data 13
  Kit 217,219
Defroster, cab 167
Defroster, fan 167B
Dipsticks
  Engine Oil 17
  Hydraulic Tank 155
  Transmission Oil 85
Drive shaft
  Center Bearing 91
  Front, axle end 91
  Front, transmission end 93
  Rear 93

E

Electrical Systems
  Bucket Height 203
  Cab Wiring 165-169
  Cold Starting Systems 55
  Harnesses 47-49D,51-53D
  Harness for Backhoe 53F
  Instrument Panels 47,49B,49F,55B
  Return-To-Dig 203
Emblem, slow moving vehicle 217
Emergency Steering 141B
Engine Mounts 43
Engine Subassemblies
  Alternator 35
  Balancer 25
  Camshaft 13B
  Crankshaft 19,19B
  Cylinder Block 17,17B
  Cylinder Head And Cover 13
  Flywheel And Housing 19,19B,19D
  Fuel Filter System 33F
  Fuel Injection System 31
  Gasket Kits 27
  Injection Nozzles 33F
  Injection Pump 33B,33D
  Injection Pump Drive 29
  Oil Filter And Heat Exchanger 23,23B
  Oil Pump And Pan 25
  Manifolds, intake and exhaust 11
  Piston And Connecting Rods 21,21B
  Starter 37-41
  Timing Gear Cover 29
  Valve Mechanism 15
  Water Manifold And Thermostat 9
  Water Pump 9B
Evaporator, alcohol 115
Exhaust, pipe and mufflers 61

740327 C

Printed in U.S.A.

Issued February, 1978

MidWestTech | Case W14 Loader Parts Catalog | Publication E1211 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

F

Fan, radiator 43
  Mounting 9,43
Fenders 153,157
Filters
  Air Cleaner 59
  Air, governor 121
  Engine Oil 23,23B
  Fuel 33,33B,149
  Hydraulic Tank 155
  Transmission Oil 67,83
Flasher Lights 161,163
Flywheel, engine 19,19B
Frames
  Articulated, front 157
  Articulated, rear 147
  Loader Lift 175
Fuel Injector 31,33B
Fuel Lines 31,33,149
Fuel Tank (without electric fuel pump) 149
Fuel Tank (with electric fuel pump) 149B

G

Gaskets, engine (Service Kits) 27
Gauges 47,49F,53,53D,59,111
Gears
  Engine (See Engine Subassemblies)
  Transmission (See Transmission Subassemblies)
Governor, air compressor 119,121
Grille 151
  Backhoe Models 151B
Guards
  Engine Side Panels 151
  Roll-Over Protection Structure 165
  Undercarriage 157B

H

Head, engine 13
Heater
  Block, engine 17,17B
  Cab 167,169
  Manifold 11,51
Hood 151
Horn, air 127,135
Hose and Fitting Chart 218
Hose, radiator 43
Hoses (See Fuel Lines, Brake Assemblies And Hydraulic Circuits)
Hydraulic Circuits
  Loader Bucket (Clam) 179,189
  Loader Bucket (Dump) 187
  Loader Lift 185
  Primary 181
  Pump To Loader Valve 183
  Steering, pump to cylinders 143
  Steering, pump to reservoir 141,141B
  Transmission 83
Hydraulic Tank Assemblies 155

I

Index, numerical . . . . . 218 on
Instrument Panel 47,49B,49F,55B
Instruments (See Gauges)

L

Lights 47-51,57,161,163
Loader Arm, mechanical parts 175
Lockup Parts 151D
  Backhoe Models 151F

M

Manifold
  Exhaust 11
  Heater 11,51
  Intake 11
  Water 9
Mounts
  Axle 103,105
  Engine 43
  Radiator 43
  Transmission 85
Mufflers 61
  Backhoe Models 61B

N

Noise Reduction Parts 167D
Nozzle, fuel injector 33F
Numerical Index 219

O

Oil Cooler, engine 23
Oil Pan, engine 25

P

Parking Brake 77,111
Pedal, accelerator 63
Pedal, brake (Treadle) 127,129
Piston Assemblies, engine 21,21B
Pulleys
  Air Compressor 113
  Alternator 35
  Alternator And Fan Drive 19
  Fan Mounting 9
  Pump Drive, water 9
Pumps
  Engine, oil 25
  Fuel Injection 33B,33D
  Fuel, electric 149F
  Fuel, primer 33B,33D
  Hydraulic Oil 141,181,197
  Steering 137,139
  Torque Converter 65,65B
  Transmission Charging 79,79B
  Water, engine 9B

MidWestTech | Case W14 Loader Parts Catalog | Publication E1211 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

R

Radiator, cooling 43
Regulator, voltage 51
Reservoirs
  Air 123
  Fuel 149
  Hydraulic Oil 155
Rims, wheel 109
Rings, engine piston 21
Rocker Arms, engine 15
Rods, connecting 21,21B
Rods, push 15
Roll-Over Protection Structure 165

S

Safety Chamber 111,133
Seat Assemblies 159
Shafts
  Axle (See Axle Assemblies)
  Engine (See Engine Subassemblies)
  Transmission (See Transmission Subassemblies)
Shroud, radiator 151
Side Panels, engine 151
Sleeve, piston 21,21B
Solenoid
  Manifold Heater 51
  Starter 41
Starter, engine 37-41,51
Starting Aid (Ether Injection) 55
Steering 139-143
Steps 157

T

Temperature Sending Unit 9
Thermostat, water temperature 9
Timing Gear And Cover, engine 29
Tire Inflation Kit 113
Tools, service 217
Torque Converter 65,65B
Transmission Mounts 85
Transmission Subassemblies
  Axle Output Shaft and Parking Brakes 77
  Charging Pump 79
  Control Valve 79
  Converter Housing, Gears And Transmission Housing 67

T

  Forward Clutch And Planetary 71
  Front Cover, Input Shaft And Torque Converter 65,65B
  High Range Clutch And Transfer Gear 75
  Hydraulic System 83
  Oil Filter 83
  Overhaul Kit 81
  Reverse Clutch And Planetary 73
  Turbine Driven Gears And Freewheel Unit . . 69
Trunnion, rear frame 147
Turn Signals 161,163

V

Valve Mechanism, engine 15
Valve Parts, hydraulic control 209-215
Valves
  Air Shutoff 127
  Air Pressure Protection 127,135
  Air Pressure Regulator 127,133
  Brake Control 127,129
  Breather, axle 103
  Breather, transmission 67
  Clutch Cutout 123
  Emergency Brake 111
  Drain, air reservoir 123,129
  Drain, engine oil cooler 23,23B
  Drain, radiator 43
  Flow Control, steering 141
  Horn 135
  Loader Control, 2 spool 199
  Loader Control, 3 spool 201
  Tire, valve stem 109
  Torque Converter 67
  Transmission Control 79
  Check, double 123,133

W

Wheel, steering 137
Wheel, tire 109
Wiper, windshield 161
Wire (See Electrical Circuits)

740029 B

Printed in U.S.A.

Issued February, 1978

MidWestTech | Case W14 Loader Parts Catalog | Publication E1211 Order the manual at mid-west-tech.com >