530CK Tractor

Parts Catalog

E910

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

CASE 530 CONSTRUCTION KING TRACTOR

ALPHABETICAL INDEX

ENGINE SECTION

	159 GAS	188 DIESEL
AIR INTAKE AND EXHAUST SECTION		
AIR CLEANER	19	51
MANIFOLD	19	51
MUFFLER	19	51
COOLING SECTION		
FAN	5	37
RADIATOR	5	37
THERMOSTAT	5	37
WATER PUMP	5	37
ELECTRICAL SECTION		
BATTERY	29	61
DISTRIBUTOR	31	-
GENERATOR	33	63
STARTING MOTOR	35	65
INSTRUMENTS	67	67
ENGINE SECTION		
BLOCK ASSEMBLY	11-11B	41D-43B
CAMSHAFT & BUSHINGS	13	45
CONNECTING ROD & BEARINGS	15	47
CRANKSHAFT & BEARINGS	13	45
FLYWHEEL	13	45
GASKET KITS	7	39
HEAD ASSEMBLY	9	41-41B
MANIFOLDS	19	51
OIL PAN	17	49
OIL PUMP	17	49
ROCKER ARMS	9	41-41B
TIMING GEAR COVER	25	53
PISTONS & RINGS	15	47
PUSH RODS	9	41-41B
VALVE GROUP	9	41-41B
WATER PUMP	5	37
FUEL SECTION		
CARBURETOR	23-23B	-
FILTER	21	57
GOVERNOR	25	-
INJECTORS	-	55
INJECTION PUMP	-	57
TANK & LINES	21	55
THROTTLE CONTROLS	27	50
LUBRICATION SECTION		
DIPSTICK	17	49
OIL FILTER	17	49
OIL PAN	17	49
OIL PUMP	17	49

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

BASIC TRACTOR SECTION

AXLE, FRONT 109
AXLE, REAR 103
AXLE HOUSING, REAR 99
BRAKES 105
BRAKE PEDALS 105
CLUTCH-STANDARD 73
CLUTCH PEDAL 85-99
CLUTCH-IND. P. T. O. 147
CLUTCH-STD. P. T. O. 95
DECALS 157
DIFFERENTIAL 103
DIFFERENTIAL LOCK 103B
DRAFT-O-MATIC SECTION
- ADJUSTING LINK. . . . 123-123B
- DRAFT ARMS 121
- LIFT ARMS & LINKS 119B
- PUMP, HYDRAULIC 133
- ROCKSHAFT 119
- SENSING LINKAGE. . . 123-123B
- VALVE CONTROLS 125
- VALVE PARTS 127

DRAWBAR 149
FENDERS 149
GEAR-FINAL DRIVE 103
GEAR SHIFT 97
GRILLE-RADIATOR 71
HEATER-ENG. BLOCK 155
HORN 155
HYDRAULICS-REMOTE
- ADAPTER HOUSING . . . 129-131
- CONTROL LINKAGE. . . 135-137
- COUPLINGS 139
- CYLINDER-2-1/2 x 8". 141
- CYLINDER-3-1/4 x 8". . . . 141B
- HOSES-FRONT. 139
- HOSES-REAR 141-141B
- PUMP, HYDRAULIC 133
- VALVE, CONTROL. 133

INSTRUMENT PANEL. 67
INSTRUMENTS 67B
LIGHTS
- FLOOD AND TAIL 69
- FUSE 67
- HEAD. 69
- INSTRUMENT 67B
- STOP AND TAIL 155
- SWITCH 67
- WARNING LAMP 153
- WARNING FLASHER. 153

PLATFORM 149
P. T. O. -INDEPENDENT. 145
P. T. O. -STANDARD 143
SEAT 151
STEERING SECTION
- CYLINDER 117
- HYDROSTATIC LINES. 111
- PUMP - MANUAL. 113
- PUMP - POWER. 115
- RESERVOIR 115
- TIE ROD. 109
- VALVE - CONTROL 113
- WHEEL 111

TOOL BOX 149
TORQUE CONVERTER DRIVE
- ADAPTER HOUSING 79
- CONTROL LINKAGE. 85
- CONVERTER PARTS 77B
- HOUSING-CONVERTER. . . . 77
- OIL COOLER. 5-37
- OIL COOLER TUBES 81
- OIL FILTER 81
- PUMP-DRIVE 83
- VALVE-CONTROL 83
- VALVE-REGULATOR 79

TRANSMISSION SECTION
- 4 SPEED COVER 97
- 4 SPEED GEARS 101
- 8 SPEED COVER 87
- 8 SPEED GEARS 91
- 12 SPEED COVER 93
- 12 SPEED GEARS. 93
- SHUTTLE COVER 87
- SHUTTLE GEARS. 89

WEIGHTS-FRONT WHEEL. 107
WHEELS-REAR 107
WHEEL-STEERING 111

Order the manual at mid-west-tech.com >